
OpenTower Designer

CONNECT Edition (10.02.00.05)

User Manual



Last Updated: March 21, 2021

Table of Contents

1	Getting Started	8
	Services and Support Information.....	9
2	Summary	10
3	Introduction	11
4	Tower Geometry	12
	Base Geometry	12
	Section profiles	13
	Materials	13
	Modeling Panels and Bays.....	13
	Open an Existing Tower Model	14
	Creating a New Tower Model	14
	Import a tnxTower file into OpenTower.....	22
	Section Detail.....	23
	Section Editor	25
	Geometry	25
	Bracing Connections	28
	Leg Connection.....	30
	Design Parameter Page	36
	Edit Section Overview	38
	Edit Custom Capacity	39
	Section Detail (Monopole)	40

Guy Details.....	42
Anchor Group Details.....	43
Attachment Details.....	44
Modifications.....	47
Highlighting Member	49
5 Work Order.....	51
Configure Work Order	51
User Settings	52
Project Data.....	52
6 Loading Definition	54
Wind Definition	54
Building code	55
Wind Parameters	56
Adjustment Factors	65
Load Combination Parameters.....	66
Existing Structure	67
Seismic Definition.....	68
Create a Seismic Definition	68
7 Appurtenances.....	72
Appurtenance Group	72
Discrete Appurtenance.....	74
Mount Level Summary	74
Level Details.....	78
Miscellaneous	81

Output Summary	81
Linear Appurtenance	82
Linear Attachment Table	83
Linear Appurtenance Table	85
FeedLine Tool	86
Appurtenance Configuration	90
8 Foundation Definition	92
Isolated/MAT Footing Foundation.....	92
Isolated Footing Definition	92
Soil Parameters.....	93
Footing Properties.....	95
Pedestal Properties	96
Material Properties	98
Drilled Pier Foundation.....	99
Drilled Pier Definition	99
Soil Parameters.....	101
Drilled Pier Properties.....	102
Material Properties	105
Guy Anchor Foundation	105
Guy Anchor Definition	106
Soil Parameters.....	107
Guy Anchor Properties	108
Material Properties	110
Design Foundation and Foundation Output	111

9	Scenario Analysis	116
	Operations on Scenario	117
	Analysis	120
	Report.....	123
	Report Contents.....	124
	Print Group	126
	Page Setup Group.....	126
	Scale Settings	127
	Set Custom Margins	128
	Orientation.....	129
	Size	129
	Navigation Group.....	129
	Find dialog box.....	130
	Zoom Group.....	131
	Page Background Group.....	132
	Export group	132
10	Graphical Interface.....	135
	Standard Group.....	135
	View Group	136
	Selection Group.....	138
	Analysis Group	139
	Windows Group	140
	Axis Group.....	140
	Active Load Case Group.....	146

Active Scenario.....	146
Results Tab	147
View Results Commands.....	147
Member Design Tab.....	148
Tower Model Explorer.....	150
View User Settings.....	151
View Project Information	151
View Tower Panels.....	152
View Supports	153
View Mount	153
View Antenna	154
View Miscellaneous.....	154
View Linear Attachment	155
View Feedlines	155
Library Page.....	156
Truss Leg Library.....	156
User Provided Table (UPT).....	161
SPC Custom Section.....	171
Edit Config	174
Tower Profile Page.....	176
Examples Descriptions	178
Bentley Cloud Services	178
To Associate a ProjectWise Project with Your File	179
To Disassociate a ProjectWise Project from a File	180

OpenTower Analysis & Analysis Control Parameters	181
1. Linear Analysis.....	181
2. P-Delta Analysis	181
2.1 Introduction of P-Delta Effects	181
2.2 Introduction of P-Delta Analysis Methods	182
2.3 Iterative Method	183
2.4 Kg Method.....	183
2.5 Control Parameters	183
3. Nonlinear Analysis.....	184
3.1 Introduction of Newton Method	185
3.2 Introduction of Tension-Only Approaches	187
3.3 Introduction of Retention Guys to Initial Tension Routine.....	189
3.4 Control Parameters	190
Appendix	193
New Features and Updates	200
Index	210

1 Getting Started

OpenTower Connect Edition is purpose-built for analyzing and designing telecom towers. It can design different types of towers including monopoles, self-supported and guy masts. The program was developed by practicing tower engineers in collaboration with tower owners, consultants, and tower engineers. It is designed to capture the typical workflow of a tower analysis and modifications. A state-of-the-art technology (and graphics), the program is futuristic by design for its openness and user-friendliness. OpenTower can import tower models from legacy software, such as tnxTower.

It is a physical modeling system, where geometry is defined as a combination of multiple panels, starting from the top. Discrete and linear appurtenances can be easily attached and viewed through built-in catalogs and intuitive UI. OpenTower uses a modern graphical environment to get a realistic visualization of the model. Discrete and linear appurtenances are drawn to scale on your 3D tower model.

It has a comprehensive library of panel types and appurtenances that enables users to quickly generate telecom structures. It automatically generates loads for any number of directions with user-defined topographic configurations and quickly performs design checks. The program can create reports using the standard as well as user-defined templates. Reports can be exported in various formats, including PDF, HTML, CSV etc.

OpenTower Connect Edition supports US design Standards (EIA/TIA-222-F, TIA-222-G, and TIA-222-H).

You can design tower foundations (ACI 318) for tower legs and guy support points. It includes design for pad-pier, drilled pier, guy anchor, and mat foundations. The program can automatically design foundations for all the critical load cases for different criteria and automatically reports foundation rating.

Scenario analysis is an innovative approach and engineers will save time through scenario creation by combining geometric layers including modifications, appurtenance grouping, and loading criteria. It can create a physical model by applying hierarchical modification layers with revision history on top of the base geometry using built-in business logic. You can use advanced options like User-Provided Table (UPT) to create non-standard tower sections, materials and both discrete and linear appurtenances. You can use built-up sections, including industry-specific profiles like a split-pipe, bent plate, and more (30+ section types), as well as materials for virtually all global standards. With the help of the custom catalog, you can add any number of sections and shapes.

The program automatically calculates the effect of cluster formation on linear appurtenances. "Connection interface" can be used to easily define member connections with various bolt patterns including pre-defined bolt configurations. It automatically considers the effects of connections on member design calculations and check connections.

The result of the OpenTower building process is a complete OpenTower data file, that is saved, with the extension “STWR”.


Services and Support Information

Downloads and support of Bentley products are facilitated through Bentley CONNECT Services. For more detailed information visit [Bentley CONNECT services](#).

Technotes, FAQs and additional Bentley product information, can be found on the [Bentley Communities page](#). Here you can find answers to your technical questions about the program, as well as gain insight into current and emerging best practices in the industry.

Log issues that you encounter with Bentley products using the [Service Request Manager](#).

2 Summary



The first screen (or Start Page) that opens when you start the OpenTower application.

Many example problems can be found in the start screen of the program under the “Example Files” section.

3 Introduction

OpenTower is a program developed by practicing tower engineers, for practicing tower engineers, and in collaboration with practicing tower engineers. It is designed to capture the typical workflow of a tower analysis and modification. A state-of-the-art technology, the program is futuristic by design for its openness and being user-friendly as the user interface was laid out by practicing engineers for the best possible user experience.

One of the most important aspects of the program is to divide the modeling into two distinct categories.

- 1) Geometry
- 2) Work Order (or loading)

4 Tower Geometry


As the name suggests, this section is specifically dedicated to model the tower geometry. Geometry can further be divided in the following three categories.

- 1) Base Geometry
- 2) Modifications
- 3) Base Support (or boundary conditions)

Base Geometry


Base geometry contains original or unreinforced geometric properties of the tower. The application does not have any limitations on the size and complexities to model any telecom tower. It is a physical modeling system, where geometry is defined as a combination of multiple panels, starting from the top. Geometry includes three essential components.

- 1) Section profiles (shapes and sizes)
- 2) Materials
- 3) Panel definitions




Section profiles

The program is shipped with virtually all standard steel section catalogs including different versions of AISC catalogs. You can combine sections from different catalogs to support original sections and their properties. The program greatly improves performance and user-friendliness by adding a custom tower catalog, which includes many built-up shapes and sizes needed for the telecommunications tower industry. It is called “Custom-Tower Catalog”. Unlike standard AISC section catalogs, the custom catalog is editable and expandable. As you or your organization increasingly start using custom sections, those sections will be added to the catalog for future usage including reanalysis and modifications. A catalog can be shared among engineers and organizations.




Materials

Like the section profile catalogs, the program is shipped with standard materials catalogs. Additional materials can be added to the custom tower catalog.



Modeling Panels and Bays


You have three options to create a tower model in OpenTower. Create a new model, open an existing OpenTower file, or import an existing tnx tower(*.eri) file. These processes are explained below.



OpenTower Application

Open an Existing Tower Model

1. On the Start ribbon tab, select Open.




2. Browse to and select the desired OpenTower (.STWR) file to open.

Creating a New Tower Model

1. On the **Start** ribbon tab, Select **New**.




2. The Tower Setup wizard opens (Fig.3).

The Tower Setup wizard window is titled "Tower Setup". It features a sidebar on the left with "Tower Information" selected. The main area is divided into three sections: "Tower Summary" with dropdowns for Tower Type (Lattice), Upper Structure (None), and Guyed (No); "Unit System" with radio buttons for Imperial (selected) and Metric; and "General Data" with text boxes for Project ID (1), Tower Name (Demo Tower), Bearing Angle (deg) (0.0), and dropdowns for Tower Convention (US_CONVENTION), Design Code (EIA/TIA-222 standards), and Wind Code (EIA/TIA-222 standards). A central image shows a tall lattice tower against a blue sky. At the bottom are buttons for "Next", "Create Tower", "Cancel", and "Help".

Tower Information

3. Select Tower Type


Two types of tower structures can be parametrically generated using the tower generation wizard. Those are monopole (shown as Pole) and lattice (which includes self-supporting Tower and guyed tower). Each of these choices will create different pages on the left pane to help model that tower type. If you select the tower type as Pole, you should input Structure Details as shown in Fig.4. If you select Lattice as the tower type, you should input (Base) Structure Details as shown in Fig.5. In the tower information page, you must specify if the tower is a guyed tower in case of tower type is lattice. The guyed input is disabled for a pole. The upper structure option is disabled for both tower types in this version.



Monopole Tower Type

4. Lattice Tower Type.

Lattice Tower wizard can be used to model both self-supporting and guyed towers. To help model lattice tower type, on the left panel, you should input **(Base) Structure Details** as shown in Fig.5. In the tower information page, you must specify if the tower is a guyed tower. Default values can be used.



Lattice Tower Type

5. Specify the Tower Information. The field description is given below.

Parameter Name	Description
Tower Type	Pole or Lattice Tower can be selected
Guyed	For the Pole tower type, this option is disabled. For Lattice Tower Type, select Yes or No.
Unit Systems	Imperial
Project ID	Current Project ID
Tower Name	Name of the Tower, by default it's called Demo Tower.
Bearing Angle (deg)	Bearing angle of the Tower
Tower Convention	US Convention
Design Code	Select the design code standard to be used. The default standard is EIA/TIA-222.
Wind Code	Select the wind code standard to be used. The default standard is EIA/TIA-222.

6. Specify Tower Geometry.

For Lattice tower type, the (Base) Structure Details on the left panel will show the following options

Parameter Name	Description
Tower Shape	In Case of Lattice Tower Type, select between 3-Sided and 4-Sided.
Tower Height	Provide the total height of the tower above its base.
Top & Bottom Width	The width is the distance between adjacent legs. Provide the width at the bottom of the lowest panel and the top of the highest panel in these fields, respectively. For Guyed tower, the bottom width option is disabled.
Default Length of Section	Provide the default length of a section. It can be edited as needed in the “section detail” page.
Default No of Bays	Provide the default no of bays per section.
Default Face Bracing	Select from one of the predefined typical bracing patterns you want to apply for all panel faces by default. You can edit individual panel faces or levels as needed in the “section detail” page later.
Taper Start Elevation	Provide the start elevation from where the taper starts for non-guyed tower(self-supported). For guyed tower, this option is disabled.
Base Support	Select the support of the base you want to apply to the tower. For all lattice towers excluding the guyed towers with no taper base, the options are Fixed But Mx, Mz, Fixed and Pinned. For guyed towers with non-taper base, the options are Fixed But Mx, Mz, Fixed, Pinned, I-Beam, and I-Beam Pinned.


If you select Guyed in tower information, the following 4 parameters get enabled apart from the above parameter list.

Guy Taper Base Length	Provide the guy taper base length for bottom section of the tower.
No of Guy Levels	Specify the total number of guy levels along the height of the tower.
No of Anchor Groups	Provide the number of anchor groups.
Anchor Support	Select from the given options. The options are Fixed But Mx, Mz, Fixed, and Pinned.

Tower Information

Tower Information

(Base) Structure Details



Lattice Tower Geometry

Tower Shape: 3-Sided

Tower Height(ft): 150

Top Width(ft): 4

Bottom Width(ft): 18

Default Length of Section(ft): 20

Default Number of Bays: 3

Default Face Bracing: X Brace

Taper Start Elevation: 140

Guy Geometry

Guy Taper Base Length (ft):

No. of Guy Levels:

No of Anchor Groups:

Support Block

Base Support: Fixed but Mx,Mz

Anchor Support: Pinned

Pivot Height (ft): 0

Next
Create Tower
Cancel
Help

Base Structure Details for Lattice Tower

For Monopole tower type, Select the tower shape from the drop-down list in the Structure Details page. The options are Tapered, Stepped, and Hybrid. Depending upon the selected tower shape, the inputs will be changed accordingly.

The Structure Details on the left panel will show the following options if we choose the Tapered shape for the pole (Fig.7).

Parameter Name	Description
Dimension Input	Select one of the options to input dimensions. The options are Diameter Flat to Flat, Flat Width, and Perimeter.
Tower Height	Specify the total height of the tower, above its base in ft.
No of Sections	Provide the no. of sections.

Polygonal Sides

Specify the number of polygonal sides (8,12,16,18) or choose Round.

Length of Top Section

Provide the Length of Top Section in ft.

Top Diameter

Provide the top section diameter in inch.

Top Section Thickness

Provide the top section thickness in inch.

Taper Factor

Provide tapered factor.

Material Type

Choose the material type from the available options (steel or concrete)

Default Material

Choose the default material from the combo box.

Base Support

Select the Fixed base support. This input is common for all the pole shapes.

Tower Setup

Tower Information

Tower Information
Structure Details

Monopole Tower Geometry

Tower Shape: Tapered

Tapered Section

Dimension Input: Diameter_Flat_To_Flat

Tower Height (ft): 150

No of Sections: 4

Polygonal Sides: 18

Length of Top Section (ft): 45

Top Diameter (in): 22

Top Section Thickness (in): 0.25

Taper Factor (in/ft): 0.2

Material Type: STEEL

Default Material: A572 Gr.65

Support Block

Base Support: Fixed

Diagram illustrating the structure details for a tapered shape monopole tower. The diagram shows a tapered tower with labels for Top Diameter, Bottom Diameter, Tower Height, Panel Length, Lap Splice Length, No of Panels, and Tapered factor.

Next Create Tower Cancel Help

Structure Details for Tapered Shape Monopole Tower

The structure details for the Stepped monopole tower will show the following input (Fig.8).

Parameter Name	Description
Tower Height	Specify the total height of the tower, above its base in ft.
No of Sections	Provide the no. of sections.
Country	Select the United States
Specification	Provide the specification from the combo box.
Shapes	Select the shapes.
Default Section Profile	Provide the section profile from the option given in the combo box.
Material Type	Choose the material type from the available options (steel or concrete)
Default Material	Choose the default material from the combo box.
Base Support	Select the Fixed base support. This input is common for all pole shapes.

Tower Setup

Tower Information

Monopole Tower Geometry

Tower Shape: **Stepped**

Straight Section	
Tower Height (ft)	120
No of Sections	4
Country	United States
Specification	API 5L-ALPHA PIPE
Shapes	PIPE API 5L-PIPE-ALPHA
Default Section Profile	Pipe 16 STD
Material Type	STEEL
Default Material	A500 Gr. B

Support Block

Base Support: **Fixed**

Diagram labels: Top Diameter, Pipe Length, Tower Height, No of Panels, Bottom Diameter

Buttons: Next, Create Tower, Cancel, Help

Structure Details for Stepped Shape Monopole Tower

The hybrid shape monopole tower input (Fig.9) is the combination of Stepped and Tapered monopole input. Refer to page no 21 and page no 23.

Tower Setup
— □ ×

Tower Information

Tower Information

Structure Details

Monopole Tower Geometry

Tower Shape Hybrid

Tower Height 170

Straight Section

No of Sections 1

Country United States

Specification AISC:13 Edition:Gener

Shapes HSS-ROUND AISC13-I

Default Section Profile HSS12.750X.250

Material Type STEEL

Default Material A500 Gr. B

Tapered Section

Dimension Input Diameter_Flat_To_Flat

Tapered Pole Height (ft) 150

No of Sections 4

Polygonal Sides 18

Length of Top Section (ft) 45

Top Diameter (in) 20

Top Section Thickness (in) 0.25

Taper Factor (in/ft) 0.2

Material Type STEEL

Default Material A572 Gr.65

Support Block

Base Support Fixed


Next
Create Tower
Cancel
Help

Structure Details for Hybrid Shape Monopole Tower


7. Click the **Create Tower** Button to complete the wizard.

Import a tnxTower file into OpenTower

1. On the Import Page ribbon tab, Select **Import tnx tower**.




2. The **tnxTower Import** page opens as shown in Fig. 10.
3. Browse to and select the desired tnxTower file (.eri) to import.
4. Click on **Import**.



Tnx Tower Import Page

The program generates a log file in the tnxTower model folder. The log file reports the messages related to the data imported from the tnxTower file and lists any error and warning messages related to the geometry, sections, and materials.

Section Detail



Section Detail Page

The section detail page contains all the information about each section. You can add new sections or delete and copy existing sections (Fig. 11). To modify the geometry of the model, you can use the section detail page.

Note: The recommendation is to input the custom capacity after defining the scenarios.

You can also add or delete a section by right-clicking on the Base Structure Overview table. The popup as shown in Fig. 11 (above) will appear.

Parameter

Base Tower Type

This will always be set during the initial setup and cannot be edited by the user once they exit the initial setup. Available options are Lattice 3-Sided and Lattice 4-Sided.

Section ID


Automatically assigned to each section from the top to the bottom. If a new section is added, it is always assigned as the first section (Section ID 1) and all other section numbers increase by one.

Top Elevation (ft)	The height at the top of a given section, not including the base elevation. For lattice towers, this is simply the sum of the current section height and all the sections below.
Section Length (ft)	The total length of the section is equal to the sum of all the bay lengths plus the top and bottom girt offsets. You can edit the section length.
No of Bays	It is the number of braced sub-sections the tower section is divided into.
Top Girt Offset (in)	The vertical distance from the top of the leg section to the working point where the first bay begins.
Bottom Girt Offset(in)	The vertical distance from the working point where the last bay ends to the bottom of the leg section.
Spacing (ft)	This is the length of each bay from the top to the bottom of the section. By default, each section is divided into equal bay height.
Top Width/(Depth) (ft)	Width of the tower face at the top of each section as measured from center-to-center of the legs. For all but the top section, this is automatically set equal to the Bottom Width of the section above.
Bottom Width/(Depth) (ft)	Width of the tower face at the bottom of each section as measured from center-to-center of the legs.
Face Bracing	This is not user input, but simply a summary of the bracing types that are selected in the Section Editor. If the bracing type varies within a section, the table will have a comma-separated list of the bracing types for each bay from the top to the bottom of the section.
Plan Bracing	A summary of the plan bracing for each bay as specified in the Section Editor.
Hip Bracing	A summary of the hip bracing for each bay as specified in the Section Editor.

Section Editor

Due to the complexity of a lattice base structure, the Section Editor is designed to customize one section at a time. The Base Structure Overview for lattice structures will only allow you to define the dimensions of the super-structure. Member and connection detailing definitions for individual members, you will have to use the Section Editor. You can either click on **Edit Section Details** (shown in Fig.11) or double-click on a section in the “Base Structure Overview” section to open the Section Editor Window. You can edit geometry, bracing connections, leg connections and design parameters in the Section Editor window. Section Editor can be used to edit bay spacing, choose bracing patterns, assign Section profiles, define connections, and define design parameters. The section editor is divided into three tabs, one for the geometry, one for the connections and one for design parameters. The geometry tab can be seen below as shown in Fig.12.

Geometry



Section Editor Geometry

The Geometry page of the section editor can be used to edit all possible properties of a given section, which can be selected from the Section ID combo box. Basic input parameters are the number of bays and the section length.

Section ID

This is a drop-down list with every all the sections of the tower. The section editor automatically opens to whichever section was selected on the Tower Overview,

	but you can change the tower sections without returning to the Tower overview.
Top/Bottom Elevation	These are non-editable fields displayed for reference. This information can only be adjusted in the Tower Overview.
Top/Bottom Face Width	These are non-editable fields displayed for reference. This information can only be adjusted in the Tower Overview.
Top/Bottom Face Depth	These are not inputs and are displayed for reference only. Also, it is displayed for 4-sided towers only.
Section Length (ft)	You can input a section length here and the program should automatically adjust the table to evenly distribute the section length to the correct number of bays. However, if you change the length of an individual bay or adds a bay to the section, the section length should automatically update to reflect the sum of all bay lengths and girt offsets.
No of Bays	This input directly edits the number of bays, the program evenly distributes the section length to the correct number of bays. However, if you add or delete a bay from the table, the number of bays in this box gets updated.
All Faces Identical (Checkbox)	When this option is checked you only need to enter data for face A and all other faces will use the same configuration. Checked by default. Member class Step does not get copied to the other faces and user has to input the profiles on each face if needed.
All Hips Identical (Checkbox)	When this option is checked you only need to enter data for Leg A hips and all other hips will use the same configuration. Checked by default.
All Bays Identical (Checkbox)	When this option is checked you only need to enter data for Bay 1 and all subsequent bays will be identical. Checked by default. Member class Bottom Horizontal does not get copied to the other bays as this class is applicable to the bottom segment of the panel.
Girt Offsets	Girt offsets are applicable for the top and bottom bays only. All middle bays have this column inactive. If "All Bays Identical" is checked then the bottom girt offset automatically made equals to the top girt offset.

Top Horizontal

The Top Horizontal of the Bay.

Bottom Horizontal

The Bottom Horizontal is applicable to only bottom bay of the section.

Secondary Horizontal

The secondary horizontal of the Bay.

Bracing Table**

The bracing table is consisting of a few tables including one for each face, hip, and plan. The members can be assigned by double-clicking a cell to open the Section Profile Catalog. The default columns available for all face bracing types are Leg, Diagonal, Top Horizontal and Bottom Horizontals. However, depending on the selected bracing type, the columns may vary. The tables in the hip and plan tabs are different than the face tab and columns may vary depending on the selected bracing type. Refer to appendix for more details on different bracing patterns.

Section Profile Page

The section Profile Page (Fig. 13) can be used to edit or assign a section profile to a member. You can choose from any of the section catalogs including the custom tower catalog. Section and Materials can be Standard, Custom, or UPT. Depending on the type of selected catalog, available sections and materials are populated in the grid. You can mix and match, like select a section from a standard catalog along with a custom material, etc.

SectionProfile

Section

☒ Standard 3.1.4.5 ☐ Custom CustomTower_1.0.0.1 ☐ UPT ☐ Truss Leg

Material

☒ Standard 3.1.4.5 ☐ Custom CustomTower_1.0.0.1 ☐ UPT

Select Criteria

Country: United States

Specification: AISC:13 Edition:Generic

Shapes: PIPE

Section Profile: Pipe2SCH40

Material

Material Type: STEEL

Material: A53 Gr. B


Design...	A (in2)	W (lbf...	OD (in)	ID (in)	TDES (...)	TNOM	CATAL...
Pipe1/...	0.23	0.85	0.84	0.622	0.101	0.109	AISC1...
Pipe3/...	0.31	1.13	1.05	0.824	0.105	0.113	AISC1...
Pipe1S...	0.46	1.68	1.315	1.049	0.124	0.133	AISC1...
Pipe1~...	0.62	2.27	1.66	1.38	0.13	0.14	AISC1...
Pipe1~...	0.75	2.72	1.9	1.61	0.135	0.145	AISC1...
➤ Pipe2S...	1	3.66	2.375	2.067	0.143	0.154	AISC1...
Pipe2~...	1.59	5.8	2.875	2.469	0.189	0.203	AISC1...
Pipe3S...	2.08	7.58	3.5	3.068	0.201	0.216	AISC1...

Cancel OK

Section Profile

Bracing Connections

The bracing connection user interface allows users to assign bracing connections to the bracing members of a lattice tower. Though bracing connections on lattice towers are simple, they can be numerous and occasionally complex. The main goal of this interface is to allow the user to model the typical cases quickly while still having the flexibility to model complex connections as needed (Fig. 14).



Bracing Connections Page

Parameter

Bracing Connected Directly to Leg

This option is used to adjust the member lengths when bracing members are bolted or welded directly to the leg members. When checked, the effective length of the bracing members will be calculated from the internal edge of the leg members.

Member End Adjustment Length

This option is used to adjust the member length from both ends.

Section Adjustment Factors

These inputs are used to increase or decrease the wind area and weight of the section.

Group by Member and Type (Checkbox)

Checked by default. When checked all members of the same type and section property are grouped into one row.

Check Gusset Connections (Checkbox)

When checked four additional columns are enabled and user can define the start and end connection details for Gusset Horizontal Edge Distance (Gusset Hor.) and Gusset Vertical Edge Distance (Gusset Vert.). When unchecked these columns are disabled. The Gusset Horizontal Edge distance is further used to perform gusset bearing check calculations.

End Condition

This input allows the program to do two things. First, it helps to design the bolt connections correctly using the shear condition on the bolts. All concentric connections are assumed to be double shear. Second, it allows the program to choose the effective slenderness ratio equation for design calculations.

Pattern*

This is the bolt pattern used to connect the bracing member. Zero is an option if the connection is welded or requires special design consideration. Refer to Appendix.

Edge/Pitch/Gage/Gage Spacing

Provide the measurements of gage and edge distance. When bolt patterns are staggered, the pitch is the distance between two bolts in a row.

Gusset Horzi. /Gusset Vertical

These options are activated by the "Check Gusset Connection" checkbox. When active you can specify a horizontal and vertical edge distance from the gusset to the reference of the bolt group. If you enter zero for the vertical edge distance, then the bolt group is assumed to be in the middle of the gusset plate where there is no block rupture path involving the top or bottom edges of the gusset.

Mirror (Checkbox)

When checked for an individual row this makes the end connection the same as the start connection. The top box is meant to toggle this option for all rows.

Gussets


Gusset area can be calculated from height and width or entered directly. If the area is entered, then the application considers the area of gusset as flat area in the wind load calculations and is also considered to include the weight of the gusset plate in the self-weight calculations. Thickness and

Material are used to calculate the correct weight and to check the bolted connection on the gusset.

The Panel view on the right shows the image of the connection that gets updated based on your input.

Leg Connection

Leg Connection UI is used to define the leg connection of a lattice tower. The program supports four types of Leg Connections - Flange, Splice, Shear Sleeve, and Base Plate. Base Plate option is available only for the bottom section of the tower. The input parameters will change, depending upon the selected leg Connection Type. The different connection types with the input parameters are described below.



Leg Connection Page for Flange Connection Type

The Panel view on the right, shows the image of the connection that gets updated based on user input.

Parameter	Description
No of Bolts	Provide the no of bolts
Bolts	Select a bolt type. You can double-click on the field to open the Select Bolt UI, where you can select bolt type and

Leg Connections Identical

Material from the standard or the UPT catalog as shown in the image below (Fig.16). The concatenated string of the Bolt type and Material will be automatically displayed in the field, once clicked ok.

For all Leg Connection details to be identical, check the Leg Connection Identical checkbox.

The dialog box titled "Select Bolt" contains two main sections: "Bolt Types" and "Bolt Material".

Bolt Types Section:

Name	Diamet...	GrossA...	NetAre...	TPI
1-3/8	1.375	1.48	1.15	6
1-1/2	1.5	1.77	1.41	6
1-3/4	1.75	2.41	1.9	5
2	2	3.14	2.5	4.5
2-1/4	2.25	3.98	3.25	4.5
2-1/2	2.5	4.91	4	4
2-3/4	2.75	5.94	4.93	4
3	3	7.07	5.97	4
3-1/4	3.25	8.3	7.1	4
3-1/2	3.5	9.62	8.33	4
3-3/4	3.75	11	9.66	4
4	4	12.6	11.1	4

Bolt Material Section:


Name	Fy (ksi)	Fu (ksi)
A325 (...)	92	120
A325 (...)	81	105
A36	36	58
A193...	105	125
A193...	95	115
A193...	75	100
A307...	36	60
A354...	130	150
A354...	115	140
A449 (...)	92	120
A449 (...)	81	105
A449 (...)	58	90

Bolt Connection Type Section:

☒ Threads Included in Shear Plane (N)
☐ Threads Excluded from Shear Plane (X)

Buttons: Cancel, OK

Select Bolt Types and Material



Leg Connection Page for Shear Sleeve Connection Type

Parameter

Shear Sleeve Type

Bolts

Number of bolts

Edge Distance

Bolt Shear resist leg compression (checkbox)

Description

Select from the options, Double Shear and Single Shear.

Select a bolt type. You can double-click on the field to open the Select Bolt UI, where you can select bolt type and Material from the standard or the UPT catalog as shown in Fig.16. The concatenated string of the Bolt type and Material will be automatically displayed in the field, once clicked ok.

Specify the number of bolts.

Specify the edge distance in inch.

If you check the bolt shear resist leg compression checkbox, the program will perform the bolt shear resist leg compression check.

Leg Connection Page for Splice Connection Type

If Upper and Lower Splice Identical checkbox is checked, input from the Connection to Upper leg will be duplicated to the Connection of Lower Leg. If not checked, the user must input values for the lower leg.

Note: For guys towers, TIA-222-G and TIA-222-H clause 4.9.7 can be considered from scenario options

Parameter

Description

Connection to Upper and Lower Leg

Splice Type

Select from the options, Double Shear and Single Shear.

Bolts

Select a bolt type. You can double-click on the field to open the Select Bolt UI, where you can select bolt type and Material from the standard or the UPT catalog as shown in Fig.16. The concatenated string of the Bolt type and Material will be automatically displayed in the field, once clicked ok.

No of Bolts

Specify the number of bolts.

Columns

Specify the number of columns

Patterns

Select from the options, Aligned, Positive Stagger and Negative Stagger.

Column Spacing	Specify column spacing in inch, by default auto is used.
Leg Edge Distance	Specify column spacing in inch, by default auto is used.
Pitch	Specify column spacing in inch, by default auto is used.
<i>Outside and Inside Splice Plate</i>	
Material	Select material from the combo box. This option is enabled only if Check Splice Plate checkbox is checked.
Thickness	Specify the Splice Plate thickness in inch. This option is enabled only if Check Splice Plate checkbox is checked.
Width	Specify the splice plate width in inch. This option is enabled only if Check Splice Plate checkbox is checked.
Edge Distance	Specify the edge distance in inch. This option is enabled only if Check Splice Plate checkbox is checked.

Section Editor

Geometry

Bracing Connections

Leg Connections

Design Parameters

Section ID: 8

Section Length: 20.0000 ft

Number Of Bays: 3

Top Elevation: 20.0000 ft

Top Face Width: 16.0000 ft

Leg A | Leg B | Leg C

Connection Type : Base Plate

Bolted Connection Summary

Bolt Data

Plate Data				Bolt Data								
Type	Diameter (in)	Thickness (in)	Material	Quantity	Diameter (in)	Material	Thread Type	Bolt Circle (in)	Extreme Fiber	ETA Factor	Lar (in)	Grout Considered
Circle	0	0	A36	0				0	Bolt	0.5	0	No

Resist Axial (Pu)	Resist Shear (Vu)	LegModEccentricity	Consider AnchorRodEccentricity
Yes	Yes	0	<input checked="" type="checkbox"/>

Leg Connection image


Leg Connection Page for Base Plate Connection Type

Parameter	Description
<i>Plate Data</i>	
Type	Select from the options, Circle and Square.
Diameter (in)	Specify the diameter of plate in inch.

Thickness (in)	Specify the thickness of plate in inch.
Material	Select material from the combo box.
<i>Bolt Data</i>	
Quantity	Specify the number of bolts.
Diameter (in)	Select a bolt type. You can double-click on the field to open the Select Bolt UI, where you can select bolt type and Material from the standard or the UPT catalog as shown in Fig.16. The concatenated string of the Bolt type and Material will be automatically displayed in the field, once clicked ok.
Material	It's a read only parameter and gets populated after user selected the bolt diameter, material, and thread type in Select Bolt UI.
Thread Type	It's a read only parameter and gets populated after user selected the bolt diameter, material, and thread type in Select Bolt UI. Options threads included in shear plane or excluded from shear plane.
Bolt Circle (in)	Specify the bolt circle in inch.
Extreme Fiber	Select from the options Bolt and Bolts. represents different arrangement of bolts. Refer to appendix
ETA Factor	Select from the options, 0.5,0.55,0.7, and 0.9. This option is used in the calculation for TIA-222-G design standard scenario.
Lar (in)	Specify the lar in inch. "Lar" is the anchor rod projection from supporting surface to bottom of leveling nut.
Grout Considered	Select from the options Yes and No. This option is applicable for TIA-222-G and TIA-222-H only. In case of Yes, the anchor rod bending interaction equation is secluded from the design checks whereas in case of No, based on the selected standard scenario, the design checks performed.
Resist Axial (Pu)	Select from the options Yes and No.
Resist Shear (Vu)	Select from the options Yes and No.
Leg Mod Eccentricity (in)	Specify the eccentricity due to leg modification shapes connected to the baseplate.
Consider Anchor Rod Eccentricity	Check or uncheck the option to consider the eccentricity due to anchor rod locations. Default is checked always.

Design Parameter Page

The design parameters section allows you to specify all additional information needed to perform member design checks.



Design Parameter Page

Parameter

Group by Member and Type (Checkbox)

Connection Type

Connection Spacing

Description

Checked by default. When checked all members of the same type and section property will be grouped into one row and assumed to have the same member design properties.


This option defines the intermediate connection type for composite members. The options are bolted or welded.

Define the intermediate connection spacing for composite members. The default option is a special input of “Mid-Point” which will calculate the intermediate connector spacing based on half of the effective length.

End Connection	It is used to define how two composite members are connected at the termination. Options are fixed or free. The default option is fixed.
Fully Composite	The user must select from, “Yes” or “No” options. The default option is No. This is a design option for the custom composite sections.
Crushing Possible	The user must select from “Yes” or “No” options. The default option is No. This option is used when a small part of the member is unreinforced. The section must be too small to buckle but could still fail in compression yield.
Tension Reinforced	The user must select from “Yes” or “No” options. The default option is Yes. Some sections may have different effective sections in compression and tension.
Consider Eccentricity	The user must select from “Yes” or “No” options. The default option is No. This option allows you to consider the effect of member offset from the analytical centerline.
U factor	The shear lag factor. The default is “auto”. This option will allow you to override the calculated U factor.
LE(x/y/z)	Effective length in feet. The default value is “auto”. Sometimes you will need to override the effective length to ensure the correct effective length is used. X, Y, Z are the local axes of the member.
K(x/y/z)	Effective length factor. The default is “auto”. This will allow you to override the calculated value.
Passing Rating	The percentage value used to differentiate a Pass Member and a Fail Member for a specific design code check. This value is inactive in this table and can be edited from the wind definition.

Once you are done with all the inputs and modifications, click Apply and then OK, to save the changes made in the tabs. Then click Apply and OK on the Section Detail Page (above Fig.11) to apply the changes in the model. The message box will ask for the confirmation **“Want to Update the Base Model”**. If you click ok, it will automatically update the base model with the changes.

The hip Bracing tab shows the Hip bracing properties of all the sections in a single table. If **Show Connection Details** checkbox is checked it will show the connection parameters in the page.




Section ID	Top Elevation (ft)	Inner Bracing
1	60	
2	50	
3	40	
4	30	
5	20	
6	10	

Section Overview Page-Inner Bracing

Inner Bracing tab shows the Inner bracing properties of all the sections in a single table. **Show Connection Details** checkbox, if checked will show the connection parameters, in the page.

Edit Custom Capacity

The Edit Custom Capacity table can be accessed after activating the scenario. You must use Edit Custom Capacity to override the design capacities of any member. Once you click the Edit Custom Capacity button, Custom Capacity UI (shown in Fig. 25) will appear. You can input the fields that are shown as “auto” to override those capacities with your preferred values. Click Apply and Ok to save the changes. Capacities are separated for each revision of the code, TIA-222-F, TIA-222-G, and TIA-222-H. The fields that can be updated are Member Tension, Member Compression, Connection Compression, Connection Tension, and Passing Rating.



Member ID	Member Type	Member	Member Compression (Kips)	Member Tension (Kips)	Connection Compression (Kips)
23,24	LEG	Pipe25CH40 A53 Gr. B	auto	auto	auto
152,153,158,159,164,...	DIAGONAL	L2X2X3/16 A36	auto	auto	auto

Custom Capacity Page


Section Detail (Monopole)

The Section detail page for monopole towers contains all the information about each section. Fig.26 shows the section detail page for Tapered monopole.

For table editing operations a user can right-click on the Pole Overview table and then select from the options like Copy Row, Insert Row, Delete Row and Cancel.

The Add section button will add a new section and will be displayed in the Pole Overview table, and the Remove Section will remove the selected section from the Pole Overview table.

The grayed cells cannot be edited. The followings are the details of the Section detail page for monopole towers.



Monopole Section Detail Page

You can add new sections or delete and copy existing sections (Fig. 26). To modify the geometry of the model, you can use the section detail page.

In order to efficiently model all types of monopoles, a user may choose different types of Input Methods. Depending on each method, different columns and cells within the table will be enabled and disabled. The “Detailed” method allows users to create any combination of custom tapered sections and sections from the section profile catalog. All other input methods are for tapered poles only and will be used to reduce the number of inputs for the user by interpolating much of the data. The different input methods are explained below.

Detailed: When a tower is created in the detailed method or the user switches to the detailed method and applies the changes, they will not be allowed to switch to any other input method.

Taper Factor: This method requires the minimum amount of user input but will be limited to tapered monopoles only. As this method is restricted to tapered poles, the “Flange” and “Database” options are not available for connection type and section type respectively.

Mapped – Detailed: A detailed mapping of a tapered pole typically includes the top dimensions of the top section and the bottom dimensions of every other section. In this case, the user will

enter the Measured Length of each section rather than the exact length and the program will calculate the lap splice lengths, taper factor, and top dimensions for each section.

Mapped – Taper Factor: Mapped taper factor requires the top and bottom dimensions of the top section. This method forces each section to have a uniform taper factor and the program will calculate the lap splice lengths, taper factor, and top and bottom dimensions.

Mapped – Limited: In this case, the program will solve for a taper factor that gives the correct dimensions at top and bottom.

Parameter	Description
Tower Type	The monopole type is selected.
Input Method	Select from the five types of input methods that are, Detailed, Taper Factor, Mapped-Detailed, Mapped Taper Factor and Mapped Limited. For Stepped and Hybrid monopole, the only available option is the Detailed input method. Depending upon the selection, the Preferred Section Dimension option will change, and the pole overview table will allow editing specific columns.
Preferred Section Dimension	For polygonal poles, there are three ways to input the section dimensions. Users can select Diameter (Flat to Flat), Flat width, and Perimeter. The selection of the input method will change the options for the preferred section dimension. If a user selects the input method as Detailed, the Preferred Section dimension will only have one option, i.e., Diameter (flat to flat), as polygonal and round sections can be combined. For other input methods, it will show all three options.
Section ID	Automatically assigned to each section in order from top to bottom. If a new section is added, it is always assigned Section ID 1 and each other section ID increases by one.
Top /Bottom Elevation (ft)	These are non-editable fields displayed for reference. This information will be auto updated based on the section length and design lap splice length inputs.
Measured Length (ft)	Provide Section length. For mapped towers, only the visible length of the section can be measured.
Connection	Select the connection. Depending upon the Input method selection, the options will change for Connection input. The options are Flange, Lap slice, Base Plate, None. The bottom section of a tower has two options None and Base Plate, the Base Plate option is only available on the bottom section. Application does not perform the connection calculations in this version

Design Lap Slice/Socket length (ft)	Provide the Lap Splice/Socket Length in ft. This is the length of a section which overlaps the top of the section below. The input is enabled, only if a user selects the Input method as Taper Factor or Detailed. For any of the mapped input methods this input is inactive, and the software will use the required splice length as calculated per code. The lap splice/socket length weight will be considered in the overall analysis and design calculations
Section Type	Provide the section type from the options 8,12,16,18, Round, Database. "Database" will only be available when the input method is set to "Detailed". This option will allow users to double click on the Section Profile box to open the Section Profile Catalog where they can assign a profile and material grade. For all other section types, the Section Profile box will be inactive, and the Top Diameter, Bottom Diameter, Thickness, and Material Grade will be required.
Section Profile	This option is non-editable for sections with 8,12,16 and 18-sided polygonal pole types and is editable for both stepped and hybrid pole structures with database section type. For hybrid monopole, the user can select the section profile, by double-clicking on the first section cell, which will open the Section profile selection dialog box.
Taper Factor	The taper Factor will be used differently for each input method.
Top /Bottom Diameter (in)	Provide the Top and Bottom diameter. Depending upon the input method selection, these fields are non-editable.
Thickness(in)	Provide the thickness of the section
Material	Select the material from the options.
Required Lap Splice (ft)	This is a non-Editable field displayed for reference only and is calculated based on the code requirements.
Inside Bend radius	<p>Default value is auto and is equal to the Bend radius factor (defined in tower settings) x by the thickness of the section.</p> <p>Note: After changing the bend radius factor in tower settings, it's recommended to click save in the pole overview to update the geometry.</p>

Guy Details

The Guy Details Tab gets displayed when user selects "Guyed" as "Yes" in the Tower summary tab. The guy Details tab uses a unique method of specifying guy anchor points and guy attachment points before mapping the guy wire between them. There are two tables, the anchor group table which shows each anchor group and all their corresponding anchors, and the

attachment table which gives a summary of the attachment details for an elevation and shows which anchor group the guys have been mapped to. There are no inputs on these tables. You can edit these data using the Anchor Group Tool and the Quick Guy Tool which will provide graphical aids to help you place guys correctly.

Main Model

Section Detail

Guy Details

Anchor group details

	Anchor Group	Anchor ID	Anchor Radius (ft)	Elevation (ft)
	Outer	A	160	0
		B	160	0
		C	160	0

<

>

Attachment details

	Attachment Elevation (ft)	Anchor Group	Attachment Type	TA Spread (ft)	Number of Guys	Guy Type
	200	Outer	Pull-offs	0	3	EHS
	160	Outer	Pull-offs	0	3	EHS
	120	Outer	Pull-offs	0	3	EHS
	80	Outer	Pull-offs	0	3	EHS
	40	Outer	Pull-offs	0	3	EHS

Guy Details Tab

Anchor Group Details

The anchor table is a simple summary of each anchor group and its individual anchors. There are only three properties associated with anchors, those are Radius, Azimuth, and Elevation.

On double-clicking on the Anchor group table, the user can edit the data. A new window titled Anchor Group Tool will appear as shown in the image below.

Anchor Group Tool

Group Name: Outer

Number of Anchors: 3

☐ All Anchors Identical ☐ Symmetrical Arrangement

	Anchor	Radius (ft)	Elevation (ft)
▶	Outer-A	160	0
	Outer-B	160	0
	Outer-C	160	0

Cancel Apply OK

Anchor Group Tool

Anchor Group Tool

The anchor group tool allows you to create or edit one group of anchors at a time. The graphic on the right shows a plan view of the tower and guy anchor locations. These are updated in real-time as you enter specifics of the guy group.

Parameter	Description
Group Name	You can enter any name for the group when you are adding groups, else it will show the selected group.
Number of Anchors	The number of anchors in a group. The default is 3.
Anchor Table	There will be one row in this table for each anchor. The anchor names will be automatically generated based on the group name. Anchor radius, elevation, and azimuth can be edited here.
All Anchors Identical (Checkbox)	When checked, you only need to enter Radius and Elevation of the first anchor.
Symmetrical Arrangement (Checkbox)	When checked, you only need to enter an azimuth for the first anchor. All other anchors will be evenly distributed based on the number of anchors.

Attachment Details

The guy attachment table has a summary of each attachment elevation, how the guys are attached, and what anchor group they are connected to. These properties can be edited, one level at a time, using the Quick Guy Tool, shown in Fig. 29. On double-clicking on the cell, the quick guy tool window will appear for the user to edit the properties.

Quick Guy Tool

Attachment Elevation: 173.0443 ft Type: Channel

Top Mount Elevation: 173.0443 ft Bottom Mount Elevation: 173.0443 ft

Spread: 7 ft

☒ Torque Arm Members Identical ☐ Use default

Members Connections Design Parameters

Face	Horizontal	Top Strap	RedundantDiagonal1	RedundantDiagonal2	RedundantHorizontal
A	C15X33.9	None	None	None	None
B	C15X33.9	None	None	None	None
C	C15X33.9	None	None	None	None

Anchor Group: Outer Create New Anchor Group


☐ All Guys Identical

Attachment Point	Anchor	Guy	I.T.	E.F.E.
2	Outer-A	3/4"EHS	10	100
4	Outer-C	3/4"EHS	10	100
6	Outer-C	3/4"EHS	10	100
7	Outer-R	1/2"EHS	10	100

Cancel Apply OK

Quick Guy Tool

The guy tool allows you to define attachment properties such as elevation and torque-arm or pull-off style. You will then be able to assign specific guy wires between connection points at this elevation and guy anchors. The upper graphic displays a small section of the tower at the given attachment elevation. The lower graphic shows a plan view of the current elevation with attachment points labeled. Both the graphics will show the torque-arm, pull-off, and guys as they are added. The connection and the design parameters will be addressed in the Quick Guy tool as shown in Fig. 29.



Design Parameter and Connection Tab in Quick Guy Tool

Parameter

Description

**Attachment Elevation
Type**

You can enter any elevation below the top of the tower.

It lists all the types of guy attachments in the guy attachment catalog. The catalog includes pull-offs as well as channel, bat ear, dog ear, and wing style torque-arms.

**Top/Bottom Mount
Elevation**

This input is dependent on the attachment type.

Spread

The distance from one attachment point to another attachment point.

**Torque-Arm Member
Table**

You can specify specific torque arm members here. The number of rows on the table will be either three or four depending on the number of faces of the tower. The default

Torque Arm Members Identical (Checkbox)

Anchor Group

Guy Table

All Guys Identical (Checkbox)


columns will be Top Strap, Bottom Strap, and Horizontal. Many additional columns will be added for various torque arm types

When checked, you will only need to input member types for face A.

This is a dropdown box that lists all the anchor groups that you have already defined. There is also an option for “Varies” which will allow you to assign guys to anchors in any group. In case you did not define anchor groups before getting to this screen you can click the “create new anchor group” option to be taken to the Anchor Tool before continuing.

You can map guy wires between attachment points on the current level and anchors in the selected group. There are six possible attachments points for both torque-arms and pull-offs. The attachment points follow a standard numbering pattern, starting with point 1 on leg A and continuing around clockwise. You will be able to delete and add guys as needed. If the arrangement is atypical and the program can’t make a reasonable guess at the guy locations, there will be a warning to let you know to map all the guy wires. You can double-click on a cell in the Guy column to open the Guy Wire Catalog and assign the correct profile as shown in the image given below (Fig. 31).

When checked, you will only have to enter guy type, initial tension (I.T), and end fitting efficiency (E.F.E) in the first row.





Guy Wire Catalog

Modifications

Modification is a unique concept. It enables you to create a series of modifications to replicate the history of tower modifications. The file eventually becomes a living history of the tower. Modifications are geometric layers which can be applied on top of the base geometry (layer) or on top of another modification.

Modifications can be defined as section substructures. A complete panel or some components of a panel can be replaced by a modification layer. You can define hierarchical orders for those layers.

To create a new modification layer, right-click on “Modifications” and click on “Create Modifications”. It will open a new window for panel modification.



Model Modification


Parameter	Description
Name	Alphanumeric Name of the layer
Existing Mod(s)	Select one or more existing mods to copy from.
Copy	Create a layer by copying data from selected existing mods
Details	Description and other details of the current mod layer
Add New Section	Add a new section starting from the top
Remove Section	Remove currently selected section
Show Base Model	Shows the original section before modification
Create	Create a new modification layer
Edit	Edit the current modification layer.

The rest of the controls are like “Section Editor”, ‘Bracing Connections”, “Leg Connections” and “Design Parameters” pages as described earlier.

The modification hierarchy helps the user to prioritize the different modifications created, depending upon the specification and the requirement. You can set the priority of the




modifications with the help of the up and down arrows while creating or updating a scenario. As shown in Fig.33. The modification priority is only applicable to the same panel with different modifications. For example, let’s first create a modification layer called Mod1 to change the bracing pattern from X Brace to Diagonal Up, and then create another modification layer called Mod2 to change the bracing pattern from X Brace to Z Brace. Both the modifications are on Panel1. Now, while creating a new scenario assign higher priority to Mod2. After activating the scenario, panel 1 will have Z Brace bracing.



Modification Hierarchy

Highlighting Member

If a user changes any member using model modification UI, and apply the changes, not only the change gets reflected in the Main model graphics, the modified member gets highlighted too. To view the change, you must activate the scenario. The change is also highlighted in the Section Editor dialog box, with a different color as shown in Fig.34.




Highlighted Member

If you do not want to use highlighting the member, simply right click on the Main model page, and select Unhighlight Modified member from the pop-up menu.

5 Work Order

A work order is a project-based approach to mimic tower engineers' daily workflow. Project data or loading data are separated from the geometry layer.


A tower model can have only one Work Order. While creating a new file, the program automatically creates a navigation tree for the "Work Order" user interface, and you must configure it with appropriate data. From the Tower Model Explorer on the left panel, when you right-click on **Work Order**, a pop up appears as shown in Fig.35. On clicking, the Work Order Configuration dialog opens as shown in Fig. 36.



Configure Work Order

Configure Work Order

With the **Work Order** Tab user can add or modify work order. You must give a **Name** to the Work Order. **The description** is optional.



Work Order

User Settings

The screenshot shows a window titled 'Work Order Configuration' with a sub-header 'New Work Order'. Below the sub-header are three tabs: 'Work Order', 'User Settings' (which is selected), and 'Project Data'. The 'User Settings' tab contains a form with the following fields: Engineer Name, Checker Name, Approver Name, Approver Designation, Company Name, Street Address, City, State, Postal Code, County, Phone, Fax, and Company Logo. Each field is represented by a text input box.

User Settings Tab

To set the company information for a tower model, you can give the information as shown above in Fig.37.

Project Data

To store the data related to the project, you may want to save information in the tab Project data as shown in Fig.38.

The screenshot shows the same 'Work Order Configuration' window, but with the 'Project Data' tab selected. The form is organized into sections, each with a blue upward arrow icon: 'Carrier' (SiteNumber, Site Name, AnalysisType, CarrierName), 'Customer' (SiteID, Job Number, Site Name, Address, City, State, Zip, Project ID, Application ID, Application Revision ID, Customer Name), 'Misc' (Subject), and 'SiteData' (Street Address, City, State, Zip, County, Jurisdiction, Latitude, Longitude). Each field is represented by a text input box.

Project Data


Once **Apply** is clicked, the program will configure or update the work order. **Cancel** will undo all the recent changes made in the work order configuration page. To close it with saving, click the **OK** button.

6 Loading Definition


Towers are most vulnerable to lateral loads, such as wind and earthquake loads. Wind loading is generally measured in terms of speed and can be affected by temperature (application considers the default temperature drop of 50 degree Celsius for guyed tower cable members) and the angle at which it is blowing as well as the surrounding terrain of the tower. This section describes the different parameters that can be changed related to the load application onto the tower due to wind.

Wind Definition

To create a wind definition, right-click on the Wind Definition leaf, under Loading definition. Click on **Create New Wind Definition** as shown in Fig.39.



Create Wind Definition




Wind Definition User Interface

There are five tabs within the Wind Definition user interface: Building Code, Wind Parameters, Adjustment Factors, Load Combination Parameters, and Existing Structure. Although you have the option to edit any tab at any time, the recommended workflow is to start from the leftmost tab and continue to the right. Within the tabs, there are several cells that are initially left blank. Input valid data into each cell. Whenever you click 'Next', the program runs an internal validation on the provided input. If you have failed to enter any valid information, the program issues a warning message that lists all the cells that are either invalid or have no data. Within the navigation tree, each tower model can have multiple wind definitions. This feature is to enable users to run past analyses with different wind profiles and different codes.

Building code

The first tab of the Wind Definition, shown in Fig. 40(above).



Jurisdiction

Select the standard to be considered for wind load generation and member design calculations. You can create as many wind definitions as needed.

Name	The unique name associated with the wind definition.
Standard	<p>This cell shows the applicable TIA standard. You can select a code from one of the following options.</p> <ol style="list-style-type: none"> 1. TIA-222-F 2. TIA-222-G 3. TIA-222- G (ASCE 7-10 Wind Maps) 4. TIA-222- H (ASCE 7-16)
Jurisdiction Notes	You can input any note specific to a regulatory body, like wind exceptions, references etc.
Additional Notes	This section is used to input any additional notes

Wind Parameters

Wind Speed Requirements - Depending on the code selected in the 'Building Code' Tab, inputs for the wind speed and ice requirement fields will appear, as shown in the pictures given below.

The screenshot shows the 'Wind Definition' software window with the 'Wind Parameters' tab selected. The interface includes fields for State (Alaska), County (Aleutians East), City, Latitude, and Longitude. The 'Wind Speed Requirements' section shows 'TIA-222-F Wind Speed' with a value of 110 mph and 'Service Wind Speed' with a value of 50 mph. The 'Base Elevation' is set to 0 ft. The 'Ice Requirement' section shows 'Ice Wind Speed' with values of 56.7 mph for Min, Max, and Design, and 'Ice Thickness' with values of 0.25 in for Min, Max, and Design. The 'Ice Density' is set to 56 pcf. The 'Escalated Ice Thickness' checkbox is unchecked. The 'Wind Directions' section shows a table with columns for Wind Direction, Wind Direction with true North, and Consider Analysis. The table lists wind directions from 0 to 300 degrees, all of which are checked for analysis.

Wind Direction	Wind Direction with true North	Consider Analysis
0	0	<input checked="" type="checkbox"/>
30	30	<input checked="" type="checkbox"/>
60	60	<input checked="" type="checkbox"/>
90	90	<input checked="" type="checkbox"/>
120	120	<input checked="" type="checkbox"/>
150	150	<input checked="" type="checkbox"/>
180	180	<input checked="" type="checkbox"/>
210	210	<input checked="" type="checkbox"/>
240	240	<input checked="" type="checkbox"/>
270	270	<input checked="" type="checkbox"/>
300	300	<input checked="" type="checkbox"/>

Wind Parameters page for TIA-222-F Building Code

Wind Definition

Building Code | Wind Parameters | Adjustment Factors | Load Combination Params | Existing Structure

State: Alaska County: Aleutians East City: Latitude: Longitude:

Wind Speed Requirements

TIA-222-G Wind Speed

Min (mph): 130

Max (mph): 130

Design (mph): 130

Service Wind Speed

Wind Speed (mph): 60

Site Parameters

☒ All Wind Directions Identical

Structure Class: II

Exposure Category: C

Topographic Category: 1

Ice Requirement

Ice Wind Speed

Min (mph): 70

Max (mph): 70

Design (mph): 70

☒ Consider Ice Load

Ice Thickness

Min (in): 0.25

Max (in): 0.25

Design (in): 0.25

Ice Density (pcf): 56

Base Elevation

Base Elevation (ft.): 0

Wind Directions

Select / Unselect All

Wind Direction	Wind Direction with true North	Consider Analysis
0	0	<input checked="" type="checkbox"/>
30	30	<input checked="" type="checkbox"/>
60	60	<input checked="" type="checkbox"/>
90	90	<input checked="" type="checkbox"/>
120	120	<input checked="" type="checkbox"/>
150	150	<input checked="" type="checkbox"/>
180	180	<input checked="" type="checkbox"/>
210	210	<input checked="" type="checkbox"/>
240	240	<input checked="" type="checkbox"/>
270	270	<input checked="" type="checkbox"/>
300	300	<input checked="" type="checkbox"/>
330	330	<input checked="" type="checkbox"/>

<< Back Next >>

Reset Save Cancel

Wind Parameters page for TIA-222-G Building Code

Wind Definition

Building Code | Wind Parameters | Adjustment Factors | Load Combination Params | Existing Structure

State: Alaska County: Aleutians East City: Latitude: Longitude:

Wind Speed Requirements

ASCE 7 Wind Speed

Wind Load Factors

☐ ASCE 7-10

☒ TIA-222-G (ASCE 7-05)

Ultimate (mph):

Nominal (mph): 0

Service Wind Speed

Wind Speed (mph): 60

Site Parameters

☒ All Wind Directions Identical

Structure Class: II

Exposure Category: C

Topographic Category: 1

Ice Requirement

Ice Wind Speed

Min (mph): 70

Max (mph): 70

Design (mph): 70

☒ Consider Ice Load

Ice Thickness

Min (in): 0.25

Max (in): 0.25

Design (in): 0.25

Ice Density (pcf): 56

Base Elevation

Base Elevation (ft.): 0

Wind Directions

Select / Unselect All

Wind Direction	Wind Direction with true North	Consider Analysis
0	0	<input checked="" type="checkbox"/>
30	30	<input checked="" type="checkbox"/>
60	60	<input checked="" type="checkbox"/>
90	90	<input checked="" type="checkbox"/>
120	120	<input checked="" type="checkbox"/>
150	150	<input checked="" type="checkbox"/>
180	180	<input checked="" type="checkbox"/>
210	210	<input checked="" type="checkbox"/>
240	240	<input checked="" type="checkbox"/>
270	270	<input checked="" type="checkbox"/>
300	300	<input checked="" type="checkbox"/>
330	330	<input checked="" type="checkbox"/>

<< Back Next >>

Reset Save Cancel

Wind Parameters page for TIA-222-G (ASCE 7-10 Wind Maps) Building Code

Wind Parameters page for TIA-222-H (ASCE 7-16) Building Code

Parameter

Description

State

The state where the tower is located. Both TIA-222-F and TIA-222-G have databases for every state in the USA.

County

The county where the tower is located. Both TIA-222-F and TIA-222-G have databases for every county in the USA. These lists include county-specific wind speeds, ice thicknesses, etc.

City

The city where the tower is located.

Latitude

The application automatically converts the latitude to a decimal format (instead of degrees, minutes and seconds).

Longitude

The application automatically converts the longitude to a decimal format (instead of degrees, minutes, and seconds).

Wind Speed Requirement

Depending on which code was selected in the 'Building Code' Tab, inputs for the wind speed and ice requirement fields will change.

Parameter

Description

TIA-222-F Wind Speed (mph)

This cell is initially auto-populated with the county's fastest mile wind speed (without ice considerations) as specified by the TIA-222-F code. It is based on the county where the tower is located. Unlike TIA-222-G, TIA-222-F only specifies one value for the design wind speed for each county. This cell is also active, so you can

Service Wind Speed (mph)	change the wind speed. The value entered in this cell is what the application uses for the wind load generation.
TIA-222-G Wind Speed: Min (mph)	This is auto populated based on the code selected in the Building Code tab. It is 50 mph for TIA-222-F and 60 mph for TIA-222-G, and TIA-222-H, respectively.
TIA-222-G Wind Speed: Max (mph)	This cell is auto-populated with the minimum county 3-second gust wind speed (without ice considerations) specified by the TIA-222-G code. This cell cannot be edited. This cell is for reference only and will not be used in the analysis.
TIA-222-G Wind Speed: Design (mph)	The same rules apply to this cell as to the previous cell. The only difference is that this wind speed is the <i>maximum</i> allowable wind speed for the county.
Wind Load Factors	This is an active cell for you to manually input a special design wind speed. The value entered in this cell is what the application uses for the wind load generation. Default value is based on the maximum wind speed and can be edited as per the requirement.
Ultimate (mph)	This option is visible only if the selected standard in the building code is "TIA-222-G (ASCE 7-10 Wind Map)". You must choose to either use ASCE 7-10 load factors or TIA-222-G (ASCE 7-05) load factors. When the ASCE 7-10 load factors are selected, the application hides the nominal wind speed box. In this case, the ultimate wind speed used for the wind load generation. When the ASCE 7-05 wind speeds are selected, the nominal wind speed box reappears. The application automatically calculates the nominal wind speed based on your input for ultimate wind speed. The nominal wind speed cell is inactive, but this the wind speed use for wind load generation.
Nominal (mph)	This is an ultimate wind speed (without ice considerations) that you must specify.
	This is a nominal wind speed (without ice considerations) that the application calculates based on your input for ultimate wind speed. This cell is inactive.

Ice Requirement

Ice Wind Speed: Min (mph)	This cell cannot be edited. This cell is for reference only and will not be used in the wind load generation.
----------------------------------	---

Ice Wind Speed: Max (mph)	The same rules apply to this cell as to the previous cell. The only difference is that this wind speed is the <i>maximum</i> allowed wind speed for the county.
Ice Wind Speed: Design (mph)	This is an active cell for you to manually input a special design ice wind speed. The value entered in this cell is what the application uses for the wind load generation
Consider Ice Load	To consider Ice Load this checkbox should be checked.
Ice Thickness: Min (in)	It shows the minimum ice thickness. You cannot edit this cell. Since it is for reference purposes only, the cell is always grayed out.
Ice Thickness: Max (in)	It shows the maximum ice thickness. You cannot edit this cell. Since it is for reference purposes only, the cell is always grayed out.
Ice Density (pcf)	This is auto generated and cannot be edited. The value is 56 pcf.
Escalated Ice Thickness	This box is only visible for TIA-222-F analysis. The default is to escalate ice, but you have the option to uncheck this cell.
Design	Provide the ice thickness in inch which is used for wind load generation.

Site Parameters

The Site Parameters section is invisible for the TIA-222-F standard. The first checkbox within the Site Parameters section is called “All wind directions identical”. This option is active for topographic category 5 (RSM) and 5 (RSM CC) and is inactive and checked for topographic category 1-4. When checked, you only input the critical wind direction parameters, and the Wind Directions table will only consist of the first three columns. The other columns will be invisible.

In case of “All wind directions identical” unchecked, all the site parameters except the structure class and other SEAW RSM -03 parameters are exposed in the wind direction table.

Parameter	Description
All Wind Directions Identical	When this option is unchecked, you can apply varying exposure and topo categories for different wind directions. Active only for topographic Category 5.
Structure Class	This includes a dropdown list with the options I, II, or III. The default is II, but you have the option to change this.
Exposure Category	This includes a dropdown list with options B, C, or D. The default is C, but you have the option to change this.


Topographic Category

This includes a dropdown list with options 1, 2, 3, 4, 5 (RSM), or 5 (RSM CC).

Crest Height (ft)

This is input that is initially left blank. When topographic category 1 is chosen, the site has no additional topographic effects to consider, and the Crest Height box is not displayed. A value is necessary here for topographic categories 2-4. For topographic category 5 (RSM), this cell is active. For topographic category 5 (RSM CC), this cell is inactive, and the application calculates the crest height based on inputs in the SEAW RSM-03 section (see below).


SEAW RSM-03



SEAW RSM - 03 Parameters

Topographic Feature	Hill
Structure Distance from Crest Line (x) (ft.)	
Crest to Mid-Height Distance (L/2) (ft. AMSL)	
Slope distance L (ft.)	

SEAW Parameters when Topographic category 5 (RSM) is selected



SEAW RSMCC - 03 Parameters

Topographic Feature	Hill
Crest Point Elevation (ft. AMSL)	1000
Base Point Elevation (ft. AMSL)	100
Mid-Height Elevation (ft. AMSL)	550
Crest to Mid-Height Distance (L/2)(ft. AMSL)	400
Slope distance L (ft.)	800
Tower Point Elevation (ft. AMSL)	850
Structure Distance from Crest Line (x) (ft.)	133.33

SEAW Parameters when Topographic category 5 (RSM CC) is selected

Parameter

Description

Topographic Feature

It is a dropdown list with the options of hill, flat-topped hill, continuous ridge, flat-topped ridge, or continuous escarpment. Default value is "Hill". This row is visible in both the 5 (RSM) and the 5 (RSM CC) methods.

Crest Point Elevation (ft)

This is a user input that is initially left blank. It is the total elevation of the crest above mean sea level. This row is only visible for topographic category 5 (RSM CC).

Base Point Elevation (ft)	This input is initially left blank. It is the total elevation at the base of the topographic feature with respect to mean sea level. This row is only visible for topographic category 5 (RSM CC).
Mid-Height Elevation (ft)	This is the average of the crest point elevation and the base point elevation. It is automatically calculated by the application and is inactive. This row is only visible for topographic category 5 (RSM CC).
Crest to Mid-Height Distance (L/2) (ft)	This is the horizontal distance from the feature's crest to the mid-height point of the topographic feature. This is initially left blank. This row is visible in both the 5 (RSM) and the 5 (RSM CC) methods.
Slope Distance L (ft)	The program calculates the total slope distance (L) as twice the crest to mid-height horizontal distance. This cell is auto-populated and inactive for user-input. It is visible in both the 5 (RSM) and the 5 (RSM CC) methods.
Tower Point Elevation (ft)	This row is only visible for topographic category 5 (RSM CC). It is the tower's base elevation with respect to mean sea level. For hills and continuous ridges, this is a user-defined input and will initially be blank. For flat-topped ridges, flat-topped hills, and continuous escarpments, this cell will be automatically calculated by the application based on input for Structure Distance from Crest Line. The calculation assumes a constant slope for the feature and uses similar triangles to determine the tower point elevation.
Structure Distance from Crest Line (x) (ft)	This row is visible in both the 5 (RSM) and the 5 (RSM CC) methods. It is the horizontal distance from the crest to the tower.

Wind Directions

When the "All wind directions identical" checkbox is selected, the table within the Wind Directions section will have the wind direction information and checkbox option for user to select the directions to be considered for the analysis. For "All wind directions identical" unchecked, more information is available for the user to define including the consider analysis option.

Wind Definition

Building Code | Wind Parameters | Adjustment Factors | Load Combination Params

State: Alaska County: Aleutians East City: Latitude: Longitude:

Wind Speed Requirements

ASCE 7 Wind Speed

Wind Load Factors

☐ ASCE 7-10

☒ TIA-222-G (ASCE 7-05)

Ultimate (mph):

Nominal (mph): 0

Service Wind Speed

Wind Speed (mph): 60

Site Parameters

☒ All Wind Directions Identical

Structure Class: II

Exposure Category: C

Topographic Category: 2

Crest Height (ft):

Ice Requirement

Ice Wind Speed

Min (mph): 70

Max (mph): 70

Design (mph): 70

☒ Consider Ice Load

Ice Thickness

Min (in): 0.25

Max (in): 0.25

Design (in): 0.25

Ice Density (pcf): 56

Base Elevation

Base Elevation (ft.): 0

Wind Directions

Select / Unselect All

Wind Direction	Wind Direction with true North	Consider Analysis
0	0	<input checked="" type="checkbox"/>
30	30	<input checked="" type="checkbox"/>
60	60	<input checked="" type="checkbox"/>
90	90	<input checked="" type="checkbox"/>
120	120	<input checked="" type="checkbox"/>
150	150	<input checked="" type="checkbox"/>
180	180	<input checked="" type="checkbox"/>
210	210	<input checked="" type="checkbox"/>
240	240	<input checked="" type="checkbox"/>
270	270	<input checked="" type="checkbox"/>
300	300	<input checked="" type="checkbox"/>
330	330	<input checked="" type="checkbox"/>

<< Back Next >>

Reset Save Cancel

Wind Definition Dialog - wind directions identical unchecked.

Wind Definition

Building Code | Wind Parameters | Adjustment Factors | Load Combination Params | Existing Structure

State: Alaska County: Aleutians East City: Latitude: Longitude:

Wind Speed Requirements

TIA-222-G Wind Speed

Min (mph): 130

Max (mph): 130

Design (mph): 130

Service Wind Speed

Wind Speed (mph): 60

Site Parameters

☒ All Wind Directions Identical

Structure Class: II

Exposure Category: C

Topographic Category: 5 (RSM)

Crest Height (ft):

Ice Requirement

Ice Wind Speed

Min (mph): 70

Max (mph): 70

Design (mph): 70

☒ Consider Ice Load

Ice Thickness

Min (in): 0.25

Max (in): 0.25

Design (in): 0.25

Ice Density (pcf): 56

Base Elevation

Base Elevation (ft.): 0

Wind Directions

Select / Unselect All

Wind Direction	Wind Direction with true North	Consider Analysis
0	0	<input checked="" type="checkbox"/>
30	30	<input checked="" type="checkbox"/>
60	60	<input checked="" type="checkbox"/>
90	90	<input checked="" type="checkbox"/>
120	120	<input checked="" type="checkbox"/>
150	150	<input checked="" type="checkbox"/>
180	180	<input checked="" type="checkbox"/>
210	210	<input checked="" type="checkbox"/>
240	240	<input checked="" type="checkbox"/>
270	270	<input checked="" type="checkbox"/>
300	300	<input checked="" type="checkbox"/>
330	330	<input checked="" type="checkbox"/>

SEAW RSM - 03 Parameters

Topographic Feature: Hill

Structure Distance from Crest Line (x) (ft.):

Crest to Mid-Height Distance (L/2) (ft. AMSL):

Slope distance L (ft.):

☒ DownWind

<< Back Next >>

Cancel Apply OK

Wind Definition Dialog - wind directions identical checked.

Base Elevation

This specifies the tower’s base elevation with respect to the ground level. A large base elevation will increase the wind pressures on the tower. The default value is at zero feet as shown in Fig.48.

When you select the TIA-222-H code, the base elevation shows two new inputs, Ground Elevation Factor and Rooftop checkbox as shown below.

Base Elevation

Base Elevation (ft.) 0

Ground EL above Sea Level (ft.)

☐ Rooftop

Ground EL. Above Sea level

Rooftop

The input for the average ground elevation above sea level is required to calculate the Ground Elevation Factor.

To consider increased wind pressure due to the rooftop wind speedup factor, this checkbox should be checked. If this Rooftop checkbox is checked, the wind parameters UI expands, as shown in the fig. 48.

Wind Definition

Building Code | Wind Parameters | Adjustment Factors | Load Combination Params | Existing Structure

Wind Speed Requirements

ASCE 7-16 Wind Speed

Ultimate (mph) 130

Service Wind Speed

Wind Speed (mph) 60

Site Parameters

☒ All Wind Directions Identical

Risk Category II

Exposure Category C

Topographic Category 1

Ice Requirement

Ice Wind Speed

Design (mph) 70

☒ Consider Ice Load

Ice Thickness

Design (in) 0.25

Ice Density (pcf) 56

Base Elevation

Base Elevation (ft.) 0

Ground EL above Sea Level (ft.)

☒ Rooftop

Wind Directions

Select / Unselect All

Wind Direction	Wind Direction with true North	Consider Analysis
0	0	<input checked="" type="checkbox"/>
30	30	<input checked="" type="checkbox"/>
60	60	<input checked="" type="checkbox"/>
90	90	<input checked="" type="checkbox"/>
120	120	<input checked="" type="checkbox"/>
150	150	<input checked="" type="checkbox"/>
180	180	<input checked="" type="checkbox"/>
210	210	<input checked="" type="checkbox"/>
240	240	<input checked="" type="checkbox"/>
270	270	<input checked="" type="checkbox"/>
300	300	<input checked="" type="checkbox"/>
330	330	<input checked="" type="checkbox"/>

Rooftop


Rooftop Parameters

Parapet Height (ft.)

Minimum Distance to Edge of Building (ft.)

Maximum Width of Building (ft.)

Maximum Height of Building (ft.)



<< Back | Next >>

Cancel | Apply | OK

Rooftop Parameters

If you check the rooftop option, the four inputs that must be input by the user are Parapet Height, Minimum Distance to Edge of Building, Maximum Width of Building and Maximum Height of Building.

Adjustment Factors

The third tab of the Wind Definition user interface is called the Adjustment Factors (Fig.48).

Section ID	Section Top Elevation(ft)	Face Af (Flat)	Face Ar (Round)	Ar Ice (Round)	Weight Multiplier	WindPressureMultiplier
1	150	1	1	1	1	1
2	140	1	1	1	1	1
3	120	1	1	1	1	1
4	100	1	1	1	1	1
5	80	1	1	1	1	1
6	60	1	1	1	1	1
7	40	1	1	1	1	1
8	20	1	1	1	1	1

Adjustment Factors

Parameter

Description

Section ID

The application auto-populates this data, you cannot edit this column.

Section Top Elevation (ft)

This is auto populated in a similar manner to the Section column described above. You cannot edit this column either.

Face Af (Flat)

The application calculates the flat area of the structural members "Af" for the wind load calculations. This Face Af factor acts as a multiplier to the Af of structural members. This multiplier can be edited for every panel section on the tower shown in Fig. 14.

Face Ar (Round)

The application calculates the round area of the structural members "Ar" for the wind load calculations. This Face Ar factor acts as a multiplier to the Ar of structural members. This would apply to the wind conditions where no ice is present.

Ar ice (Round)

This is an adjustment factor that is only applied to the total round tower wind area that the application calculates when ice conditions are considered.

Weight Multiplier

The weight multiplier is a user input that accounts for additional miscellaneous weight on the tower. This value is applied to the tower weight calculated by the application.

Wind Pressure Multiplier

This factor will be multiplied to the calculated wind pressure and will be applied to the structure and all the appurtenances.

Load Combination Parameters

As the name suggests, load combinations are the combinations (or grouping) of primary load cases used for the analysis and design of a tower. The cells represent the factors to be added with the primary load cases, depending upon the rules of the TIA Standards.

Each row in a table represents the ID for a different load combination.

- Index - The first column indicates the index of the load combination.
- toggle - Select the checkboxes of the combination which you want to use.
- Load Type columns - Primary Load cases are assigned a load type, each of which is represented by a separate column in the load combination tables. Enter the load combination factor for a given load type in the cell.

Tip: The cell with zero values appears in white color whereas nonzero values are shown as numbers.

Tip: Negative load factors may be used to reverse load direction.

Wind Definition

Building Code | Wind Parameters | Adjustment Factors | Load Combination Params

Load Combination Params

De Select All

	Is Valid	D	Dg	Di	E	Ti	Wo	Wi	Ws
	<input checked="" type="checkbox"/>	1.2	0	0	0	0	1.6	0	0
	<input checked="" type="checkbox"/>	1.2	0	1.0	0	0	0	1.0	0
	<input checked="" type="checkbox"/>	1.2	0	0	1.0	0	0	0	0
	<input checked="" type="checkbox"/>	0.9	0	0	0	0	1.6	0	0
	<input checked="" type="checkbox"/>	0.9	0	0	1.0	0	0	0	0
→	<input checked="" type="checkbox"/>	1.0	0	0	0	0	0	0	1.0

<< Back

Reset Save Cancel

Load Combination Parameter Tab

Parameter	Description
D	Dead Load of the structure and appurtenances.
Dg	Dead load of guys.
Di	Dead load of ice weight on the structure and appurtenances.
E	Earthquake load
Ti	Temperature load (for guy towers)
Wo	Wind without ice
Wi	Wind with ice
Ws	Wind with service

Existing Structure

The existing Structures tab allows you to consider an appropriate reduction to the wind load and allows you to change the passing rating. You can also select the option “Divide Demand-Capacity Ratios by 1.05” to see the changes in the reporting. The load modification group is available for TIA 222 H code only.

Wind Definition

Building Code | Wind Parameters | Adjustment Factors | Load Combination Params | Existing Structure

Existing Structure

Report Ratings

Passing Rating: 100 %

☒ Divide Demand-Capacity ratios by 1.05

Load Modifications

☒ Consider Load Modification Factors

Risk Category	Existing Structure Load Modification Factors, Kes		
	Wind Load	Design Ice Thickness	Seismic Loads Effect
I	1.0	N/A	N/A
II	0.95	0.85	1.0
III	1.0	1.0	1.0
IV	1.0	1.0	1.0

<< Back

Reset Save Cancel

Existing Structure Tab

Seismic Definition

OpenTower can perform seismic analysis by automatically generating seismic load cases and then performing advanced Eigen solution during analysis. This section describes the different parameters that are required and can be edited for the generation of seismic loadings.

Create a Seismic Definition

To create a Seismic definition, right-click on the Seismic Definition leaf, under Loading definition. Click on **Create New Seismic Definition** as shown in Fig.52. Seismic definition Page has three tabs, building code, standards, and seismic parameters.

Building Code

In this tab you must select the building code from the combo box, the options are ASCE 7-10 and TIA-222-H. Depending upon the selection of the code, the fields in the next tab will be updated.

Standards

The general information is provided under the standard tab.


Parameter	Description
Method	The selected method for load generation. The default option is the Equivalent Lateral Force Procedure. If you have selected TIA-222-H code in the Building Code tab, another option gets added, i.e. TIA-222-H Lateral Force Procedure. You can choose from these two options.
Name	The unique name associated with the seismic definition.
State	The state where the tower is located.
Country	The country where the tower is located.
City	The city where the tower is located.
Latitude	The application automatically converts the latitude to a decimal format (instead of degrees, minutes, and seconds). This is used to determine the site seismology parameters.
Longitude	The application automatically converts the longitude to a decimal format (instead of degrees, minutes, and seconds). This is used to determine the site seismology parameters.
Jurisdiction	This is used for output and for documentation purposes only.

Seismic Parameters

Structure category information is provided in the seismic Parameters tab.



Parameter	Description
Risk Category	It determines the Importance Factor. You must select from the options given from One to Five.
Importance Factor	This is auto-populated as per the input provided for Risk Category.
Response Modification Factor	You must provide the response modification factor.
Site Class	It is to define the site soil type. You must choose from the options provided under the dropdown as shown in Fig. 53. Available options are dependent on the selected building code. For TIA-222-H, an additional option is added, which is Stiff Soil (Determined).
SS	This is spectral response acceleration for the shorter period. You can click to "Fetch Ss, S1 and TL from" and the data will be auto-populated based on the "Latitude" and "Longitude" from the USGS website or can input manually.
S1	This is spectral response acceleration for a 1-sec period. You can click to "Fetch Ss, S1 and TL from" and the data will be auto-populated based on the "Latitude" and "Longitude" from the USGS website or can input manually.
TL	This is the long period transition in seconds. You can click to "Fetch Ss, S1 and TL from" and the data will be auto-populated based on the "Latitude" and "Longitude" from the USGS website or can input manually.
Fundamental Period Method	This input is specific to the TIA-222-H code. Users must choose from one of the two available options, Rayleigh Method and user specified method.
Amplification Factor (As)	The amplification factor input is specific to the TIA-222-H code. The default value is 1.

Once the Load Definition is defined and saved, the load definition will be added in the tower model explorer under the seismic definition category as shown below.



seismic definition creation

If you double-click on the definition, the load definition dialog box will open for editing.



Add the inputs for the Standard tab

The image displays two side-by-side screenshots of the 'Seismic Definition' dialog box, specifically the 'Seismic Parameters' tab. The left window represents the TIA-222-H seismic code, and the right window represents the ASCE 7-10 seismic code.

Left Window (TIA-222-H):

- Risk Category:** II
- Importance Factor:** 1
- Response Modification Factor:** 3.0
- Site Class:** A - "Hard Rock" (selected from a list: A - "Hard Rock", B - "Rock", C - "Dense Soil / Soft Rock", D - "Stiff Soil" (Determined), E - "Soft Clay", F - "Soil Likely to Fail", D - "Stiff Soil" (Default))
- Fetch Ss, S1 and TL from:** (button)
- Ss:** (empty text field)
- S1:** (empty text field)
- TL (long-period transition period):** (empty text field)
- Fundamental Period Method:** ☒ Rayleigh Method, ☐ User specified
- Amplification factor (As):** 1.0

Right Window (ASCE 7-10):

- Risk Category:** I
- Importance Factor:** 1
- Response Modification Factor:** 3.0
- Site Class:** HardRock (selected from a list: HardRock, Rock, VeryDenseSoilSoftRock, StiffSoil, SoftClaySoil, SoilVulnerabletoFailure)
- Fetch Ss, S1 and TL from:** (button)
- Ss:** (empty text field)
- S1:** (empty text field)
- TL (long-period transition period):** (empty text field)


Both windows have 'Cancel', 'Apply', and 'OK' buttons at the bottom.

Seismic Definition Seismic Parameters Page(left side shows the TIA-222-H seismic code and the right side ASCE 7-10 seismic code)

The compatibility of the wind definition type and seismic definition type is checked while creating a scenario. (For e.g. A scenario can't be saved with wind definition of type TIA-222-G and Seismic definition Type of TIA-222-H)

7 Appurtenances


This section allows the user to create discrete and linear appurtenances on a tower to be used for analysis. Discrete and linear appurtenances have separate user interfaces as input and properties vastly differ. To create the appurtenances, users must add the appurtenance group by right-clicking on Appurtenances and clicking Add Group. as shown in Fig.54.




Appurtenances

Appurtenance Group

Multiple appurtenance groups can be defined to be used for multiple scenario analysis. You can create a new group from scratch or can copy data from an existing group. Once saved, the appurtenance group will be created and added under the "Appurtenances" group as shown in Fig. 55.



Appurtenance Group



Appurtenance Group Created

Discrete Appurtenance

The discrete appurtenance user interface consists of four tabs, Mount Level Summary, Level Details, Miscellaneous, and Output Summary as shown in the picture below. All these four pages are described in detail in the following sections.


Elevation (ft)	Mount Type	Manufacturer	Model	Quantity	Location	Carrier	Load Case Classification	Horizontal Offset (ft)	Mount Width (ft)	Stand off Distance (ft)	Mount Azimuth (Deg)	Face Rotation (Deg)	Ka
297	Framed Platform (3-sided)			1	FaceA/Centroid	A	Existing	0	14	0	0	0	1
270	Sector Mount			3	LegA	A	Existing	0	12.5	4	75	0	0.75
					LegB	A	Existing	0	12.5	4	75	0	0.75
					LegC	A	Existing	0	12.5	4	75	0	0.75
250	Sector Mount			3	LegA	A	Existing	0	10.5	4	-45	0	0.75
					LegB	A	Existing	0	10.5	4	-20	0	0.75
					LegC	A	Existing	0	10.5	4	-40	0	0.75
205	Pipe Mount			1	LegB	A	Existing	0	0	0.375	0	0	1
193	Pipe Mount			3	LegA	A	Existing	0	16	4	-35	0	0.75
					LegB	A	Existing	0	16	4	5	0	0.75
					LegC	A	Existing	0	16	4	-18	0	0.75
134	Pipe Mount			1	LegB	A	Existing	0	0	0.375	0	0	1
120	Pipe Mount			1	LegA	A	Existing	0	0	0.375	0	0	1
110	Pipe Mount			1	LegA	A	Existing	0	0	0.375	0	0	1

Discrete Appurtenance UI Mount Level Summary Tab

Mount Level Summary

This interface contains an overview of all the mount levels. It allows you to add, delete, and edit general mount level data. Copy and paste functions are available to quickly copy full lines or fields to other areas where applicable. Right-click functions such as Add New Mount, Delete New Mount, Copy Mount, and Paste Mount are also available. From the Mount Level Summary window, you can access the Level Details window for an in-depth view of each elevation and the loading associated with that elevation. Shown in Fig. 56(above).

Parameter	Description
Elevation	Provide the Elevation from the base of the tower to the centerline of the mount.
Mount Type	It is a dropdown list which contains all the Mount types with the options as shown in Fig.57
Manufacturer	Select the manufacturer name from the dropdown. All the manufactures from different databases are listed under this column.
Model	Once the mount manufacturer is selected, model names will be populated. You can select an appropriate model using the dropdown list.
Quantity	The default value of 1 will be added for each mount. Changing the quantity will adjust the number of rows that are displayed for that elevation.

Location	It is a dropdown list, where you can select from different tower legs or tower faces that mount will be attached to.
Carrier	Carrier information is populated based on appurtenance information in the Level Details window and for informational purposes only. This information cannot be altered from this window.
Load case Classification	<p>You can select the classification from one of the listed options as shown below.</p> 
Horizontal Offset (ft)	Provide the horizontal offset. The horizontal offset is the clear distance between the mount and the tower location (Leg/face) reference.
Mount Width (ft)	Overall width of a mount that the appurtenances are attached. It is normally auto-populated from the mount database. Pipe mounts, most stand offs, and “none” models will not populate a width per mount database.
Stand-Off Distance (ft)	The horizontal distance from the mount face relative to the leg or face on the tower that the mount is attached.
Mount Azimuth	It is the relative angle from the leg or face the mount attached.
Face Rotation (Degree)	Face rotation is applicable for T- Arms. The arm rotation is described as the angle at which the width of the mount is rotated, on which the mount pipes are attached. The default value is 0 degrees, which is perpendicular to the supporting mount members (mount azimuth).
Ka	Ka is the shielding factor applied to appurtenance effective projected areas to account for the shielding of the tower by discrete appurtenances. The default is set to Autocalc ON (auto-calculated mode) and the value of the Ka factor is auto calculated based on the selected standard. User can right click on the Ka cell to change to setting to Autocalc OFF to define any other value. This factor does not apply to TIA-222-F.


Mount Level Summary	Level Details	Miscellaneous	Output Summary
	Elevation (ft)	Mount Type	Manufacturer
	110		
		<div> Framed Platform (3-sided) Pipe Mount Platform (3-Sided) Sector Mount Standoff (2 arms) Star Mount T-Arm None </div>	

Mount Types

The **Add Mount** function inserts a new line at the bottom of the Mount Level Summary table. You fill out the information and based on what elevation is added, the table will be redrawn to position the row to its correct elevation order. This option is available by right-clicking on the table.

The **Delete Mount** will delete the row that is currently selected or multiple rows if multiple rows are highlighted. This option is also available by right-clicking on the table. Any appurtenances on the level details tab associated with this mount will also be deleted. A dialog box will warn that deleting the mount will delete associated appurtenances on the level details tab.

The **Copy Mount** will copy the existing selected row. This option is also available by right-clicking on the table. **Paste Mount** will paste the copied mount in the new row or existing row.



Right Click Operation

Once you add all the input, click **Apply mount**, to apply the changes, which will populate the required data in the Level Details Page.

Quick Editor

The discrete and miscellaneous loading quick editor is a quick and easy way to view the data in a single table and update the data in multiple cells with a drag and drop operation. To view the quick editor, you must press the Quick Editor button at the bottom left in the discrete appurtenance page as shown in Fig. 56.

Discrete and Miscellaneous Loading Quick Editor

Quick Editor- Discrete Loading Page

The Radio button, Discrete and Miscellaneous, as shown in Fig.59, switches between the Discrete Quick Editor and Miscellaneous Quick Editor. To copy the data from one cell to multiple cells in a single column, the user must drag the selected cell while pressing CTRL. The data will be updated in the subsequent cells automatically. To delete any data from a cell, select the cell and press Delete.

Fig.59 shows the Discrete Loading Quick editor, where the table comprises of the Mount level summary properties and Level Details Page properties.


For parameters like Ka, where the default value is auto, if a user updates it with a new value, the cell will automatically be turned into green color to show the updated cell as shown in the Fig.59. If you revert the change to auto, the cell will be unhighlighted.

Hide Mount Related Columns checkbox, gives you an option to hide/unhide the Mount related properties, that cannot be edited and shown as grayed cells.

	Elevation	Manufacturer	Model	Type	Classification	Pipe Mount Type	Pipe Mount Length	Location	Orientation	Horizontal Offset	Lateral Offset	Vertical Offset	Relative Azimuth	Ka	Ks Front	Ks Side
1																
2																
3																
4																
5																
6																
7																
8																
9																
10																

Quick Editor- Miscellaneous Loading Page

Fig.60 shows the Miscellaneous Loading Quick editor, where the table comprises of the Miscellaneous loading properties.

You can also filter the data of each column by clicking the filter icon , shown beside each column name.


The grey cells are non-editable. Once the user adds /updates the data in the tables, to apply the changes, a user must click Apply and OK button. The changes will be reflected in the Discrete Appurtenance UI.

Level Details

Level Details user interface allows you to add, delete, and edit data for all appurtenances on the tower. Copy and paste functions are available for quick copying of full lines or fields to other areas where applicable.

The **All Mounts Identical** option allows you to apply symmetric loading on an elevation.


Right-click functions pop up the image as shown below. It allows you to add, delete, copy, paste mount pipes and appurtenances. The **Add Appurtenance** and **Add Multiple Appurtenance** allows users to insert one row or multiple rows respectively; selecting multiple rows prompts a dialog box to input the number of rows to be added. The **Delete Appurtenance** deletes the current row that is selected or will delete multiple rows if multiple rows were selected. A dialog box will display to confirm your choice. **Copy Appurtenance** copies the selected row and **Paste Appurtenance** pastes it to the existing or new row.



Discrete Appurtenance													-	□	×
										(ft)	(ft)	Azimuth (Deg)	^		
FaceA (LP 1101-1)															
*	EMS WIRES	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	1	0.5	6	0	a.b	10		
*	EMS WIRES	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	1	0.5	2	0	a.b	10		
*	EMS WIRES	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	1	0.5	-2	0	a.b	10		
*	EMS WIRES	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	1	0.5	-6	0	a.b	10		
FaceB (LP 1101-1)															
*	EMS WIRES	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	1	0.5	6	0	a.b	10		
*	EMS WIRES	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	1	0.5	2	0	a.b	10		
*	EMS WIRES	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	1	0.5	-2	0	a.b	10		
*	EMS WIRES	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	1	0.5	-6	0	a.b	10		
FaceC (LP 1101-1)															
*	EMS WIRES	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	1	0.5	6	0	a.b	10		
*	EMS WIRES	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	1	0.5	2	0	a.b	10		
*	EMS WIRES	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	1	0.5	-2	0	a.b	10		
*	EMS WIRES	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	1	0.5	-6	0	a.b	10		
Note -															

Discrete Appurtenance Dialog Level Details Tab

Parameter	Description
Manufacturer	Select the manufacturer from the list of available manufacturers. All the manufactures from different catalogs are listed under this column.
Model	Once the manufacturer is selected, the corresponding model names will be populated. You can select an appropriate model name from the dropdown list.
Type	This field provides the information about the antenna type and is auto-populated from the database based on the manufacturer and model selected.
Carrier	The carrier for that appurtenances
Classification	You can select classifications for loading such as Existing, Proposed, Reserved, To Be Removed, Other, and Suppressed The application generate the loads and report the discrete appurtenances based on the selected classifications for the scenario.
Pipe Mount Type	The pipe mount type can be selected from the drown list. The selected pipe will be shown in the graphics and loads will be generated. Default option is "None".
Pipe Mount Length (ft)	The length of the mount pipe. It is adjustable and used by the program to calculate area and weight.
Pipe Mount Vertical Offset (ft)	It is an offset to the pipe mount vertically from the centerline of the mount. The default value is 0 ft and it can have both positive and negative values.
Horizontal Clear Distance (ft)	The horizontal offset for an appurtenance is relative clear distance between the face of the mount and the back of the antenna in case of pipe mount type "None". If pipe mount type is defined, then it's a clear distance between the face of the mount and the back of the mount pipe. The default horizontal offset is 0 ft.
Lateral Offset (ft)	The lateral offset of a pipe mount is the lateral distance, across the face of the mount, to the pipe mount from the center of the mount. The appurtenance's lateral offset is relative to the center of the mount face. The default value of lateral offset is 0 ft.



Vertical Offset (ft)	The vertical offset of an appurtenance is the vertical distance from the center elevation of the mount.
Orientation	<p>It represents the orientation of the appurtenance on the mount. The orientation options that can be chosen are: a,b; a,c; b,a; b,c; c,a; c,b. The first letter represents the height of the antenna and second letter represents the width of the antenna. The default orientation is a,b for all the appurtenances and is mostly used for mounting the correct orientation for tower mounted amplifiers or RRU's or diplexers etc. This can be explained with the below image.</p> <div data-bbox="584 531 1214 884" data-label="Image"> <p>Orientation Details</p> <ul style="list-style-type: none"> a,b - Height = a, Width = b, Depth = c a,c - Height = a, Width = c, Depth = b b,a - Height = b, Width = a, Depth = c b,c - Height = b, Width = c, Depth = a c,a - Height = c, Width = a, Depth = b c,b - Height = c, Width = b, Depth = a </div>
Relative Azimuth (Deg)	The azimuth for an appurtenance is relative to the perpendicular to the location (face or leg) of the mount that it is attached.
Absolute Azimuth (Deg)	The absolute azimuth of an appurtenance is relative to true north. This field cannot be edited and is auto-calculated based on the relative azimuth of appurtenance and the bearing of the tower.
Ka	Ka is the shielding factor applied to appurtenance effective projected areas to account for the shielding of the tower by discrete appurtenances. The default is set to Autocalc ON (non-edited mode) and the value of the Ka factor is auto calculated based on the selected standard. User can right click on the Ka cell to change to setting to Autocalc OFF to define any other value. This factor does not apply to TIA-222-F.
Ks Front	This is applied to the area of appurtenances to account for the shielding effects from one appurtenance to another from the front.
Ks Side	This is applied to the area of appurtenances to account for the shielding effects from one appurtenance to another from the side.
App No	The application number is for reference only and has no impact on the calculations for wind load generation and analysis.

Once you add all the input, click on the **Apply** button to apply the changes.

Miscellaneous

The Miscellaneous section of the Discrete Appurtenance user interface works the same way as the Level Details information. The miscellaneous information is not connected with the mounts in the mount level summary, but pipe mounts can be defined if necessary. The miscellaneous appurtenance can be defined at various locations such as Legs, Faces and/or centroid. The centroid location will distribute the loads to all the legs of the tower.

The screenshot shows the 'Discrete Appurtenance' dialog box with the 'Miscellaneous' tab selected. The dialog has four tabs: 'Mount Level Summary', 'Level Details', 'Miscellaneous', and 'Output Summary'. The 'Miscellaneous' tab contains a table with the following data:

Elevation (ft)	Manufacturer	Model	Type	Classification	Pipe Mount Type	Pipe Mount Length (ft)	Location	Orientation	Horizontal Offset (ft)	Lateral Offset (ft)	Vertical Offset (ft)	Relative Azimuth (Deg)	Absolute Azimuth (Deg)	Ka	KaFront	KaSide
300	BEACON	Large	BEACON	Existing	None	0	Centroid	a,b	0	0	0	0	15	1	1	1

At the bottom right of the dialog are three buttons: 'Cancel', 'Apply', and 'OK'.

Discrete Appurtenance Dialog Miscellaneous Tab

Once the user adds all the input, click on the **Apply** button to apply the changes.

Output Summary

This is a read-only table where you will see the list of all the appurtenances from the level details tab aligned with the elevation sequence. In this window, you can sort information by elevation, manufacturer, model, type, carrier, classification, or location (leg/face). You can sort by individual columns or by multiple columns using a hierarchal method.


The screenshot shows the 'Discrete Appurtenance' dialog box with the 'Output Summary' tab selected. The dialog has four tabs: 'Mount Level Summary', 'Level Details', 'Miscellaneous', and 'Output Summary'. The 'Output Summary' tab contains a large table with the following data:

Elevation	Manufacturer	Model	Type	Carrier	Classification	Pipe Mount Type	Pipe Mount Length (ft)	Location	Pipe Mount Vertical Offset (ft)	Horizontal Offset (ft)	Lateral Offset (ft)	Vertical Offset (ft)	Orientation	Relative Azimuth (Deg)	Absolute Azimuth (Deg)	Ka
300	EMS WIRELESS	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	FaceA	1	0.5	6	0	a,b	10	325	1
300	EMS WIRELESS	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	FaceA	1	0.5	2	0	a,b	10	325	1
300	EMS WIRELESS	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	FaceA	1	0.5	-2	0	a,b	10	325	1
300	EMS WIRELESS	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	FaceA	1	0.5	-6	0	a,b	10	325	1
300	EMS WIRELESS	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	FaceB	1	0.5	6	0	a,b	10	85	1
300	EMS WIRELESS	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	FaceB	1	0.5	2	0	a,b	10	85	1
300	EMS WIRELESS	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	FaceB	1	0.5	-2	0	a,b	10	85	1
300	EMS WIRELESS	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	FaceB	1	0.5	-6	0	a,b	10	85	1
300	EMS WIRELESS	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	FaceC	1	0.5	6	0	a,b	10	205	1
300	EMS WIRELESS	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	FaceC	1	0.5	2	0	a,b	10	205	1
300	EMS WIRELESS	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	FaceC	1	0.5	-2	0	a,b	10	205	1
300	EMS WIRELESS	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	FaceC	1	0.5	-6	0	a,b	10	205	1
280	EMS WIRELESS	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	LegA	1	0.5	6	0	a,b	10	45	0.8
280	EMS WIRELESS	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	LegA	1	0.5	6	0	a,b	10	45	0.8
280	LGP TELECOM	LGP13901	TME	-	Existing	None	0	LegA	0	0	0	0	a,b	0	35	0.8
280	EMS WIRELESS	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	LegB	1	0.5	-6	0	a,b	10	155	0.8
280	EMS WIRELESS	DR65-18-04DPL2Q	PANEL	-	Existing	Pipe2STD	6	LegB	1	0.5	-6	0	a,b	10	155	0.8

At the bottom right of the dialog are three buttons: 'Cancel', 'Apply', and 'OK'.

Discrete Appurtenance Dialog Output Summary tab

After all the inputs are added in the relevant tab, click Save, to save the discrete appurtenance changes. The appurtenance will be added in the Tower Model Explorer under the Appurtenance Group and Discrete leaf as shown in Fig. 64.



Discrete Appurtenance got Added in the Navigation Tree

Linear Appurtenance

The Linear Appurtenance user-interface allows you to define linear appurtenances on towers to be considered for scenario analysis. It consists of two tables, **Linear Attachments** and **Linear Appurtenances**. These two tables are linked together, and the workflow is defined to reflect the industry practice. Feedlines on lattice towers are usually attached to feedline ladders, waveguide brackets, t-brackets and banjo brackets, and all these attachments may contain the feedlines of different sizes and with different start and end elevations.

The **Linear Attachments** table allows you to select an attachment type and position using lateral and horizontal offset. If no attachment exists, you can simply model the feedlines attached directly to the tower by defining the attachment as “None”.

The **Linear Appurtenances** table allows the user to define the feedlines (round or elliptical or flat) from in built catalogs or UPT. Each feedline is referring to the attachment. The quantity of feedlines and its start and end elevation is also defined in the linear appurtenance table.

Linear Appurtenance

Linear Attachment

	Attachment ID	Attachment	Attachment Spacing (ft)	Bottom Elevation(ft)	Top Elevation (ft)	Location	Lateral Offset (Fraction of Face)	Lateral Offset From Leg (in)	Horizontal Offset (in)	Attachment Azimuth (Deg)	Load Case Classification	App	KS Fa
*	1	Waveguide (2.5 ft)	3.33	8	270	FaceA	0	0	0	0	Existing	-	1
*	2	None	0	0	300	FaceB	0	0	0	0	Existing	-	1
*	3	Waveguide (2.5 ft)	3.33	8	300	FaceC	0	0	0	0	Existing	-	1
*	4	None	0	0	300	FaceA	0	0	0	0	Existing	-	1

Linear Appurtenance

	Appurtenance ID	Select Attachment	Manufacturer	Model	Quantity	Bottom Elevation (ft)	Top Elevation (ft)	Load Case Classification
*	1	1	ANDREW	LDF2-50[3/8]	1	8	110	Existing
*	2	1	ANDREW	LDF5-50A[7/8]	1	8	120	Existing
*	3	3	ANDREW	LDF2-2R[1]	3	8	193	Existing
*	4	3	ANDREW	LDF6-50A[1-1/4]	1	8	193	Existing
*	5	3	ANDREW	LDF2-50A[3/8]	2	8	205	Existing
*	6	1	ANDREW	LDF7-50A[1-5/8]	6	8	250	Existing
*	7	3	ANDREW	LDF7-50A[1-5/8]	6	8	270	Existing
*	8	1	ANDREW	LDF5-50A[7/8]	1	8	297	Existing
*	9	2	UPT:Safety Line	UPT:0.375 SL[0.375]	1	8	300	Other

FeedLine Tool

Cancel

Apply

OK

Linear Appurtenance dialog

Linear Attachment Table

Parameter

Description

Attachment ID

This is an automatically generated unique ID starting from 1. If an attachment in this table is deleted, all appurtenances assigned to that attachment in the Linear Appurtenances Table are also deleted.

Attachment

This input contains a list of all the available attachments from the linear attachment database and from UPT database.

Attachment Spacing (ft)

The spacing refers to the center-to-center vertical spacing. This column is only applicable to interval attachments such as waveguide brackets, t-brackets and banjo brackets. The default value of attachment spacing is 3.333 ft. This option is inactive for continuous attachments such as feedline ladders, climbing ladders, conduits etc.

Bottom Elevation (ft)

This is the bottom elevation of the attachment. This input has a default value of 0 ft.

Top Elevation (ft)

This is the top elevation of an attachment or attachment section.

Location

It is a drop-down option and the user can select the attachment location on the tower. There are mostly two options either from Leg or Face of the tower. For a 3-sided lattice tower and monopole, the options for location are Leg A, Leg B, Leg C, Face A, Face B, and Face C.

**Lateral Offset
(Fraction of
Face)**

For a 4-sided lattice tower, the options are Leg A, Leg B, Leg C, Leg D, Face A, Face B, Face C, and Face D.

This input is only active for attachments located on faces of the tower structure. With this option, user can locate the attachments along the face width of the tower. The range is from -0.5 to 0.5 where negative values are counterclockwise and positive values are clockwise from the center of the face. The 0 value refers to the attachment located at the center of the face along the height of the tower.

**Lateral Offset
from Leg**

This input is only active when you select a leg location. This is used to specify the lateral location of an attachment that's connected to a leg.

**Horizontal
Offset (in)**

This input specifies the attachment's standoff distance from the face. It is only active for attachments that connect to a face. The value can be both negative and positive. Negative value means the attachment is inside the tower face and positive value implies it's outside the face. The default value is 0 inches.

**Attachment
Azimuth (Deg)**

This option is for interval attachments such as t-brackets or banjo brackets. There are two options either 0 or 180 deg, 0 deg if attachments are facing inside the tower from the leg and 180 deg facing outside the tower from the leg.

**Load Case
Classification**

You can select classifications for loading such as Existing, Proposed, Reserved, To Be Removed, Other, and Suppressed. The application generates the loads and report the linear appurtenances based on the selected classifications for the scenario.

Load Case Classification	App
Existing	
Proposed	
Reserved	
To Be Removed - Reserved	
To Be Removed - Proposed	
Other	
Suppressed	


App

The application number is for reference only and has no impact on the calculations for wind load generation and analysis.

KS Factor

This input is applied to the area of appurtenances to account for the shielding effects from one appurtenance to another.

There are other features implemented to the table for the user to add, delete, copy, and paste the data to different rows. Right-clicking on a row will open a menu with the following options:



Add Attachment – It adds a new line for you to enter data for a new attachment.

Add Multiple Attachments – It allows the user to enter multiple rows of appurtenances. Clicking this option, opens another dialog box to input the required number of rows.

Delete Attachment – It deletes the selected attachment row from the table.

Add Section – It allows flexibility to split the attachment location along the height and taper of the tower

Delete Section – It deletes the selected section under the selected attachment.

Copy Attachment – It allows the user to copy the entire row of the attachment and enables the paste attachment option in the right click menu.

Paste Attachment – It will paste the copied data into the selected row.

Linear Appurtenance Table

Once an attachment ID is defined within the **Linear Attachment** table, you can assign feedlines to that attachment in the **Linear Appurtenance** table as shown in Fig. 65(above). This section allows you to assign an appurtenance to an attachment.

Right-clicking on a row will open a menu with the following options,

Insert Row- Adds a new row for you to manually enter feedline data.

Delete Row – Deletes the selected feedline data.

Insert Sub row / Delete Sub row - Allows an alternative method to re-stacking feedlines and allows quantity change.

Appurtenance ID
Select Attachment

This is an automatically generated unique ID starting from 1.

This is a drop-down list that includes list of linear attachments define in the linear attachment table. This input allows you to assign a given appurtenance to an attachment group. The default is a blank cell. All appurtenances are assigned to an attachment ID. Each time a new attachment is defined in the Linear Attachments table, its attachment ID gets added to the Attachment ID list after clicking apply.

Manufacturer

Once the manufacturer is selected, the corresponding model names will be populated. You can select an appropriate manufacturer name from the dropdown list.

Model

This drop-down list contains the list of all the models under the manufacturer.

Quantity

This input is the number of feedlines in the group or in the feedline row.

Bottom Elevation (ft)

This is the bottom elevation of the feedlines.

Top Elevation (ft)

This is the top elevation of feedlines.

Load Case Classification

You can select classifications for loading such as Existing, Proposed, Reserved, To Be Removed, Other, and Suppressed. The application generates the loads and report the linear appurtenances based on the selected classifications for the scenario.

Load Case Classification	App
Existing	
Proposed	
Reserved	
To Be Removed - Reserved	
To Be Removed - Proposed	
Other	
Suppressed	


App

The application number is for reference only and has no impact on the calculations for wind load generation and analysis.

FeedLine Tool

This feature allows users to model and arrange the feedlines on the attachments very precisely. The feedline tool is a graphical tool with built-in CAD features such as move the feedlines right, left, up

and down and zoom to an extent to place the smallest feedline to an accuracy.



FeedLine Tool

Parameter

Description

Classification

You can choose which feedlines are displayed in the Main Model Configuration by checking/unchecking the classification (treating each feedline classification as a layer).

Attachment ID

Select an Attachment ID to display the feedlines that are associated with the attachment. This drop-down menu contains all the attachment IDs with checked classifications in the classification tab.

Feedline Data

This shows the feedlines that are associated with the selected attachment ID. The five parameters shown are Appurtenance ID, (No of Lines), Nominal Size, Start-Elevation, and Classification.

Feedline Layout





In this section, user can see the linear appurtenance width and depth information for the reference. The appurtenance rotation option is for the elliptical / rectangular feedlines with option of 0 and 90 deg. The 0 deg is the default and 90 degree will rotate the feedline in such a way that the appurtenance width and depth will swap at the tool level. The number per row will auto align the feedlines in the stack configuration. The column and row spacing will change the grid spacing both in stack and attachment configuration.

Stack Configuration

This section displays feedlines after they have been selected from the 'Feedline Data' section. When adjustments are made in the 'Feedline

Select Feedlines

Layout' section, the stack configuration image will update based on those changes.

Right-clicking on the Stack Configuration grid allows further flexibility in re-positioning feedlines by using the , ,  and  arrows.




Select All

By right-clicking in the 'Stack Configuration' grid, all feedlines can be selected.

Apply to Attachment Config

After you choose 'Select All', right-click in the Stack Configuration grid to "Apply to Attachment Config". The feedlines will be transferred to the "Attachment Configuration" grid as they appeared in the "Stack Configuration" grid.

Attachment Configuration

In the Attachment Configuration Grid, you can re-position lines by choosing 'Select Feedlines' to move individual lines or 'Select All' and utilizing the , ,  and  arrows.

Grid Layout

Adjustments can be made to the Row and Column offsets to model lines more accurately.

Apply Model

Click on the **Apply Model** button to apply the attachment configuration to the main model configuration.

Main Model Configuration

This section displays the exact linear appurtenance placement as it will appear in the model.

Elevation

Enter an elevation to view the linear appurtenance configuration at various tower levels.

View Cluster

Click the **View Cluster** button to view clusters of feedlines recognized by the program. The program will cluster lines based on line spacing, not limiting clustering to line size or elevation.

For monopole tower the feedline tool interface is shown as below






Fig 66a: Monopole with circular Gridline.

Appurtenance Configuration




Appurtenance Configuration

After creating the appurtenance group, the appurtenance configuration needs to be defined to consider into the scenario. Multiple appurtenance configurations can be created. Right-click on the Appurtenance configuration and then click Add configuration, the configuration definition dialog opens. In this dialog, you have to specify a name for the configuration and have to choose classifications from the list shown in Fig.67.

8 Foundation Definition

Foundation Definition helps you to design different types of foundations of a Tower. The types of foundation that can be used are Isolated Footing (also known as Pad and Pier), MAT Foundation, Drilled Pier Foundation, and Guy Anchor Foundation. All the foundations will be designed for all appropriate load combinations for the current scenario. The different foundation types are added under the Foundation Definition leaf as shown in the image below.

In the case of multiple scenarios, the definition of foundation parameters is independent of a scenario definition. The same input data is applicable to all the scenarios.



Isolated/MAT Footing Foundation

The Isolated/Mat Footing Wizard is a step-by-step process to define a set of design parameters for isolated/Mat footing. You must double-click the **Isolated/Mat Footing Foundation** from the Tower Model Explorer. The wizard appears with auto-populated default values. You must review and edit the design parameters of each tab before saving the definition. The five input tabs for isolated/Mat Footings are described as below.

Isolated Footing Definition

In this tab, you assign the foundation definition to specific tower legs, that are listed in the **Assign Legs** field, by checking the checkbox beside the desired leg names. To select all the legs, the user can either choose, **Select All** which automatically select all the tower legs or can click on the individual checkboxes beside the Leg Name. To deselect All the selection, click the **Deselect All** radio button.

To create a **MAT foundation**, you must check the checkbox **Create MAT Foundation**. This will automatically select all the legs in the Assign Leg group and a user cannot select individual legs to be assigned for this foundation. For deselecting the legs, you must uncheck the Create MAT Foundation checkbox, or click the Deselect All radio button. Create MAT foundation checkbox is only enabled for Self-Supported Towers.

To create an Isolated Foundation, you must uncheck the Create Mat Foundation checkbox. By default, the checkbox is unchecked.

For applying the changes, you need to click the **Apply** button. Only one isolated/Mat footing definition is permitted for a given work order.

The screenshot shows a software window titled "Isolated/Mat Footing Foundation". It has five tabs: "Isolated Footing Definition" (selected), "Soil Parameters", "Footing Properties", "Pedestal Properties", and "Material Properties". The "Isolated Footing Definition" tab contains an "Assignment" section. In this section, the "Create MAT Foundation" checkbox is checked. Below this, there is an "Assign Legs" section with a list of legs: A, B, and C. Each leg has a checked checkbox next to it. To the right of the list are two radio buttons: "Select All" and "Deselect All". At the bottom of the window are three buttons: "Cancel", "Apply", and "OK".

Isolated/Mat Footing Definition

Soil Parameters

This page is used to input all the soil properties and soil type.

Isolated/Mat Footing Foundation

Isolated Footing Definition | **Soil Parameters** | Footing Properties | Pedestal Properties | Material Properties

Soil Parameter

Total Soil Unit Weight	112.0	lb/ft3
Bearing Capacity Type	Ultimate Gross Bearing Capacity	
Bearing Distribution	Plastic	
Bearing Capacity	4.0	kip/ft2
Foundation Depth	6.0	ft
Neglected Depth	10.0	in
Cohesion	0.0	lb/ft2
Friction Angle	0.0	Deg
Soil Type	Cohesionless	
Depth of Water Table	100.0	ft
Coefficient of Friction		Auto-calculated if blank
Blow Count	0	Blows/ft

Diagram: ELEVATION. Shows a cross-section of a footing with a central column. Labels include 'CLR' (centerline), 'Depth of water Table', and 'ELEVATION'.

Buttons: Cancel, Apply, OK

Soil Parameters

Parameter	Description
Unit Weight of Soil	Specify a density to be used for the soil for the selected unit. The unit can be selected from the unit combo box adjacent to this field.
Bearing Capacity Type	You must select from one of the available options which are "Ultimate Gross Bearing Capacity" or "Ultimate Net Bearing Capacity".
Bearing Distribution	You must choose either Plastic or Elastic option.
Bearing Capacity	Specify the allowable bearing capacity of the soil for the selected unit. The unit can be selected from the unit combo box adjacent to this field.
Foundation Depth	Specify the depth of the foundation in the selected units. The unit can be selected from the unit combo box adjacent to this field.
Neglected Depth	Specify the Neglected depth (or frost depth) of the foundation in the selected unit. The unit can be selected from the unit combo box adjacent to this field.

Cohesion

For footings in a drained condition, specify a cohesion pressure in the selected unit. The unit can be selected from the unit combo box adjacent to this field.

Friction Angle

Specify the angle of friction in degree.

Soil Type

Select the type of soil supporting the foundation. The options are: Cohesive, Cohesionless, and Silty.

Depth of Water Table

Specify the depth from the soil surface to the water table in the selected unit. The unit can be selected from the unit combo box adjacent to this field.

Coefficient of Friction

Specify a coefficient value of friction between the soil and concrete in the selected units. The unit can be selected from the unit combo box adjacent to this field. If this field is left as blank, the application automatically calculates the friction coefficient.

Blow Count

Specify the blow count per feet.

Footing Properties

This page is used to input geometry parameters used in the foundation design.

The screenshot displays the 'Isolated/Mat Footing Foundation' application window. The 'Footing Properties' tab is active, showing two main sections: 'Geometric Properties' and 'Rebar Parameters'. In the 'Geometric Properties' section, 'Footing Length' is set to 8.0 ft and 'Footing Height' is set to 2.0 ft. The 'Rebar Parameters' section includes 'Footing Cover' (3.0 in), 'Top Rebar Size' (6), 'Bottom Rebar Size' (6), 'Top Rebar Count' (10), and 'Bottom Rebar Count' (10). To the right of these input fields are two technical diagrams. The 'ELEVATION' diagram shows a cross-section of the footing with rebar, labeled 'Column/Pedestal' and 'Footing Depth'. The 'PLAN' diagram shows the top view of the footing, labeled 'Rebar/Column Width', 'Footing Length', and 'Footing Width'. The bottom of the window features 'Cancel', 'Apply', and 'OK' buttons.

Footing Properties

Parameter	Description
Footing Length	Specify the length to be used for the footing design in selected unit. The unit can be selected from the unit combo box adjacent to this field.
Footing Height	Specify the height to be used for the footing design in selected unit. The unit can be selected from the unit combo box adjacent to this field.
Footing Cover	Specify a concrete clear cover distance to be used for the bottom-most layer of the footing reinforcement in the selected units. The unit can be selected from the unit combo box adjacent to this field.
Top Rebar Size	Select the allowed reinforcing top bar sizes to be used in the design. Sizes listed correspond to the appropriate bar sizes used in the Design Code.
Bottom Rebar Size	Select the minimum and maximum allowed reinforcing bar sizes to be used in the design. Sizes listed correspond to the appropriate bar sizes used in the selected Design Code.
Top Rebar Count	Specify the top rebar count.
Bottom Rebar Count	Specify the bottom rebar count.

Pedestal Properties

This page is used to input pedestal geometry parameters used in the foundation design.

Parameter	Description
Consider Pedestal	Select from "Yes" or "No" options, to specify whether to consider pedestal or not.
Pedestal Shape	Select the pedestal shape, either from "Square" or "Circular".
Pedestal Length/ Dia	Specify the length of the pedestal in case of a square pedestal shape or diameter for a circular pedestal shape in the selected unit. The unit can be selected from the unit combo box adjacent to this field.
Pedestal Height	Specify the pedestal height to be used for the footing design in selected unit. The unit can be selected from the unit combo box adjacent to this field.
Pedestal Cover	Specify the pedestal cover to be used for the footing design in selected unit. The unit can be selected from the unit combo box adjacent to this field.

Longitudinal Rebar Size

Select the longitudinal reinforcing bar size to be used for capacity calculation. Sizes listed correspond to the appropriate bar sizes used in the Design Code

Longitudinal Rebar Count

Specify the rebar count.

Tie Size

Select the tie size to be used for capacity calculation. Sizes listed correspond to the appropriate tie sizes used in the Design Code

Tie Count

Specify the tie count.

Superimposed Axial Load or Pure Bending

The radio button with the two options Superimposed Axial load or Pure bending help the user to select the design intent of the pedestal.

Anchor Bolt Circle

This input field is enabled if the user selects Pure Bending or if the user selects Superimposed Axial Load along with consider pedestal as “No”. Specify the anchor bolt diameter when it is enabled.

Centroid Offset (for MAT)

This input field is considered only for MAT foundation when you select the Create MAT foundation Checkbox in the Footing Definition Page. Specify the tower centroid offset from the foundation centroid. The unit can be selected from the unit combo box adjacent to this field.

Isolated/Mat Footing Foundation

Isolated Footing Definition Soil Parameters Footing Properties Pedestal Properties Material Properties

Pedestal Properties

Geometric Properties

Consider Pedestal Yes

Pedestal Shape Circular

Pedestal length/Dia 4 ft

Pedestal Height 3.5 ft

Anchor Bolt Circle 4.0 in

Centroid Offset (for MAT) 0.0 in

☒ Superimposed Axial Load ☐ Pure Bending

Rebar Parameters

Pedestal Cover 3.0 in

Longitudinal Rebar Size 9

Longitudinal Rebar Count 13

Tie Size 4

Tie Count 7

Column/Pedestal

Length x Breadth Per Plan

ELEVATION

PLAN


Cancel Apply OK

Pedestal Properties

Material Properties

This page is used to input material properties.


Parameter	Description
Steel Grade	Specify the strength of steel reinforcing bars, in specified units. The unit can be selected from the unit combo box adjacent to this field.
Concrete Grade	Specify the ultimate strength of the concrete in the selected unit. The unit can be selected from the unit combo box adjacent to this field.
Concrete Density	Specify concrete density in the selected unit. The unit can be selected from the unit combo box adjacent to this field.



Material Properties

Drilled Pier Foundation

The Drilled Pier Footing Wizard is a step-by-step process to define a set of design parameters to be used for designing a drilled pier foundation. You must right-click on the **Drilled Pier Foundation** leaf from the Tower Model Explorer navigation tree to create a new definition. The wizard appears with auto-populated default values. You must select all the tabs and review all the parameters before clicking on Save to complete the wizard and create a new definition for a drilled pier foundation. The four input tabs for a Drilled Pier foundation are as described below.



Create New Drilled Pier Foundation

Drilled Pier Definition

In this tab, a user assigns the foundation definition to specific tower legs, that are listed in the **Assign Legs** field, by checking the checkbox beside the desired leg names. To select all the legs, the user can either choose, **Select All** which automatically select all the tower legs or can click on the individual checkboxes beside the Leg Name. To deselect All the selection, click the **Deselect All** radio button. For applying the changes, the user needs to click the **Apply** button. You can create multiple drilled pier definitions in a single work order. Once created, if you double-click on the definition name, the wizard automatically opens for editing.

The screenshot shows a software window titled "Drilled Pier Foundation" with standard window controls (minimize, maximize, close). The interface has four tabs: "Drilled Pier Definition", "Soil Parameters", "Drilled Pier Properties", and "Material Properties". The "Drilled Pier Definition" tab is active and contains the following elements:

- A text field labeled "Drilled Pier Definition ID" containing the text "DrilledPierID1".
- A section titled "Leg Selection" which includes:
 - A label "Assign Legs" next to a list of three checkboxes labeled A, B, and C.
 - Two radio buttons labeled "Select All" and "Deselect All".
- At the bottom right, there are three buttons: "Cancel", "Apply", and "OK".

Drilled Pier Definition Page

For a guyed tower, the drilled pier definition page adds another section for anchor selection apart from the leg selection.

The **Anchor group** list the groups that are already defined.

Anchor Guy lists all the anchors assigned to the selected anchor group. To select a particulate anchor, you must click the corresponding checkbox. To select all anchors, you can simply click on the **Select All** radio button. To deselect all the selection, you can choose **Deselect All**. To apply the changes, click on the **Apply** button. Drilled Pier Definition ID is a unique name that will be saved and viewed in the Tower Model Explorer.

Drilled Pier Foundation

Drilled Pier Definition Soil Parameters Drilled Pier Properties Material Properties

Drilled Pier Definition

Drilled Pier Definition ID: DrilledPierID1

Leg Selection

Assign Legs: ☐ A

☐ Select All

☐ Deselect All

Anchor Selection

Anchor Group: Outer

Anchor Guy: ☐ A, ☐ B, ☐ C

Cancel Apply OK

Drilled Pier Definition page for Guyed Tower

Soil Parameters

This page is used to input all the soil properties and soil type.

Drilled Pier Foundation

Drilled Pier Definition Soil Parameters Drilled Pier Properties Material Properties

Soil Parameters

Depth of Water Table (ft): 100 Expansive Soil Force (kips): 0

Drag a column here to group by this column.

LayerNo	SoilType	Depth of Bottom of Layer(ft)	Total Soil Unit Weight...	Friction Angle(°)	Cohesion (psf)	Ultimate Skin Friction Comp.(psf)	Ultimate Skin Friction Uplift (psf)	Ultimate Gross End Bea...	N (Blows/ft)
1	Cohesive	3	130	0	1500			0	0
2	Cohesionless	10	125	30	0			0	0
3	Cohesionless	16	125	35	0			0	0
4	Silty	35	135	22	2000			16000	0

Skin Friction is Auto-calculated if blank

Cancel Apply OK

Soil Parameters Page

Parameter	Description
Depth of Water Table (ft)	Specify the water table depth measured from the Ground Elevation
Layer No	This field is not editable, and auto incremental.
Soil Type	Select the soil type that best describes the layer. Options are Cohesive, Cohesionless, and Silty.
Depth of Layer (ft)	Depth for each soil layer is measured from Ground Elevation
Density (kcf)	Specify soil density for the respective soil layer.
Friction Angle (Deg)	Specify the Effective Friction Angle
Cohesion (ksf)	Undrained shear strength of cohesive soil.
Ultimate Skin Friction (ksf)	Specify skin friction. If you leave this field blank, the program will automatically calculate Skin friction.
Ultimate Skin Friction Uplift (ksf)	Specify ultimate skin friction for uplift. If you leave this field blank, the program will automatically calculate ultimate skin friction for uplift.
Ultimate End Bearing Pressure (ksf)	Specify ultimate end bearing pressure at the bottom of a layer
N (Blows/ft)	Specify the blow count
Expansive Soil Force	Specify the extra soil force exerted due to expansive soil condition

Drilled Pier Properties

This Page is used to input drilled pier geometric properties and Reinforcing properties. It consists of two tables, Pier Profile, and Rebar Cage List. The rebar cage table is dependent on the pier profile table. It allows you to add and edit reinforcing related data of the corresponding section, selected in the pier profile table. You can add multiple sections to the pier with different diameters, depths, clear covers, and tie sizes. For a given geometric section, users can assign multiple rebar cages to that section.

Drilled Pier Foundation

Drilled Pier Definition Soil Parameters **Drilled Pier Properties** Material Properties

Drilled Pier Geometry

Geometry properties

Pier Height Above Ground (ft) Segment Length (ft) Depth Unit Diameter Unit Cover Unit

0.5 0.0185 ft ft in

Pier Profile

Drag a column here to group by this column.

Section ID	Section Depth	Diameter	Cover	Tie Bar Size
1	20	4	3	3
2	14	3	3	3

Click here to add a new pier profile

Rebar Cage List

Drag a column here to group by this column.

Section ID	Rebar Cage ID	Rebar Cage Diameter	Rebar Size	Rebar Count
1	1	3.35416666666667	8	16

Click here to add a new rebar

Apply Changes to Rebar

PIER ELEVATION

Rebar Cage Diameter for Rebar Cage 1 is auto-calculated when changes are applied

Cancel Apply OK

Drilled Pier Properties page

Parameter

Pier Height Above Ground (ft)

Segment Length (ft)

Section ID (Pier Profile)

Section Depth

Diameter

Cover

Description

Specify pier height above ground level

Specify the segment length of a pier section. A short segment length used by the program to break up the pier into many small segments to perform design calculations.

Auto incremental and non-editable unique ID of a section

Specify the depth of the corresponding section

Specify the diameter of the corresponding section, the unit can be selected from the diameter unit combo box.

Specify side reinforcing cover, the unit can be selected from the cover unit combo box.

Tie Bar Size	Select the reinforcing tie bar size to be used in the design. Sizes listed correspond to the appropriate tie sizes used in the Design Code
Section ID (Rebar Cage List)	Auto incremental and a non-editable unique ID. This ID is the selected ID of the pier profile table.
Rebar Cage ID	Auto incremental and non-editable unique ID.
Rebar Cage Diameter	Specify the diameter of the corresponding reinforcing cage. The unit can be selected from the depth unit combo list.
Rebar Size	Select the reinforcing bar size for longitudinal reinforcement. Sizes listed correspond to the appropriate tie bar sizes used in the Design Code
Rebar Count	Specify the rebar count.

To add a new row in pier profile table or in the rebar cage list, click “Click here”. It adds a new pier profile or a new reinforcing property respectively. Rebar Cage diameter gets automatically calculated based on the section diameter and other reinforcing properties. You are not allowed to update the calculated Rebar Cage Diameter.

Apply Changes to Rebar Button is used to apply changes users made in the rebar cage list table.

Material Properties

Drilled Pier Foundation

Drilled Pier Definition

Soil Parameters

Drilled Pier Properties

Material Properties

Material Property

Steel Grade

60.0

ksi

Concrete Grade

3.0

ksi

Concrete Density

150.0

lb/ft3

Cancel

Apply


OK

Material Property Page

Parameter	Description
Steel Grade	Specify the strength of steel reinforcing bars, in specified units. The unit can be selected from the unit combo box adjacent to this field.
Concrete Grade	Specify the ultimate strength of the concrete in the selected unit. The unit can be selected from the unit combo box adjacent to this field.
Concrete Density	Specify a density to be used for concrete in the selected unit. The unit can be selected from the unit combo box adjacent to this field.

Guy Anchor Foundation

The Guy Anchor Foundation is available only for guyed towers. This wizard is a step-by-step process to define a set of design parameters for a guy anchor foundation design. You must right-click on the **Guy Anchor Foundation leaf** from the Tower Model Explorer navigation tree, to create a new definition. The wizard appears with auto-populated default values. Select each tab and review all design parameters before clicking the **Save** button. Multiple guy anchor foundations can be defined for a given Work Order. The four input tabs for a Guy anchor foundation are described as below.



Create New Guy Anchor Foundation

Guy Anchor Definition

In this tab, you assign the foundation definition to specific tower legs, that are listed in the **Assign Legs** field, by checking the checkbox beside the desired leg names. To select all the legs, the user can either choose, **Select All** which automatically select all the tower legs or can click on the individual checkboxes beside the Leg Name. To deselect All the selection, click the **Deselect All** radio button. For applying the changes, the user needs to click the **Apply** button. You can create multiple guy anchor definitions in a single work order. To edit design parameters, the user can double click on the definition name. Anchor Guy Definition ID is the unique name that will be saved and viewed in the Tower Model Explorer.

Guy Anchor Foundation

Anchor Guy Definition ID:

Anchor Selection

Anchor Group:

Anchor Guy: ☐ A ☐ B ☐ C

Buttons: Cancel, Apply, OK

Guy Anchor Definition Page

Soil Parameters

This page is used to input all the soil parameters for guy anchor foundations. Multiple soil layers can be defined using a table, with each row representing a different layer of soil.

Guy Anchor Foundation

Soil Parameters

Depth to Bottom of Anchor:

Neglect Depth:

Depth to Water Table:

Soil Properties

Drag a column here to group by this column.

Layer	SoilType	Depth of Bottom of Layer(ft)	Total Soil Unit Weight (pcf)	Friction Angle (°)	Cohesion (psf)	Ultimate Skin Friction (psf)	N (Blows/ft)
1	Cohesive	2	120	0	0		0
2	Cohesionless	5	120	0	0		0
3	Cohesionless	10	130	0	0		0

Buttons: Cancel, Apply, OK

Small text: Skin Friction is Auto-calculated if blank

Soil Parameter Page

Parameter	Description
Depth to Bottom of Anchor	Specify the depth of the bottom of the anchor block in specified units. The unit can be selected from the unit combo box adjacent to this field.
Neglect Depth	Specify the neglected (or frost) depth in the selected unit. The unit can be selected from the unit combo box adjacent to this field.
Depth of Water Table	Specify the depth of the top of the water table, measured from Ground Elevation in the selected unit. The unit can be selected from the unit combo box adjacent to this field.
Layer	This field is non-editable, and auto incremental.
Soil Type	Select the type that best describes the contents of the selected layer
Depth of Bottom Layer (ft)	Specify the bottom depth of each soil layer, measured from Ground Elevation
Soil Unit Weight (kcf)	Specify the unit weight of soil for the corresponding soil layer
Friction Angle (Deg)	Specify Effective Friction Angle for the corresponding soil layer
Cohesion (kcf)	The undrained shear strength of the respective soil layer.
Ultimate Skin Friction (ksf)	Specify the ultimate skin friction of the respective soil layer. The application will automatically calculate this value if the field is left blank.
N (Blows/ft)	Specify the blow count of the respective soil layer.

Guy Anchor Properties

This page is used to input all the geometrical properties of a guy anchor foundation.

Guy Anchor Foundation

Guy Anchor Definition Soil Parameters **Guy Anchor Properties** Material Properties

Guy Anchor Properties

Geometry

Footing Width: 3.0 ft

Footing Height: 3.0 ft

Footing Length: 10.0 ft

Toe Dimension: 0.0 ft

Anchor Shaft

Quantity: 1

Diameter: 2 in

Area Override: in2

Auto-calculated if blank

Rebar

Rebar Size: 5

Top Rebar Count: 4

Front Face Rebar Count: 4

Clear Cover: 3.0 in

Cancel Apply OK

Guy Anchor Properties Page

Parameter

Description

Footing Width

Specify the width of the anchor block to be used for design, in selected units. The unit can be selected from the unit combo box adjacent to this field.

Footing Height

Specify the height of the anchor block to be used for design, in selected units. The unit can be selected from the unit combo box adjacent to this field.

Footing Length

Specify the length of the anchor block to be used for design, in selected units. The unit can be selected from the unit combo box adjacent to this field.

Toe Dimension

Specify the toe dimension, in selected units. The unit can be selected from the unit combo box adjacent to this field.

Quantity

Specify the number of anchor rods

Diameter

Specify the diameter of each anchor rod in the selected unit. The unit can be selected from the unit combo box adjacent to this field.

Area Override

This is an optional input to override the total anchor rod area. The application automatically calculates area based on diameter and quantity if the field is left blank.

Rebar Size	Select reinforcing rebar size to be used in the design. Sizes listed correspond to the appropriate bar sizes used in the Design Code.
Top Rebar Count	Specify the number of reinforcing bars at the top of the footing.
Front Face Rebar Count	Specify the number of reinforcing bars at the front face.
Clear Cover	Specify a concrete clear cover distance to be used for the bottom-most layer of footing reinforcement in the selected unit. The unit can be selected from the unit combo box adjacent to this field.
Quantity	Specify the quantity.
Diameter	Specify the diameter in selected units. The unit can be selected from the unit combo box adjacent to this field.
Area Override	Specify area override in selected units. The unit can be selected from the unit combo box adjacent to this field. If you leave this field empty, the application will automatically calculate the area override.


Material Properties

Material Property Page

Parameter	Description
Steel Grade	Specify the strength of steel reinforcing bars, in specified units. The unit can be selected from the unit combo box adjacent to this field.

Concrete Grade	Specify the ultimate strength of the concrete in the selected unit. The unit can be selected from the unit combo box adjacent to this field.
Concrete Density	Specify a density to be used for concrete in the selected unit. The unit can be selected from the unit combo box adjacent to this field.
Anchor Shaft Grade	Specify the grade of anchor shaft in the selected unit. The unit can be selected from the unit combo box adjacent to this field.


As foundation definitions are created, those are added within the foundation definition navigation tree as shown in Fig. 84. After a successful completion of tower structural analysis, the application will design foundations based on these definitions.



Drilled Pier Foundation


Design Foundation and Foundation Output

To design foundation, a user must right click on the current scenario name and select "Foundation Design", to perform foundation design checks.



Foundation Design

- Select **Set Active** to activate the scenario.
- Select **Generate Load** for designing load.
- Select **Perform Analysis**, to analyze the model.
- Select **Foundation Design** to start designing the foundation, defined.
- Once the foundation is designed successfully, a message will be shown in the Output window, in the lower pane, **Foundation Design Completed, Foundation Report Added**. It will automatically add a new menu in the popup shown below, **Foundation Output Report**.



After successful completion of foundation design, the program will automatically add a new item in the popup menu, called Foundation Output Report. To review the foundation design output, you can click on the new menu item. It will bring up the foundation design output window, which comprises all the output of different types of foundation defined for this model in specific tabs as shown in Fig. 86, Fig. 87, Fig. 88 and Fig. 89.

Foundation Design Output

Isolated Foundation Output Anchor Guy Foundation Output Drilled Pier Foundation Output Mat Foundation Output

Design Results

Drag a column here to group by this column.

	Governing Load Case	Capacity	Demand	Rating(%)	Check
Bearing Capacity (kip/ft ²)	3	8.298	3.6457	43.9347	Pass
Uplift (kip)	1	21.7018	0	N/A	Pass
Sliding Check (kip)	23	38.3075	1.2863	3.3578	Pass
Overturning Check (kip-ft)	23	402.2184	6.0777	1.511	Pass
One Way Shear Check(kip)	3	124.657	44.3262	35.5585	Pass
Punching Shear Check (kip)	3	0.1897	0.0703	37.0589	Pass
Pad Moment Check (kip-ft)	3	354.6728	104.1398	29.3622	Pass
Pier Compression Check (k...	3	3124.3139	221.0779	7.076	Pass
Pier Moment Check (kip-ft)	23	332.7039	3.3443	1.0052	Pass

OK

Isolated Foundation Output Report

Foundation Design Output

Isolated Foundation Output Anchor Guy Foundation Output Drilled Pier Foundation Output Mat Foundation Output

Design Results


Anchor Guy GuyAnchorID1 Node ID 549

Drag a column here to group by this column.

	Governing Load Case	Capacity	Demand	Rating(%)	Check
Lateral (kip)	21	139.9725	54.8411	39.1799	Pass
Uplift (kip)	21	151.8871	52.4611	34.5396	Pass
Uplift Moment (kip-ft)	21	695.3859	179.0237	25.7445	Pass
Lateral Moment (kip-ft)	21	608.0584	187.1453	30.7775	Pass
Anchor Tension (kip)	21	125.6637	75.8928	60.3936	Pass


OK

Anchor Guy Foundation Report



Drilled Pier Foundation Report

Drilled pier foundation report, also shows Moment Diagrams for the critical load combination. It draws moment diagrams along the depth of the pier and offers demand vs. capacity comparison. As Anchor Guy and Drilled Pier foundations can have more than one definition, reports are organized and listed under foundation ID. You can select the desired definition ID from the combo box to view the corresponding output.



MAT Foundation Report

MAT foundation report also shows Moment Diagram and Shear Diagram for critical load combination.

9 Scenario Analysis

Scenario definition is a unique setup, which enables engineers to perform multiple structural analysis by combining different geometric modification layers with hierarchy, appurtenance group and configuration, and loading conditions. You must create a scenario to perform analysis and then design checks.

Scenario

Name : Scenario1 Copy From : None

Select Geometry

Modification Geometry

Name	Description
------	-------------

Appurtenance and Configuration

Appurtenance Group	Appurtenance Configuration
None	None

Loading Criteria

Wind Definition	Seismic Definition
None	None

Cancel OK

Scenario

Parameter	Description
Name	Specify a scenario name, which is unique to this model.
Copy From	You can copy an existing scenario from the list of scenarios, or else can choose None.
Modification Geometry	Modifications are selected to be included in the tower geometry or structural component. If none of the modification is selected or

Appurtenance and Configuration

checked, it will not be considered in the tower geometry, i.e. in the case when a modification is not yet installed or rendered ineffective. The modifications can be adjusted/arranged with the up and down arrows to define the hierarchy. To edit a Modification layer, you need to De – Activate the scenario first.

Loading Criteria


Selecting the appurtenance group considers the loading modeled for the analysis. The appurtenance configuration is chosen based on the desired load combination to be considered in the analysis.

Select the wind and seismic definition to be used for loading generation. In case, the user considers the different standards for both wind and seismic then the application provides the validation message for user to correct the design standard. This same design standard will be used for the member and connection design checks.


Operations on Scenario

Once you create a scenario, the different operations that can be performed on the scenario are described below (Fig.91).

Operation	Description
Set Active	This operation will activate the selected scenario.
Options	With this operation, you can choose different checking conditions for the design, load generation, and analysis. A dialog box will open once you click Options. (Fig. 92).
Generate Load	Once you have activated the scenario, for designing load, you must click Generate Load.
Perform Analysis	After the load generation is completed, the output window will show the message “Model is ready for the analysis”. Right click on active scenario and click on perform analysis will perform the required analysis per design standard. After performing an analysis, you can view the analysis result from the Results Tab.
Foundation Design	To design foundations, click on Foundation design. Foundation design will not be performed if the analysis has not been performed on the active scenario.
Delete	To delete the scenario, select the scenario and click delete. To delete the active scenario, user need to de-activate the scenario first before delete.
De-Activate Scenario	To deactivate the active scenario, click De-Activate scenario.



Scenario



Options


Parameter	Description
Consider Leg Moment	This option is used to consider flexural and Interaction checks for leg members.
Consider Diagonal Moment	This option is used to consider flexural and Interaction checks for Diagonal members.
Consider Horizontal Moment	This option is used to consider for flexural and Interaction checks for Horizontal members.
TIA - 222-G Minimum Bracing Exemption 15.6. b	When checked, Minimum bracing resistance $P_r = 1.5\% F_s$ will be used as per section 15.6. b.
Wind Loading Patterns	This option is checked by default and the different wind load pattern is auto generated to account the dynamic effects of wind gusts as specified in TIA code.
Consider TIA 4.9.7 Splice check	This option is visible only for Guyed Tower. When checked, Leg bolts will be checked in accordance with Section 4.9.7 of TIA-222-G/H

The options group displays the different tower members in a tree view format on the right-hand side and the graphics on the left-hand side (Fig.92). The member that is not checked or selected in the tree view is considered in the load generation but not in the design. Once you

save these changes, the program will analyze and design the member depending upon the selection.

Analysis


To view the analysis result, the user must perform analysis. **Perform Analysis** can be done by right-clicking on the active scenario and select the perform analysis option. Once the analysis is done, a message will appear “Analysis Successfully Completed”. The generated load cases, analytical objects, and results including displacements, forces and reactions are populated and can be viewed under the leaf Analysis, in Tower Model Explorer. (Shown in Fig. 93).



Analysis


The Analysis section contains Load Cases, Analytical Objects and Results group under Structure leaf of the activated scenario.

The Load Case section shows all the Primary Load Cases and Load Combinations. If you click on the particular primary load case the property window on the right will show the wind pressure profile and the table with pressure values along the height of the tower. Click on particular value in the primary load case will show the detail information of the nodal load in the property window (Shown in Fig.94).




Primary Load Case

If you click on the particular Load combination leaf, the property window on the right will show all the load cases which are used to create the load combination (Fig. 95). To check the different Primary Load Cases or Load Combinations you can expand the respective leaf under Load Cases.




Load Combination

The Analytical Object contains the Nodes and Members as child leaf. To view the Nodes of the model, you must right-click and select **Show Nodes** from the pop-up menu to display the Analytical Load Table in the Output Pane. (Fig. 96). To view the Members of the model, you must right-click and select **Show Members** from the pop-up menu to display the Analytical Member Table in the Output Pane. (Fig. 97).



Node No	Physical Node No	X Co-ordinate (ft)	Y Co-ordinate (ft)	Z Co-ordinate (ft)	Support
1	1	2.887	147.5	0	
2	2	2.887	150	0	
3	3	-1.443	147.5	-2.5	
4	4	-1.443	150	-2.5	
5	5	-1.443	147.5	2.5	
6	6	-1.443	150	2.5	

Analytical Node Table



Member ID	Start Node	End Node	Physical Member ID	Length (ft)	BetaAngle (deg)
2	1	2	1	2.5	-225
4	3	4	2	2.5	90
6	5	6	3	2.5	-90
8	10	32	4	0.5	-225
9	32	29	4	2.4286	-225
10	29	26	4	2.4286	-225

Analytical Member Table

The Results section contains the following groups of results:

- Displacement Results
- Force Results
- Reaction Results

Analysis Results

Displacement

Description

The displacement results provide the node displacement and the deflected profiles.

Node Displacement table can be seen by right-click on “Node Displacements” and select “Show Node Displacement Table” in the Output pane.

Deflected Profile group contains three different types of deflected shapes

- Horizontal Deflection

Force

- Tilt
- Twist

To view a profile, click on that profile and the deflected shape will be displayed in the property window on the right side.

All output related to member forces are grouped into two options

- Linear Members – contains several output tables
 - Member End Forces – right click will show member end force table in output window
 - Section Forces - right click will show section forces table in output window
 - Section Displacement - right click will show section displacement table in output window
 - Member force Graphs – click on member force graph will show the graphs in output window. User can select the physical member ID and one of the force graphs (axial, shear, torsion and bending) for the select load case in the active load case window in the main ribbon

Leg Compression Curves -provides the compression graphs for the legs in the right-side property window.


Reaction

The right click on overall tower reaction in the reaction results will show support reaction table for the selected load case in the output window.

Report

To view the report of the analyzed model, the user must select the Report tab from the ribbon bar.


Report tab Contains many features for formatting, viewing, and distributing user's compiled reports. Once the user loads the Report tab, the Tower Model Explorer is replaced with two different side windows: The Report Document Map and the Selected Items List. These tools, along with the tools found along the ribbon bar, are used to add elements into the report, customize the format, and produce reports for external use and distribution. In the left panel, **Available Report Items** will be listed under the **Reports**. To generate the report, you must select the items by dragging them from the Available Report Item panel and drop it to the Selected items section. This is shown in Fig. 98.




Report Tab

Report Contents


Each individual output section can be dragged and dropped into the 'Report Contents' section. This enables you to quickly view output sections one at a time or the entire output report.



Viewing Individual Output Sections



Viewing the Entire Output Reports


Once added in the selected item list, you must click the Generate Report button , to generate the report. It compiles all the sections in the 'Report Contents' into a report to the right of the section. You can navigate through the report by clicking on specific items within the report.

Print Date: 3/12/2019 STAAD Tower CE : 10.00.01.003 Page 2 of 39

Section Id	Section Range (ft)	Section Length (ft)	Fae Bracing	Diagonal Spacing (ft)	Top Width (ft)	Bottom Width (ft)	Top Girt Offset (in)	Bottom Girt Offset (in)
1	300-280	20	X	4.9583	5	5	1	1
2	280-260	20	X	4.9583	5	5	1	1
3	260-240	20	X	4.9583	5	7	1	1
4	240-220	20	X	4.9583	7	9	1	1
5	220-200	20	X	6.6111	9	11	1	1
6	200-180	20	X	6.6111	11	13	1	1
7	180-160	20	X	6.6111	13	15	1	1
8	160-140	20	X	6.6111	15	17	1	1
9	140-120	20	X	9.9167	17	19	1	1
10	120-100	20	X	9.9167	19	21	1	1
11	100-80	20	X	9.9167	21	23	1	1
12	80-60	20	X	9.9167	23	25	1	1
13	60-40	20	K3 Down	19.8333	25	27	1	1
14	40-20	20	K3 Down	19.8333	27	29	1	1
15	20-0	20	K3 Down	19.8333	29	31	1	1

Tower Geometry Selected

Print Group



Commands for printing a hard copy of your report from OpenTower.

Report Printing commands



Opens a Windows print dialog box to select a printer and modify printer preferences.

Print



Sends the report directly to your default Windows printer.

Quick Print




Inactive.

Options

Page Setup Group

Controls the printed page size and layout of your report.



Report page setup commands



Set the options for the header and footer of the report document.

Header/Footer



Scale

Opens the Scale Settings panel to set your report scale.



Margins

Opens the Margins gallery where you can select predefined options or set custom margins.



Orientation

Opens the page Orientation gallery.




Size

Opens the Page Size gallery.

Scale Settings

It allows you to specify how the document should be scaled on a printed page.



Adjust to

Set the scale based on the percentage to full size.

Fit to

Scale the report output based on page width.


Margins

The Margins tool opens the margins gallery, where allows you may select from a list of preset margin sizes or set Custom Margins.



Set Custom Margins

1. On the Reports ribbon tab, click the Margins tool.
2. Select Custom Margins ... at the bottom of the gallery list. The Page Setup dialog box opens.



3. Specify the Margins (in inches) in the Margins panel.
4. Click **OK**.

Orientation

The Orientation tool opens the orientation gallery, where you can set the report page orientation to either Portrait or Landscape.




Size

The Size tool opens the Page Size gallery, where you can select from a variety of common paper sizes for your report output.



Navigation Group

Here, you will find controls to navigate through your on-screen report.



Report screen navigation commands



Opens the Find dialog box which is used to search for specific text strings within your generated report.

Find



Jumps the current report view to the first page.

First Page



Steps the current report view backward one page.

**Previous
Page**



Steps the current report view forward one page.

Next Page




Jumps the current report view to the last page.

Last Page

Find dialog box

Used to search for specific text strings within your generated report.

Opens when you select the **Find** tool on the Report ribbon tab Navigation group.




Dialog Controls


Find what	Specify a text string for which to search. Previously used text strings are available in the drop-down box by clicking the arrow.
Search Options	<p>Select any combination of options to narrow your search:</p> <ul style="list-style-type: none">• <i>Match case</i> — The search is case insensitive by default. This restricts the search to use on the letter case you enter.• <i>Match whole word</i> — The search will return partial word matches by default. This option restricts to only complete word matches (strings between whitespace and punctuation).• <i>Search up</i> — The search starts at the current point in the document and works towards the end. This option reverses the search to move from the current point towards the beginning.
Find Next	Click this button to begin/continue the search
Close	Closes the Find dialog.

Zoom Group

A series of controls for setting the display of your current *Report View*.



Report view zoom commands


**Mouse
Pointer**

The default pointer which does not affect the magnification or scrolling of your report in the Report View window. Use this to "turn off" the Hand Tool or Magnifier features.


Hand Tool

This tool allows you manually to scroll by clicking and dragging a page up or down.



This tool toggles between viewing the report at 100% and viewing an entire page.

Magnifier



Choose the page layout for displaying the report.

View Many Pages



Click to see more of the page.

Zoom Out



Produces a menu for resizing the page view to many preset sizes. You can also specify a custom zoom by percentage.

Zoom



Get a close-up view of the document.

Zoom In

Page Background Group

You can customize the background of the report pages.

Table 7-30: Report page watermark commands




Page Color

You can choose a color for the background of the report document.

Export group

OpenTower gives you the capability to save a prepared report in a variety of file formats for later use or distribution. The **Export To...** tools are used to save the file to a storage device (local hard drive, network drive, etc.). The **E-Mail To...** tools will open your default windows application and add the file as an e-mail attachment. Both will provide you with the same file options dialog before saving or attaching.



PDF File

Opens the PDF Export Options dialog, which is used to save the report as a portable document format (file extension .PDF) file. These files are commonly used to transport text and graphical data in a self-contained file. They require a reader program, such as Adobe® Reader®.



HTML File

(Export to only) Opens the HTML Export Options dialog, which is used to save the report as a hypertext markup language (file extension .HTM or .HTML) file. These files may contain text, images, and formats in separate files (depending on the options selected). They are typically read by web browsers such as Microsoft Internet Explorer® and Mozilla Firefox®.

Note: You cannot select HTML files for e-mailing. Use. MTH files instead for attaching a file which can be read by many web browsers.




MHT File

Opens the MHT Export Options dialog, which is used to save the report as a MIME HTML (. MHT) file. These files are self-contained html documents which can include rich data which can be read by Microsoft Internet Explorer® 5 or higher.



RTF File

Opens the RTF Export Options dialog, which is used to save the report as a rich text file (file extension .RTF). Rich text files contain both text and images in a single file and also preserves much of the formatting from your report. These files can be read by a wide variety of word processing programs, such as Microsoft Office Word® or Sun OpenOffice®.



Excel File


Opens the XLS Export Options dialog, which is used to save the report as a Microsoft Office Excel 2003 spreadsheet (file extension .XLS). These files can contain images and text data, as well as preserve the table structure. They also allow for some richer formatting features for making your data easier to read. They are typically only readable by spreadsheet programs such as Microsoft Office Excel®, IBM Lotus 1-2-3®, or Sun OpenOffice®.



CSV File

Opens the CSV Export Options dialog, which is used to save the report as a comma-separated values text file (file extension .CSV). These files are plain text with a specified content delimiter (typically a comma).

Note: No images will be included in this format.



Text File

Opens the *Text Export Options* dialog, which is used to save the report as a plain text file. These files can be read by a wide variety of programs and devices.

Note: No images will be included in this format.




Image File

Opens the *Image Export Options* dialog, which is used to save the report to one of several image file types. Saving to an image file creates a raster image of the entire report output (though .WMF files can also include vector data). The data in the image file is not directly editable, though image editors can manipulate the file graphically. All information will be human readable, though.

Note: Reports saved to image file formats will create single image files of the entire report, except for a .TIFF file which are multi-paged images.

10 Graphical Interface



Graphical Interface

Standard Group

The Standard group contains common tools for file operations and for managing the content within the current model file.



Opens the New dialog box to create a new tower model.




Used to open an existing file. Clicking the icon launches the common window file browser for selecting a file to be opened.



Used to close the current file. The program will prompt the user to save the file before closing.




This will save any changes made in the current model file since the last save.



Opens a Windows *Save As* dialog, which is used to save the current model in a different location or with a different file name.

View Group

The view group contains commonly used view control tools.



The physical Model tool is used to toggle the display of the physical model elements in the *View* pane (default view). The physical view mode is typically the environment in which the user will construct tower models. **The analytical Model** tool is used to toggle the display of the physical model elements in the *View* pane. The analytical view mode is used for reviewing the mathematical model which will be used by the application engine in the analysis. Click the **Tables** menu button, it displays a list of commonly used tables. Click any of the menu items to display that table in the *Output* pane. You can also hide the table from the output pane by clicking on the table you want to hide from the list of the tables in the pop-up menu.



Click on any of the tower view buttons to change the tower perspective. A set of tools used to control the global orientation of the *View* pane by a set of predefined directions. A seventh tool highlights three faces of the cube. This changes the current Model View to an isometric view.



Rotate tool is used to rotate the perspective in the *View* pane about all the three-global axis.



It is used to control the zoom level within the *View* pane as well as pan about the view

Show Physical Member table

Displays all members and some associated properties. Some properties can be edited directly from this table.

Show Node table

Displays all notes and associated properties

Show Joint Displacements table

Displays the joint displacements and rotations for each load case.

Show Support Reactions table

Displays the reactions at all supports for each load case.

Show Member End Forces table

Displays the force and moments at both ends of each analytical member

Show Section Force Table

Displays the section forces for all physical members in 13 intermediate section points along the length of a physical member for a given load case.

A separate control just above the table can be used to ascertain the section force at a given distance.


Show Section Displacement Table

It is used to view numerical values for sectional displacements along the length of members. The table displays the displacements of members at intermediate section points. The table shows displacements along the local axes of the members, as well as their resultants.

Show Cable Station Section Force table	Displays the section forces for all cable members (i.e. Guy cable) in intermediate section points along the length of the cable
Show Cable Station Deformation Table	Displays the section deformation for all cable members (aka guy cable) in intermediate section points along the length of the cable.
Show Cable Reaction Force Table	Displays the guy cable end forces for the selected load case. To change the load case for which the reaction is displayed, select from the drop-down list of the selection box at the top.
Show Section Force Graph Table	Displays graph of a member for a selected load case of a particular force type (Axial, Shear Y, Shear Z, etc.).The force type and member can be changed from a drop-down located just above the graph.
Show Analytical Node Table	Displays a table of nodes with coordinates for Analytical nodes. The table lists the node numbers and their coordinates
Show Analytical Member Table	Lists the Analytical members and their incidences, along with corresponding Physical member and member lengths.
Hide All Table	Hides all the tables that are displayed in the output pane.

Selection Group

The Selection Cursors Group contains various pointer types in addition to a filtering tool. The different pointers represent selection modes used to limit selections in the *Model View* by an object type.



Used to select nodes.



Used to select one-dimensional model entities that are part of the physical model.



Used to select one-dimensional model entities that are part of the analytical model.



Used to select panel entities.



Used to select ancillary entities.



Used to select an attachment.



Used to select feedlines.




Used to select guy cable entities.




Used to select mount.

Analysis Group



Performs analysis on the analytical model using the analysis methods selected for the Whole Model.

Windows Group



Model Explorer

The *Tower Model Explorer* is used to display all elements of the tower model in a folder tree interface on the left pane.

Properties

Used to view detailed information of respective items on the right pane.

Output

Geometry tables, analysis messages/warnings/errors, code check messages/warnings/errors, and design results will be displayed here.


Axis Group



It displays the true north relative to the tower. When the tower is given 0 deg bearing, the true north align with the Leg A..

Structural Properties Control

It is used to control the graphic display details included in the View pane. By selecting the **Apply Immediately** option in the drop-down window, any selections made will be updated as soon as they are selected. Otherwise, all changes will be applied once the **Apply** button has been selected. The color tab allows the user to vary the color of displayed structural elements such as members, supports, and appurtenances. The Label tab allows you to toggle the display of element labels in the View pane. The Scale tab allows you to control the relative size of graphic elements.



Structural Properties Control

The color tab allows you to vary the color of displayed structural elements such as members, supports, and appurtenances.

Change the Color of a Model Entity


1. Select the Structural Diagram pop-up dialog box from the View tab.
2. Select the Color tab in the dialog.
3. Select any color in the right column associated with the element you want to change. The colors can be selected either from the Custom tab, the Web (named colors) tab, or the System tab.
4. Select the **Apply** tool to update colors.

or

Select the **Apply Immediately** option to have all colors updated dynamically.

Use a Custom Color

1. When changing the color of a model entity as described above, select the Custom tab.
2. In any of the blank color spaces at the bottom of the dialog, right-click to open the Windows color picker dialog.



3. Use the color picker tool to select a hue and shade graphically.

or

Enter numerical values for Hue, Saturation, and Lumosity.

or


Enter numerical values for Red, Green, and Blue.

4. Select the **Add to Custom Colors** tool.

5. Select the new color that appears in the Custom colors grid.

6. Select the **OK** tool.

Label Tab



The Label tab allows you to toggle the display of element labels in the *View* pane.


Turn on Display Labels

1. Select the Structural Diagram pop-up dialog box from the View tab.
2. Select the Label tab in the dialog.
3. Select the box associated with any item label you want to be displayed.
4. Select the **Apply** tool to update labels.

or

5. Select the **Apply Immediately** option to have all colors updated dynamically.

Scale Tab



The Scale tab allows you to control the relative size of graphic elements.

Change Display Scale

1. Select the Structural Diagram pop-up dialog box from the View tab.
2. Select the Scale tab in the dialog.
3. Enter a numerical value ratio (scale units described).

or

Use the Up and Down arrows to step the scale factors by ten.

4. Select the **Apply** tool to update labels.

or

Select the **Apply Immediately** option to have all colors updated dynamically.

Design Color Tab

The screenshot shows the 'Design Results' dialog box with the 'Design Color' tab selected. The dialog has a title bar 'Design Results' and a close button. Below the title bar, there are several settings: 'Color Model By Design' (checkbox), 'Results Base' (dropdown set to 'Actual'), 'No of Result Bands' (dropdown set to '5'), 'Equal Divisions' (checkbox checked), and 'Max Ratio' (text field set to '100'). Below these settings is a table with 5 rows and 4 columns. The first column is an index (0-4), the second is a label, the third is a range, and the fourth is a color swatch with its RGB values. The table is as follows:

	0	Not Designed		244, 244, ...
1	0	25		0, 0, 255
2	25	50		0, 255, 255
3	50	75		255, 128, 0
4	75	100		255, 255, 0

Below the table is a tabbed interface with 'Color', 'Label', 'Scale', 'Design Color' (selected), and 'Select Member'. At the bottom are buttons for 'Apply', 'Apply Immediately' (checkbox), 'Color Config', 'View Mode', and a dropdown arrow.


Design Color Tab allows you to select different color codes depending upon the utilization ratio of the members. You can select the colors for a different range of ratios from the color palette. Once you select the color, click **Apply** or **Apply Immediately** to see the change in the model. This helps in understanding the utilization of the member.

Select Member Tab


The screenshot shows the 'Select Member' dialog box. It has a title bar and a close button. Below the title bar, there are five radio buttons and corresponding text fields: 'Member By ID' (selected, value '1'), 'Section' (value 'RB1-3/4'), 'Material' (value 'STEEL'), 'Member Type' (value 'Leg'), and 'Panels' (empty). Below these fields is a tabbed interface with 'Color', 'Label', 'Scale', 'Design Color', and 'Select Member' (selected). At the bottom are buttons for 'Apply', 'Apply Immediately' (checkbox), 'Color Config', 'View Mode', and a dropdown arrow labeled 'Section'.

Select Member Tab, displays the selected member, Section, Material, Member Type or Panel in the model depending upon your selection. To view a member, you must specify the Member ID. To view a Section, you must select the Section from the combo box. For Material, you must choose from the different material given from the combo box. For


Material type, you can choose from the options shown in the combo box. To view a specific panel, you must specify the Panel ID. The selection is displayed in the main model, as shown in Figure 102.




Selected Panel in the Main Model



This takes the snapshot of the model and saves it in the specified location.



Displays the load.



This is used to modify the tower geometry, at run time, as shown in the image below. You can modify Tower Name, Tower Base Elevation, and Bearing Angle. Once modified and applied, the program will update the tower geometry. For 0 degree bearing the True North will align with Leg


A. The Tower rotates in the clockwise direction with the positive bearing angle.

Tower Name	800124
Bearing Angle (degree)	330
Base Elevation (ft)	0

Apply

Active Load Case Group

This is used to display the active model and the active load case. Once the user chooses the active load cases from the combo box, the results tables automatically get updated corresponding to the active load case.


Tower
Settings ▼
Settings

Active
LoadCase ▼

Active
Scenario ▼


Active Model Whole Model ▼

Active Loadcase PLC 1 - SW ▼

Active LoadCase

Active Scenario

The active scenario option will show the last active scenario. You can see the listed scenarios in the combo but scenario will be active from the navigation tree.


Tower
Settings ▼
Settings

Active
LoadCase ▼


Active
Scenario ▼

Active Scenario Scenario1 ▼

Active Scenario

Results Tab

The result tab contains tools used to visualize results from the analysis on the model in the view pane. Here, you will be able to review member forces and displacements.









View Results Commands

The following commands are used to graphically display force and displacement results on the physical model. The results are shown to scale in wireframe, superimposed onto the current model view.

The current load case may be selected by using the drop-down list in the Results group. This list includes all Primary Load Cases and Load Combinations included prior to running the most recent analysis.

View Results commands

	The force along the local x-axis of the member.
Axial Force	
	The force along the local y-axis of the member.
Shear Y Force	
	The force along the local z-axis of the member.
Shear Z Force	
	The twisting moment about the local x-axis of the member.
Torsion	
	The bending moment about the local y-axis of the member (generally weak-axis bending).
Bending Moment Y	
	The bending moment about the local z-axis of the member (generally strong axis bending).
Bending Moment Z	




The deformed shape of the structure will be displayed.

Displacement

Member Design Tab

This page contains tools used for the design of individual members and member groups.

Note: Selecting the Member Design tab also selects the Design tab in the Tower Model Explorer pane.



Member Design Tab


Generate Design Groups

The program automatically generates the design groups based on member classes such as leg, bracing, horizontal, redundant and cross arms (torque-arms).

Perform Design


This command directs the application to perform member design checks for the entire tower structure.

In the Tower Model Explorer window under the Design tab, the Tower Design will be broken into the following three sections: Design Briefs, Design Groups, and Design results. Design Briefs includes three types of briefs which are Beam Briefs, Truss Briefs, and Guy Cable Briefs. When selected, a property window will have corresponding information to each brief in which the user can define or alter certain parameters for the design. The application will automatically create appropriate design briefs based on the selected loading criteria in the active scenario and assign them to members groups.



Tower Model Explorer for Member Design

Tower Model Explorer




Tower Model Explorer

The *Tower Model Explorer* is used to display all elements of your tower model in a folder tree interface that should be familiar to users of Windows. Here, users can quickly view all aspects of the model creation, analysis, and results. Using the model explorer to add, edit, or remove model elements is a fast and powerful way to use the application. The structure of the **Model** tab closely follows the typical workflow of model creation.

View User Settings


This section can be used to document user information, which can be included as part of the analysis report.



User Setting

View Project Information


Features of the tower are assigned through the tower wizard set-up from OpenTower. This page includes carrier information as well as site information. User can save this information for the reference and this will not be used in any calculations.



Project Information

View Tower Panels


Details of each section of the tower can be seen in **Geometry > Panels**. The Main model will also show the selected highlighted panel.



Tower Panel

View Supports


Expand **Supports** will list the assigned supports at the tower and anchor base. Clicking on the support will show the details of the supports in the property window on the right side of the view pane.



Supports

View Mount

Expand **Mounts** will list the assigned mounts at the tower. Clicking on the mount will show the details of the mounts in the property window on the right side of the view pane.




Mounts

View Antenna

Expand **Antennas** will list the assigned antenna at the tower. Clicking on the antenna will show the details of the antenna in the property window on the right side of the view pane. In the Antenna Information Data, depending upon the IsCFD property information, the EPA properties for no ice and ice are calculated. If the IsCFD property is true, the data for the EPA (for no ice and ice) is populated from the antenna database, else, it is calculated from the length, width, and height of the antenna. The calculation is refreshed, after load generation, when IsCFD is false.


Also, if IsCFD property is false and the appurtenance classification is not considered in the selected appurtenance configuration in the scenario, then the EPA values and weight for ice will not be updated in the property window.



Antenna

View Miscellaneous


Expand **Miscellaneous** will list the assigned miscellaneous at the tower. Clicking on the miscellaneous will show the details of the miscellaneous in the property window on the right side of the view pane.



Miscellaneous

View Linear Attachment


Expand **Linear Attachments** will list the assigned linear attachments at the tower. Clicking on the linear attachments will show the details of the linear attachments in the property window on the right side of the view pane.



Linear Attachment

View Feedlines


Expand **Feedlines** will list the assigned feedlines at the tower. Clicking on the feedlines will show the details of the feedlines in the property window on the right side of the view pane.



Feedlines

Library Page


Library Page contains three features, Truss Leg Library, User Provided Table (UPT) and SPC Custom Section which allows users to create various geometric configurations and are not present in the standard library. All these three features are described below.



Library Page

Truss Leg Library

This section allows users to create various geometric configurations of truss-legs that are commonly used on lattice structures. Truss-legs consists of three solid round legs that are connected to each other by solid round bracing members. They are a type of built-up section. Truss leg UI allows the user to input the section properties.



Truss Leg UI

The plan view and elevation view are shown in the Truss Leg UI, automatically updates to match the inputted data.

Section Name

Name used to represent a truss-leg section in the database.

Existing Section

Select from the existing sections listed in the combo box.

Save

Clicking this button saves the new section.

Copy

This button is only active for existing sections in the database or saved sections located within the respective folder. You will be directed to a new, active section window within the database which includes the copied data.

Cancel

No data is saved by clicking this button and returns you to the previous window.

Modify

Clicking this button copies the respective section into a new database called Modified Truss-Legs.

Basic Dimension

Section Length


Describes the total vertical length of the truss-leg section.

Face Width	Defines the center to center spacing of the legs along one face of the truss-leg section.
Top/Bottom Offset	The vertical distance from either the top or the bottom of the leg section to the working point where the first bay begins or ends, respectively. This will offset the outermost horizontal member, whether it's classified as a normal horizontal member or top or bottom girt
Bay Spacing	Defines the length, a diagonal member span, vertically. The total quantity of bays is determined from the section length, top/bottom offset and bay spacing. If the total number of bays does not equal a whole number, then an additional diagonal member is generated for the remaining length.
Type of Bracing	Choose from the drop-down selection of either Z, X or K-Right bracing.
Bracing Specification	Choose from the drop-down selection of either Smooth Ends or Cut Ends, Continuous Ends, Concentric at Center or Layered at Center.
Leg Section/Diagonal Section/Horizontal Section	Specify the Section and the Grade of steel. You can select the section and material grade, by double-clicking on this field. Section Profile Page will appear, and the user can input the required fields.
Top/Mid/Bottom Girt Section	Entering a value under one of these cells will replace the horizontal member at the respective location with the proper girt diameter. You can select the section and material grade, by double-clicking on this field. Section Profile Page will appear, and the user can input the required fields.
Top/Bottom K-Brace Section	Entering values in these sections will create two diagonals forming a V-shape which is connected to the closest horizontal member. These values are only active when offsets are applied. You can select the section and material grade, by double-clicking on this field. Section Profile Page will appear, and the user can input the required fields.
Steps Section	Steps are added to one face of the truss-legs and are included in area calculations. Steps are connected to the diagonals and legs in the middle of each bay. You can select the section and material grade, by double-clicking on this field. Section Profile Page will appear, and the user can input the required fields.
Flat Area Details	
AF face(in2)	This user input specifies the flat area that should be considered in determining the solidity ratio and the effective projected area of the truss-leg. This input applies to 0, 0.5, 1, 2, and 4 inches of ice.

AF Weight(K)	Weight accounting for flat members entered under Af (Face). This input applies to 0, 0.5,1,2, and 4 inches of ice.
Conn CaAa(in2)	Accounts for flat linear members extending the length of the truss-leg. This input applies to 0, 0.5,1,2, and 4 inches of ice.
Conn Weight(K)	Weight accounting for flat linear members entered under Conn CaAa. This input applies to 0, 0.5,1,2, and 4 inches of ice.
Truss Leg Features	This table lists the total quantity for bays, horizontals, girts, and k-braces. The value calculated for bays is the only cell in this table which does not need to be a whole number; this would signify that a smaller diagonal was generated for the section.
Area Properties	
Total Round Area($\sum Ar$) (in²)	Specifies the total calculated round area for one face of the truss-leg which is used to determine the effective projected area. This calculated value is only shown for 0 and 0.5 inches of ice.
Solidity Ratio(ϵ)	Specifies the solidity ratio for one face of the truss-leg as defined in TIA-222-G which is used to determine the effective projected area. This calculated value is only shown for 0 and 0.5 inches of ice.
Effective Area (EPAs)(in²)	Specifies the calculated value for the effective projected area along one face as defined in TIA-222-G. This calculated value is only shown for 0 and 0.5 inches of ice.
Equivalent Diameter(in)	The effective projected area of the lattice-leg is converted into an equivalent round member. This calculated value is used in determining the EPA along the face of a lattice structure.
Total Weight (K)	The calculated value for total weight.
Built-Up Properties	
AG (in2)	The calculated value for the total cross-sectional area of the three legs acting as a built-up member.
I(in4)	The calculated value for the moment of inertia of the 3 legs acting as a built-up member.
R (in)	The calculated value for the radius of gyration of the 3 legs acting as a built-up member.
Sx/Sz (in4)	The calculated value for the minimum section modulus (Sx or Sy) of the 3 legs acting as a built-up member.


Zx/Zz (in4)

The calculated value for the minimum plastic section modulus (Zx or Zy) of the 3 legs acting as a built-up member.



Import

You can import a section by clicking this button. A dialog box will open as shown in Fig. 117, where users can select from the listed sections, or else can **Select ALL** the sections to import all the listed sections and click **Import**.



Import Section

Export


You can also export the section to the database. Just like Import, a window will open to select the existing section to be exported.

User Provided Table (UPT)

The User Provided Table (UPT) allows you to create a new section that is specific to the tower and local data of an OpenTower input file. You can add different sections, materials, both discrete and linear appurtenances, mount, bolt size, bolt material, and guy cable using UPT.



You must click on the UPT button to create or edit a UPT table.

The image shows the 'User Provided Table' window. It has a tabbed interface with 'Section' selected. The 'Section Type' dropdown is set to 'Single Angle'. The 'Input Parameter' table shows: Section Name (Add New Section), Height(D) (in) (2), Width(B) (in) (2), and Thickness(T) (in) (0.25). To the right is a 3D model of an L-shaped section. The 'Output Parameter' section shows 'Common Properties' with A (in²) = 0.9375, and 'Elastic Properties' with A (in²) and Cross Sectional Area. A 'Save to UPT' button is at the bottom right of the output section. The 'Section Details' section has a header with 'SectionName', 'Height (in)', 'Width (in)', and 'Thickness (in)', and a table body with one empty row. A 'Cancel' button and an 'OK' button are at the bottom right of the window.

Section Type	
Select Section Type	Single Angle

Input Parameter	
Section Name	Add New Section
Height(D) (in)	2
Width(B) (in)	2
Thickness(T) (in)	0.25

Output Parameter	
Common Properties	A (in²) 0.9375
Elastic Properties	A (in²)
Cross Sectional Area	

Section Details..			
Drag a column here to group by this column.			
SectionName	Height (in)	Width (in)	Thickness (in)

UPT Graphical Interface


Creating/ Updating UPT Section

You can add different sections that are specific to the tower and not part of the standard database.

There are two groups of properties for each Section Type. Input Parameters are the necessary user inputs to enable additional auto-calculated values which will be shown in the Output Parameter. The user inputs vary depending on the section type being created. Output parameters are automatically calculated properties based on section type and property inputs. These values are used for analysis and for graphical section profile generation. Refer Fig. 118

To create a new UPT section or edit an existing section, follow the following steps.

1. Choose a Section Type from the drop-down list (Fig. 119)..
2. Enter the input values in the respective input fields.
3. All input fields with default values will be shown in the input parameters grid. Review and edit all relevant input fields and specify a unique name for the section type. The application will automatically check for any duplicate section name and display a message, "Section name already exists, Do you want to overwrite it?".
4. All calculated values will be automatically populated in the output parameter grid, depending upon the input.
5. To apply the changes, click the **Save to UPT** button. A message box will confirm, with the message, "UPT Section Data Updated Successfully".
6. You can check the data that got saved, by selecting the section type. The Section Details group will list all the sections that got added under the selected section type.
7. If you want to edit the data, you must double click on the selected row of the Section Details table. It will automatically fetch all properties and display in the input and output parameters grid. You can then modify any or all input data. After clicking **Save to UPT**, the changes will be saved while prompting the user to whether overwrite the data or not.
8. To save this in the database, you must click the OK button.



Section Type

Creating/ Updating UPT Material

To create a new UPT material or to update an existing section, one can follow the steps as given below. Refer Fig. 120.

1. Enter the inputs in the text boxes to add new material.
2. All input fields with default values will be shown in Material Grade Details. Review and edit all relevant input fields and specify a unique name for the material. The application will automatically check for any duplicate name and display a message, "Material name already exists, Do you want to overwrite it?".
3. To apply the changes, click on the **Save to UPT** button. A message box will confirm, with the message, "UPT Material Data Updated Successfully".
4. You can check the data that got saved, by double-clicking on the relevant Material grade from the Material Grade Details grid. It will automatically fetch all relevant properties and display them in the Material Grade Details. You can then modify any or all input. After clicking **Save to UPT**, the changes will be saved while prompting the user to whether overwrite the data or not.
5. To save this in the database, you must click the OK button.

User Provided Table

Section: Material | Discrete | Linear | Mount | Bolt Size | Bolt Material | Guy Cable

Material Grade Details..

Material Name: Add New

Yield Stress(Fy): 36 ksi

Ultimate Tensile Stress (Fu): 58 ksi

Shear Modulus (G): 11200 ksi

Young Modulus (E): 29000 ksi

Poisson Ratio: 0.3

Alpha: 1E-05 fahrenheit

Density ρ : 490 pcf

Save to UPT

Material Grade Details..

No data to display

Cancel OK

Add/Update UPT Material

Creating/ Updating UPT Discrete Appurtenance

To create a new UPT discrete appurtenance or to update an existing one, one can follow the steps as given below. Refer Fig. 122.

1. Choose the Appurtenance type from the drop-down list (Fig. 121).
2. Enter the inputs in the text boxes.
3. Add all the relevant input for the appurtenance type in the discrete appurtenance details section. The manufacturer and the model name combination should be unique, else you will be notified with a message that the “Manufacturer name with the same Model already exists, DO you want to overwrite it?”.
4. To apply the changes, click **Save to UPT**. A message box will confirm, with the message, “UPT Discrete Appurtenance Updated Successfully”.
5. You can check the data that got saved, by selecting the Appurtenance type. The discrete appurtenance details group will list all the appurtenance that got added under the selected type.
6. If you want to edit the data, you must double click on the selected row of the appurtenance Details table. It will automatically fetch and display relevant properties in the general input and the appurtenance properties. you can then modify any or all input data. After clicking **Save to UPT**, the changes will be saved while prompting the user to whether overwrite the data or not.
7. To save this in the database, you must click the OK button.

User Provided Data

Section Material Discrete Linear Mount Bolt Size Bolt Material Guy Cable

Type Of Discrete Appurtenance

Select Appurtenance Type : Dish

Discrete Appurtenance Details...

General

Manufacturer AA

Model 2ws

SubType Paraboloid w/o Radome

Force Coefficient Dish w/o Radome

Weight (lbf) : 2

Appurtenance Properties

Drag a column here to group by this column.

	No Ice	1/2" Ice	1" Ice	2" Ice	4" Ice
Aperture Area(ft ²)	0.0218	0.0491	0.0873	0.1963	0.5454
Side Area(ft ²)	N/A	N/A	N/A	N/A	N/A
Weight(lbf)	2	2.589	3.338	5.3156	11.19

Save to UPT

Cancel OK

UPT Discrete Appurtenance Type

User Provided Table

Section Material Discrete Linear Mount Bolt Size Bolt Material Guy Cable

Type Of Discrete Appurtenance
Select Appurtenance Type : Flat Panel

Discrete Appurtenance Details..

General

Manufacturer

Model

SubType Paraboloid w/o Radome

Force Coefficient Flat

Dimension Details

Height(in)

Width(in)

Depth(in)

Weight (lbf)

Appurtenance Properties

Drag a column here to group by this column.

	No Ice	1/2" Ice	1" Ice	2" Ice	4" Ice
Front Area(ft ²)	0	0	0	0	0
Side Area(ft ²)	0	0	0	0	0
Top Area(ft ²)	0	0	0	0	0
Weight(lbf)	0	0	0	0	0

Diagram illustrating the dimensions of a rectangular structure:

Discrete Appurtenance Table

Drag a column here to group by this column.

AppurtenanceName	Manufacturer	Model	Version	Height...	Width...	Depth...	Front...	Front...	Front...	Front...	Side Ar...	Side Ar...	Side Ar...	Side Ar...	Top Ar...	Top Ar...	Top Ar...	Top Ar...	Top Ar...	Top Ar...	Top Ar...	Top Ar...

Save to UPT

Cancel OK

UPT Discrete Appurtenance

Creating/ Updating UPT Linear Appurtenance and Linear Attachment

To create a new UPT Linear appurtenance/attachment or to update an existing one, one can follow the steps as given below. Refer Fig. 124.

1. Choose the Appurtenance type/Attachment Type from the drop-down list (Fig. 123).
2. Add all the relevant input for the appurtenance type in the linear appurtenance details section. The manufacturer and the model name combination should be unique, else you will be notified with a message that the “Manufacturer name with the same Model already exists, Do you want to overwrite it?”.
3. Appurtenance properties will be automatically calculated depending upon the input.
4. To apply the changes, click the **Save to UPT** Button. A message box will confirm, with the message, “UPT Linear Appurtenance Updated Successfully”.
5. You can check the data that got saved, by selecting the Appurtenance type. The linear appurtenance table will list all the appurtenance that got added under the selected type.
6. If you want to edit the data, you must double click on the selected row of the appurtenance table. It will automatically fetch all relevant data and display in the general input and the appurtenance properties, you can modify the input data. After clicking **Save to UPT**, the changes will be saved while prompting the user to whether overwrite the data or not.
7. To save this in the database, you must click the OK button.

Type Of Linear Appurtenance

Select Linear Appurtenance/Attachment Type :

- Feed Line or Uniform Linear Appurtenance
- Feed Line or Uniform Linear Appurtenance
- Continuous Attachment
- Interval Attachment

Linear Appurtenance Details...

General

Manufacturer :

Model :

Type : Fiber

Force Coefficient : Round

Dimension Details

Depth (in) :

Width (in) :

Weight (lb/ft) :

Nominal Size (in) :

Appurtenance Properties

Drag a column here to group by this column.

	No Ice	1/2" Ice	1" Ice	2" Ice	4" Ice
Front Area(ft ² /ft)	0	0.0833	0.1667	0.3333	0.6667
Side Area(ft ² /ft)	0	0.0833	0.1667	0.3333	0.6667
Weight(lb/ft)	0	0.3054	1.2217	4.8869	19.5477

Diagram: A diagram of an oval with 'Depth' and 'Width' dimensions labeled.

Appurtenance/Attachment Type

User Provided Table

Section Material Discrete Linear Mount Bolt Size Bolt Material Guy Cable

Mount Tag

Manufacturer : Mounts

Model : SM001

Mount Type : Sector Mount


Mount Dimensions

Mount Height, ft : 5

Mount Width, ft : 10

Standoff Length : 4

Dynamic Image



Mount Properties

Drag a column here to group by this column.

Ice Thickness, in	No Ice	1/2" Ice	1" Ice	2" Ice
EpAn,ft2	2.5	2.8	3	3.8
EpAt,ft2	1.2	2.1	2.9	3.2
Weight,lbs	40	48	62	71

Save to UPT

Mount Table

Drag a column here to group by this column.

Manufacturer	Model	Type	Height	Width	Standoff
Mounts	TA01	T-Arm	0	12.5	12
Mounts	SO01	Standoff (2 a...	12	0	12
Mounts	STM01	Star Mount	12	0	12
Mounts	LP01	Platform (3-...	0	14.5	0
Mounts	SM001	Sector Mount	5	10	4

Cancel OK

UPT Mount

Creating/ Updating UPT Bolt Size

To create a new UPT bolt size or to update an existing one, follow the steps as given below.
Refer Fig. 126.

1. Add all the relevant input in the bolt details and material details section. The Name should be unique.
2. To apply the changes, click **Save to UPT** button. A message box will confirm, with the message, "UPT Material Bolt Data saved successfully".
3. You can check the data that got saved, under the Bolt table. A new row will be added with the input data.
4. If you want to edit the data, you must double click on the selected row of the bolt table. It will automatically fetch all relevant data and display those in the bolt details section. After clicking **Save to UPT**, the changes will be saved while prompting the user to whether overwrite the data or not.
5. To save this in the database, you must click the OK button.

UPT Bolt Size

Creating/ Updating UPT Bolt Material

To create a new UPT bolt material or to update an existing one, follow the steps as given below.
Refer Fig. 127.

1. Add all the relevant input in the bolt details and material details section. Add a unique name for the Material.
2. To apply the changes, click **Save to UPT** button. A message box will confirm, with the message, "UPT Material Bolt Data saved successfully".
3. You can check the data that got saved, under the Bolt table. A new row will be added with the input data.
4. If you want to edit the data, you must double click on the selected row of the bolt table. It will automatically fetch all relevant data and display those in the material details section. After clicking **Save to UPT**, the changes will be saved while prompting the user to whether overwrite the data or not.
5. To save this in the database, you must click the OK button.

UPT Bolt Material

Creating/ Updating UPT Guy Cable

To create a new UPT Guy Cable or to update an existing one, follow the steps as given below.
Refer Fig. 128.

1. Add all the relevant input in the Guy Wire Details. Add a unique name for the Guy Cable.
2. To apply the changes, click **Save to UPT** button. A message box will confirm, with the message, "UPT Guy Wire Data saved successfully".
3. You can check the data that got saved, under the Guy Wire table. A new row will be added with the input data.
4. If you want to edit any data, you must double click on the selected row of the Guy Wire table. It will automatically fetch all selected data and display those in the Guy Wire details section. After clicking **Save to UPT**, the changes will be saved while prompting the user to whether overwrite the data or not.
5. To save this in the database, you must click the OK button.

Guy cable information is unique as the Type, Size, and Breaking Strength are all correlated with one another.

User Provided Table

Section Material Discrete Linear Mount Bolt Size Bolt Material **Guy Cable**

Guy Wires Details..

Type	EHS	
Name	Add New	
Diameter	0	in
Area	0	in ²
Breaking Strength	0	kip
E	21000	ksi
Linear Weight	0	plf
Alpha	6.5E-06	/F

Save to UPT

Guy Wire Table..

No data to display

Cancel OK

UPT Guy Cable

SPC Custom Section

This feature is used to add sections in the custom catalog or database that are not part of the standard shapes and sections. New custom and built-up sections are added here parametrically, and the program will automatically generate section profiles to display those sections correctly. The custom catalog database can be installed separately. Once you click the SPC Custom Section from Library, the following dialog box appears.

Custom Tower DB Interface

Choose Catalog

Select Catalog

CustomTower_1.0.0.1

Country:

United States

New Record

Select Section Type

Single Angle

Section Name

Height(D) (in)

2


Width(B) (in)

3

Thickness(T) (in)

0.25

Section Name



Bulk Insert from Excel

Add New Record

☒ Clear Before Insert

Custom Catalog Database

	Designation	DisplayName	W (lb/ft)	A (in ²)	d (in)	b (in)	t (in)	kdes (in)
▶	Test4	Test4	3.944	1.16	2	4	0.2	0
	Test5	Test5	2.686	0.79	3	5	0.1	0

Cancel

Save To DB

Custom Tower DB Interface

Choose Catalog


Select the customized database for the section.

Country

Select the country. By default, the United States is selected.

Select Section Type

Select the section type, that you want to add in the database from the options given as shown below.




Add new Section in Database

You must input all the input parameters specific to different section types and click **Add New Record** button. Click **Save to DB** button to save it in the database. The section data will get saved in the custom catalog database and can be viewed in the table below. The dynamic image shows the graphical representation of the input data and changes with the input.

Bulk Insert from Excel


If you want to input multiple entries of a section type, you can do it by entering the input in an excel file. You must click the **Bulk Insert from Excel** button, which will open a dialog box as shown in Fig.130.



Custom Tower DB Interface

While entering the input data in excel, you must first enter the input parameter name in the first row. If you keep the input parameter name as same as the name used in the custom catalog UI, the application will automatically map the name and the values. If the parameter names vary, you must map the name with the excel column header selecting from the dropdown list. In the Fig.130, the section name parameter is different from the excel header column. Click **Save to DB** button to save it in the database. The section data will get saved in the custom catalog database and can be viewed in the table below. The newly added custom section will be accessible from the section profile page after you close the application and reopen the application

Edit Config



This feature allows you to configure different databases and XML for different types of bracings that are used in the application. The application comes with default XML and database. However, if you want to use different configuration file you can do it after going through the validation check.

By default, the configuration and the XML files are linked to the application.

Edit Config

Parameter Catalog Data

Configuration XML

Bracing Configuration

Default Configuration

Description

It shows the section database used by the application, for Standard Sections, and for Customized Section. The default Standard Catalog version is 3.1.4.2.

Used to configure the bracing xml pattern.

Used to configure the default sections that are used in the application

Connection Configuration

Used to configure connections



Hip Bracing Configuration

Used to configure hip bracing pattern and geometry

Database Configuration


Used to configure databases for Antenna, Guy, Mount, Truss Leg and Miscellaneous.

The xml and the databases are installed at the time of installation, if you want to change the path or use a different configuration file, you must first browse the path by clicking the 3-dotted button and must click **Validate** button, which checks whether the xml or the databases are in

the desired format. If the configuration file is an appropriate one,  sign confirms it. Else  sign prompts the user that the xml is not appropriate. Click Ok. You will be prompted to restart the application to start using the updated configuration settings.


Tower Profile Page

Tower Profile Page gives a snapshot of important details of the current tower model, including the graphical 3D view of the Tower, Tower Summary reaction, Loading Details, Section Details, and Geometry Details, as shown in Fig. 133. To view the tower profile page, you must use Firefox or Google Chrome.

To view the Tower profile page, you must click the Tower icon  on the top-left corner. Select **Open Tower Profile** from the Pop-up menu.



on the top-left corner.



File menu

Top Elev. 170.50 #

Top Elev. 128.13 #

Top Elev. 86.50 #

Top Elev. 45.63 #

Base Elev. 0.00 #



TOWER DESIGN NOTES

1. Tower is located in Houston, TX, Orange
2. Tower is designed for exposure C, structure class II and topographic category 1 with mean height 170.
3. Tower is designed for 100 mph basic wind in accordance with the ASCE 7-10 (ASCE 7-10 Standard).
4. Tower is also designed for 100 mph basic wind with 0.5 ft/sec. It is considered to increase in thickness with height.
5. Reflections are based upon 100 mph basic wind speed.
6. Tower structural rating: 45.47%.
7. Tower Weight: 17.00 kips.

SECTION DETAILS

Section	Location	Top Elevation (ft)	Bottom Elevation (ft)	Section Length (ft)	Section Type	Section Area (sq ft)	Section Weight (kips)	Section Rating	Section Weight (kips)
1	170.50 to 128.13	170.50	128.13	42.37	1.00	1.00	1.00	1.00	1.00
2	128.13 to 86.50	128.13	86.50	41.63	1.00	1.00	1.00	1.00	1.00
3	86.50 to 45.63	86.50	45.63	40.87	1.00	1.00	1.00	1.00	1.00
4	45.63 to 0.00	45.63	0.00	45.63	1.00	1.00	1.00	1.00	1.00

I

Member No.	Material	No. of Members	Member Description	Member Weight	No. of Joints	Member Weight
1	170.50	1	170.50 to 128.13	1.00	1	1.00
2	128.13	1	128.13 to 86.50	1.00	1	1.00
3	86.50	1	86.50 to 45.63	1.00	1	1.00
4	45.63	1	45.63 to 0.00	1.00	1	1.00
5	170.50	1	170.50 to 128.13	1.00	1	1.00
6	128.13	1	128.13 to 86.50	1.00	1	1.00
7	86.50	1	86.50 to 45.63	1.00	1	1.00
8	45.63	1	45.63 to 0.00	1.00	1	1.00
9	170.50	1	170.50 to 128.13	1.00	1	1.00
10	128.13	1	128.13 to 86.50	1.00	1	1.00
11	86.50	1	86.50 to 45.63	1.00	1	1.00
12	45.63	1	45.63 to 0.00	1.00	1	1.00
13	170.50	1	170.50 to 128.13	1.00	1	1.00
14	128.13	1	128.13 to 86.50	1.00	1	1.00
15	86.50	1	86.50 to 45.63	1.00	1	1.00
16	45.63	1	45.63 to 0.00	1.00	1	1.00
17	170.50	1	170.50 to 128.13	1.00	1	1.00
18	128.13	1	128.13 to 86.50	1.00	1	1.00
19	86.50	1	86.50 to 45.63	1.00	1	1.00
20	45.63	1	45.63 to 0.00	1.00	1	1.00
21	170.50	1	170.50 to 128.13	1.00	1	1.00
22	128.13	1	128.13 to 86.50	1.00	1	1.00
23	86.50	1	86.50 to 45.63	1.00	1	1.00
24	45.63	1	45.63 to 0.00	1.00	1	1.00
25	170.50	1	170.50 to 128.13	1.00	1	1.00
26	128.13	1	128.13 to 86.50	1.00	1	1.00
27	86.50	1	86.50 to 45.63	1.00	1	1.00
28	45.63	1	45.63 to 0.00	1.00	1	1.00
29	170.50	1	170.50 to 128.13	1.00	1	1.00
30	128.13	1	128.13 to 86.50	1.00	1	1.00
31	86.50	1	86.50 to 45.63	1.00	1	1.00
32	45.63	1	45.63 to 0.00	1.00	1	1.00
33	170.50	1	170.50 to 128.13	1.00	1	1.00
34	128.13	1	128.13 to 86.50	1.00	1	1.00
35	86.50	1	86.50 to 45.63	1.00	1	1.00
36	45.63	1	45.63 to 0.00	1.00	1	1.00
37	170.50	1	170.50 to 128.13	1.00	1	1.00
38	128.13	1	128.13 to 86.50	1.00	1	1.00
39	86.50	1	86.50 to 45.63	1.00	1	1.00
40	45.63	1	45.63 to 0.00	1.00	1	1.00
41	170.50	1	170.50 to 128.13	1.00	1	1.00
42	128.13	1	128.13 to 86.50	1.00	1	1.00
43	86.50	1	86.50 to 45.63	1.00	1	1.00
44	45.63	1	45.63 to 0.00	1.00	1	1.00
45	170.50	1	170.50 to 128.13	1.00	1	1.00
46	128.13	1	128.13 to 86.50	1.00	1	1.00
47	86.50	1	86.50 to 45.63	1.00	1	1.00
48	45.63	1	45.63 to 0.00	1.00	1	1.00
49	170.50	1	170.50 to 128.13	1.00	1	1.00
50	128.13	1	128.13 to 86.50	1.00	1	1.00
51	86.50	1	86.50 to 45.63	1.00	1	1.00
52	45.63	1	45.63 to 0.00	1.00	1	1.00
53	170.50	1	170.50 to 128.13	1.00	1	1.00
54	128.13	1	128.13 to 86.50	1.00	1	1.00
55	86.50	1	86.50 to 45.63	1.00	1	1.00
56	45.63	1	45.63 to 0.00	1.00	1	1.00
57	170.50	1	170.50 to 128.13	1.00	1	1.00
58	128.13	1	128.13 to 86.50	1.00	1	1.00
59	86.50	1	86.50 to 45.63	1.00	1	1.00
60	45.63	1	45.63 to 0.00	1.00	1	1.00
61	170.50	1	170.50 to 128.13	1.00	1	1.00
62	128.13	1	128.13 to 86.50	1.00	1	1.00
63	86.50	1	86.50 to 45.63	1.00	1	1.00
64	45.63	1	45.63 to 0.00	1.00	1	1.00
65	170.50	1	170.50 to 128.13	1.00	1	1.00
66	128.13	1	128.13 to 86.50	1.00	1	1.00
67	86.50	1	86.50 to 45.63	1.00	1	1.00
68	45.63	1	45.63 to 0.00	1.00	1	1.00
69	170.50	1	170.50 to 128.13	1.00	1	1.00
70	128.13	1	128.13 to 86.50	1.00	1	1.00
71	86.50	1	86.50 to 45.63	1.00	1	1.00
72	45.63	1	45.63 to 0.00	1.00	1	1.00
73	170.50	1	170.50 to 128.13	1.00	1	1.00
74	128.13	1	128.13 to 86.50	1.00	1	1.00
75	86.50	1	86.50 to 45.63	1.00	1	1.00
76	45.63	1	45.63 to 0.00	1.00	1	1.00
77	170.50	1	170.50 to 128.13	1.00	1	1.00
78	128.13	1	128.13 to 86.50	1.00	1	1.00
79	86.50	1	86.50 to 45.63	1.00	1	1.00
80	45.63	1	45.63 to 0.00	1.00	1	1.00
81	170.50	1	170.50 to 128.13	1.00	1	1.00
82	128.13	1	128.13 to 86.50	1.00	1	1.00
83	86.50	1	86.50 to 45.63	1.00	1	1.00
84	45.63	1	45.63 to 0.00	1.00	1	1.00
85	170.50	1	170.50 to 128.13	1.00	1	1.00
86	128.13	1	128.13 to 86.50	1.00	1	1.00
87	86.50	1	86.50 to 45.63	1.00	1	1.00
88	45.63	1	45.63 to 0.00	1.00	1	1.00
89	170.50	1	170.50 to 128.13	1.00	1	1.00
90	128.13	1	128.13 to 86.50	1.00	1	1.00
91	86.50	1	86.50 to 45.63	1.00	1	1.00
92	45.63	1	45.63 to 0.00	1.00	1	1.00
93	170.50	1	170.50 to 128.13	1.00	1	1.00
94	128.13	1	128.13 to 86.50	1.00	1	1.00
95	86.50	1	86.50 to 45.63	1.00	1	1.00
96	45.63	1	45.63 to 0.00	1.00	1	1.00
97	170.50	1	170.50 to 128.13	1.00	1	1.00
98	128.13	1	128.13 to 86.50	1.00	1	1.00
99	86.50	1	86.50 to 45.63	1.00	1	1.00
100	45.63	1	45.63 to 0.00	1.00	1	1.00

SECTION DETAILS

Section	Location	Section Length (ft)	Section Area (sq ft)	Section Weight (kips)
1	170.50 to 128.13	42.37	1.00	1.00
2	128.13 to 86.50	41.63	1.00	1.00
3	86.50 to 45.63	40.87	1.00	1.00
4	45.63 to 0.00	45.63	1.00	1.00



Bentley Systems, Inc.
10000 North Central Expressway
Suite 1000
Houston, Texas 77060

Job: 170.50

Project: 170.50 - Tower 170.50

Drawn: 170.50

Check: 170.50

Scale: 170.50


Drawn: 170.50

Check: 170.50

Scale: 170.50

Scale: 170.50

Examples Descriptions


A short description of the example models is compiled and shipped with the program. To know more about the example models, you must click the icon  **Learn more about examples**, from the file menu as shown in Fig.132, which will open the pdf file, listing different examples with short descriptions.

Bentley Cloud Services

OpenTower is a CONNECT product. It means you can associate your models with ProjectWise Projects from within the application usage per project. You must sign in with your Bentley CONNECT account. The Bentley CONNECTION Client is used to sign in and the status is displayed in the user icon in the top-right corner of the application window.

The Bentley Cloud Services, ribbon tab contains ProjectWise Project features and links to cloud portals. This is used to manage ProjectWise Projects and CONNECT Portals.

Once you start a new OpenTower project model or open an existing model that is not yet associated with a ProjectWise Project, you will be prompted to assign a ProjectWise Project to your file. A list of all registered projects in the organization is displayed. You can also register new projects (Only users with Admin/Co-admin roles can register a project). OpenTower will display the ProjectWise Project name in the window title bar.



Bentley Cloud Services

Associate	Used to associate the user’s model with a ProjectWise Project.
Disassociate	Used to disassociate a user’s model with the current ProjectWise Project. If you want to change the associated ProjectWise Project, you do not need to first disassociate the model first.
Personal	Opens the CONNECT Personal Portal in the user’s web browser.
Project	Opens the Project Portal for the ProjectWise Project.

To Associate a ProjectWise Project with Your File

When you create a new file or open an existing file that is not associated with a project, use the following procedure to associate the file with a ProjectWise project.

Note: You must be signed in using the CONNECTION client to associate a ProjectWise project with the file.

Tip: If you want to change the ProjectWise project associated with the file, use the following procedure.

1. On the Bentley Cloud Services ribbon tab, select the Associate tool in the Projects group. The Choose Project dialog opens.
2. (Optional) If you want to register a new project, do the following:

- a. Click Register Project. The Register a Project page opens in your browser.

Note: Only users with Admin/Co-admin roles can register a project.


- b. Type or select the required items (marked with an asterisk, "*")
- c. Click Save. A list of registered projects within your organization opens. The newly created project is highlighted in green.

Tip: Alternatively, you can visit connect.bentley.com and select +New on the Recent Projects tile on your personal dashboard.

3. Select the desired project from the list.

Tip: Use the View controls and Search tool to locate your project.

4. Click Associate.



Connect Project Chooser

To Disassociate a ProjectWise Project from a File

When you need to disassociate a file from a ProjectWise project, use the following procedure.

Tip: If you want to change the ProjectWise project association to another ProjectWise project, this procedure is not necessary.

On the Bentley Cloud Services ribbon tab, select the Dissociate tool in the Projects group. The project association is removed from the file.

OpenTower Analysis & Analysis Control Parameters

The document introduces the analysis methods used in OpenTower. For each type of analysis, the methodology is illustrated and then the analysis control parameters are explained.

Self-supported towers are analyzed with either Linear Analysis or P-Delta Analysis. Guyed Towers are analyzed with Nonlinear Analysis.

1. Linear Analysis

TIA codes (such as TIA-222-H §3.5) specifies certain self-supported towers can be analyzed with Linear Analysis.

For linear analysis, the displacement is solved in one shot by the equation:

$$[K]\{u\} = \{F\}$$

where $[K]$ is the elastic stiffness matrix; $\{u\}$ is the to-be-solved displacement vector; and $\{F\}$ is the loading vector.

There is no control parameter for linear analysis.

2. P-Delta Analysis

Except for certain towers exempted by TIA codes (such as TIA-222-H §3.5), P-Delta effects are needed to be considered in the analysis. In STAADTower, such self-supported towers are analyzed with P-Delta Analysis.

2.1 Introduction of P-Delta Effects

P-Delta effects refer to the second-order effect associated with the lateral translational deformation of the members due to vertical loading. There are two types of P-Delta effects for members, $P-\Delta$ and $P-\delta$. As in Figure 2.1, $P-\Delta$ is associated with the displacement relative to member ends; $P-\delta$ is associated with the local deformation relative to the element chord.




Figure 2.1 P-Delta effects

2.2 Introduction of P-Delta Analysis Methods

The PDelta effects can be simulated with geometric stiffness $[K_g]$. The formulation of $[K_g]$ can take into account P-Δ effect, or P-δ effect, or both.

$[K_g]$ can be included into the stiffness matrix for the equilibrium equation:

$$\{[K] + [K_g]\}\{u\} = \{F\}$$

Because $[K_g]$ is dependent on element axial forces, and therefore dependent on the displacement vector $\{u\}$, the above equation is a nonlinear one. And it can not be solved in one shot, as in Linear Analysis. OpenTower provides two approaches for solving the questions, as named Iterative method, and Kg method.

2.3 Iterative Method

In this approach, the equation is rewritten as:

$$[K]\{u\} = \{F\} - [K_g]\{u\}$$

Iterations are executed to solve the equation:

- 1) In the first iteration, assume $\{u\} = \{0\}$.
- 2) Based on the current step $\{u\}_i$, calculate the $[K_g]_i$.
- 3) Compute the right-hand side $\{F\} - [K_g]_i\{u\}_i$. Use this to solve the equation and get the next step $\{u\}_{i+1}$.
- 4) Repeat steps 2-3.

There are two options to terminate the iterations. First, users can specify the number of iterations, and analysis will execute that certain number of iterations and terminate. Second, users can specify to check convergence. With a given tolerance ε , the analysis will check $|\{u\}_{i+1} - \{u\}_i| < \varepsilon$. Once it is satisfied, the iteration will be terminated.

2.4 Kg Method

In this approach, iterations are executed to solve the equation:

- 1) In the first iteration, assume $\{u\} = \{0\}$.
- 2) Based on the current step $\{u\}_i$, calculate the $[K_g]_i$. Add it up to the elastic stiffness $[K]$.
- 3) Solve the equation $\{[K] + [K_g]\}\{u\} = \{F\}$, to get $\{u\}_{i+1}$.
- 4) Repeat steps 2-3.

Users need to specify the number of iterations. The analysis will execute that certain number of iterations and terminate.

2.5 Control Parameters

- **Analysis Options:** There are three options to choose from.
 - **Large and Small Delta effect:** If this radio button is chosen, the “Iterative Method” is used to solve the nonlinear equation by P-Delta effect. As named, both P- Δ effect and P- δ effect are considered.
 - **Excluded Small Delta effect:** If this radio button is chosen, the “Iterative Method” is used to solve the nonlinear equation by P-Delta effect. As named, only the P- Δ effect is considered, and the P- δ effect is excluded.
 - **Include Geometric Stiffness:** If this radio button is chosen, the “Kg Method” is used to solve the nonlinear equation by P-Delta effect. Both P- Δ effect and P- δ effect are considered.

- **No. of Iteration:** This input number specifies the number of iterations. The analysis will run this certain number of iterations and then terminate. This input is used for both the “Iterative Method” and “Kg Method”. In other words, the input is applicable to all three options under “Analysis Options”.
- **Converge Check:** When this checkbox is checked, the analysis will check the convergence criteria to terminate the iterations, instead of running the certain number of iterations given by “No. of Iteration”. In other words, when this checkbox is checked, the input of “No. of Iteration” is ineffective; and vice versa. This convergence check approach is only applicable to the “Iterative Method”, which means it is only available to choose only when the selection in “Analysis Options” is either “Large and Small Delta effect” or “Exclude Small Delta effect”. It is not available when the selection is “Include Geometric Stiffness”. UI is also set in the same logic.
- **Max Number of Iterations:** The input specifies the max number of iterations to run when analysis checks converge to terminate iterations. The input is available only when the “Converge Check” checkbox is checked. The analysis will terminate when the converge is achieved or the number of iterations exceeds this input.
- **Displacement Tolerance:** The input specifies converge tolerance, in the unit of an inch. The input is available only when the “Converge Check” checkbox is checked. The analysis will pick the maximum value from the incremental solved displacement vector and compare it with this input. When the value is smaller than this tolerance input, the iteration is considered converged and terminated.

3. Nonlinear Analysis

For guyed towers, nonlinear static analysis is performed. The nonlinearity in the guyed towers are from:

- The highly geometric nonlinear of the guy cables;
- The P-Delta effect in all frame elements (i.e. legs, diagonals, etc.).

In the equilibrium equation:

$$\{[K] + [K_g]\}\{u\} = \{F\}$$

Both $[K]$ and $[K_g]$ are dependent on $\{u\}$. And the equation is a nonlinear one.

The analysis employs Full Newton method for solving nonlinear equations.

For guyed towers with a great number of tension-only members, two approaches are provided to assist the solution to converge.

To determining guy cables’ initial tensions, the procedure “Retention Guys to Initial Tension” is required, per users’ judgment.

3.1 Introduction of Newton Method

The Full Newton method runs with iterations and gets the solution by checking force equilibrium and displacement increment, as depicted in Figure 3.1. The running steps are:

- 1) The loading vector $\{\mathbf{P}\}$ is assembled. For the first iteration, define the unbalanced loading $\{\Delta\mathbf{P}\} = \{\mathbf{P}\}$, and displacement vector $\{\mathbf{u}\} = \{0\}$.
- 2) The stiffness matrix $[\mathbf{K}]$ is assembled. If any elements are performing nonlinearly, their element stiffness matrix will be determined based on their current nonlinear status.
- 3) The equation $[\mathbf{K}]\{\Delta\mathbf{u}\} = \{\Delta\mathbf{P}\}$ is solved to find out the incremental displacement $\{\Delta\mathbf{u}\}$.
- 4) The current displacement vector is calculated as $\{\mathbf{u}\} = \{\mathbf{u}\} + \{\Delta\mathbf{u}\}$. Use this newly calculated $\{\mathbf{u}\}$ to update all elements.
- 5) Based on the updated elements, calculate the element reaction $\{\mathbf{R}\}$.
- 6) Calculate the unbalanced loading $\{\Delta\mathbf{P}\} = \{\mathbf{P}\} - \{\mathbf{R}\}$.
- 7) Check convergence by comparing $|\{\Delta\mathbf{P}\}|/|\{\mathbf{P}\}|$ with ϵ , as well as $|\{\Delta\mathbf{u}\}|/|\{\mathbf{u}\}|$ with ϵ . If converge is achieved, the analysis is considered converged. Repeat steps 2-7 until converge is achieved or the maximum iteration number is reached.

Figure 3.2 demonstrates the solution process in a numerical presentation.




Figure 3.1 Flow chart of the nonlinear static solver with Full Newton method




Figure 3.2 Numerical present of the nonlinear static solver with Full Newton method

3.2 Introduction of Tension-Only Approaches

For guyed towers with tension-only members, such as TX diagonals, additional checking of the tension-only members' status is included in the analysis routine:

- In any an iteration, if a tension-only member has tensile deformation, it will be marked as "activated"; if a tension-only member has compressive deformation, it will be marked as "deactivated".
- In the next iteration, for a previously marked "deactivated" member, its stiffness (also force) will be set to zero. With such stiffness, the structure is solved again; and all tension-only members are marked again as "activated" or "deactivated".
- The iterative solution is considered converged only when all previously marked "activated" tension-only members are still in tensile deformation for the current iteration, and all previous marked "deactivated" tension-only members are still in compressive deformation for the current iteration. Please notice that the regular equilibrium check still needs to be satisfied.

For models with a great number of tension-only members, the solving process may face difficulty to get converged. Numerically, some tension-only members switch back and forth between "activated" to "deactivated" repeatedly. Physically, when many members are "deactivated", the structure's instability becomes sensitive.

Two approaches, i.e. Euler Buckling Tension Member method and Residual Stiffness Tension Member method, are provided to ease the analysis converge for models with tension-only members. In both approaches, additional strength or stiffness is added to the structure. Discretion is required to adopt the approaches and to verify the result correctness.

3.2.1 Euler Buckling Tension Member

This approach allows a “tension-only” member to take some compression force until it reaches the Euler Buckling critical force:

$$P_{cr} = \frac{\pi^2 EI}{(kL)^2}$$

Figure 3.3 depicts the axial force-deformation relation for original “tension-only” modeling and the “Euler Buckling tension member”.




Figure 3.3 Axial force-deformation constitutive relations

Compared to original “tension-only” modeling, this approach adds in additional compressive strength, capped by P_{cr} .

It is worth noticing that such modeling actually resembles better real physical performance. “Tension-only” is usually used for slender members. Such members have very small buckling strength and therefore the compressive capacity is ignored for modeling simplicity and also conservative concerns. Physically, such members can take compressive force. When the compressive force reaches the critical buckling force, the member buckles and the loading on it cannot increase (i.e. zero stiffness but some strength). When the compressive force decreases, the member returns to its elastic status. “Euler Buckling” modeling resembles the process more precisely than pure tension-only modeling.

3.2.2 Residual Stiffness Tension Member

This approach allows a “tension-only” member to take some compression force, but with a much smaller stiffness:

$$\alpha \cdot K$$

where α is a number between 0 and 1; and K is the elastic stiffness.

Figure 3.4 depicts the force-deformation relationships.




Figure 3.4 Axial force-deformation constitutive relations

Compared to the original “tension-only” member, an additional compression stiffness is added. Numerically, it helps the converge. Meanwhile, it is ideal to have a small α value, which means the behavior of the “Residual Stiffness” member is closer to the original “tension-only” member.

Similar to the original “tension-only” modeling, this “Residual Stiffness” modeling also does not precisely resemble the member’s real behavior. Further than that, it is possible that a “Residual Stiffness” member may undergo a compressive force even more than the Euler buckling force. But, as long as the α value is small, the chance is trivial.

3.3 Introduction of Retention Guys to Initial Tension Routine

A key modeling parameter of a guy cable element is its “tension under undeformed tower”, i.e. the cable’s two connection nodes have no displacement. This logic could be understood similarly as the prestressed beam/truss element. For a prestressed beam/truss element in a structure, users input its “prestressed strain”, which is the strain while the whole structure does not deform. When the structure deforms under a load case (such as SW), the prestressed beam/truss element will deform to a new strain. The guy cable element has same logic. As in

Figure 3.5a, we denote the “tension under undeformed tower” as “ T_0 ”. Under SW, the tower will deform, the guy cable tension will change to a different value, the “tension under deformed Tower”, denoted “ T ”, as in Figure 3.5b. Because the tower is shortened, “ T ” is generally smaller than “ T_0 ”.




Figure 3.5 Guy tension in undeformed model and deformed model

To define the guy cable’s tensioning condition, users input a tension value, which is called Initial Tension, denoted by “ T_i ”. It is usually 10% of the cable breaking strength.

Without the “Retention Guys to Initial Tension” routine, it indicates the input Initial Tension “ T_i ” is the “tension under undeformed tower” i.e. “ T_0 ”.

With the “Retention Guys to Initial Tension” routine, it requests the “tension under deformed tower”, i.e. “ T ”, equal to the Initial Tension “ T_i ”. Numerically, it asks the program to find a “ T_0 ” value, by using this “ T_0 ”, the tension under deformed structure is exactly or approximately this Initial Tension “ T_i ” value. Physically, it means that tower installation workers will keep tightening all guy cables during the tower erection, so at the end, each guy cable tension reaches its requested Initial Tension “ T_i ”.

In summary, with “Retention Guys to Initial Tension” option, it requests “ $T=T_i$ ”. Without that option, it means “ $T_0=T_i$ ”.

3.4 Control Parameters

Totally eight control parameters are exposed to users in the UI. They are related to the Newton method, P-Delta effect, Tension-Only handling, and Retention Guy Initial Tension routine respectively.

3.4.1 Related to Newton method

- **Number of increments (not available now but maybe activated later):** This parameter is used to divide the loading into small increments. It could be any positive integer number. If users are interested in load carrying capacity develop process under the loading, a larger than 1 number could be assigned to this parameter. Generally, a larger than 1 number could be beneficial for solution converge, as the loading is applied gradually.
- **Max Number of iterations:** This parameter is the maximum number of the iterations. During each loading increment, the analysis will iterate to find solution convergence. Once the iteration number reaches the maximum value, the analysis will be stopped even if the solution is not achieved. It could be any positive integer number. A smaller than enough number may prevent the solution to converge. However, if the model has some instability or unsolvable nonlinearity, a bigger number here may cost too much running time but still not able to achieve converge.
- **Converge tolerance:** When the computed error is equal or smaller than this threshold value, the nonlinear solver will stop iterating and consider the ongoing step as converged. A very small value may prevent the solution to be considered as converged. However, a very large value may result in inaccurate results.

3.4.2 Related to P-Delta effect

- **Include Geometric Stiffness:** When the checkbox is checked, the member geometric nonlinear P-Delta effects will be included in the analysis. Both $P-\Delta$ and $P-\delta$ effects are incorporated. The numerical approach employed is the “Kg” method, as explained previously in §2.1. The geometric stiffness matrix $[Kg]$ will be included in the stiffness matrix. Different from the Kg Method in “P-Delta Analysis” for SST, the force equilibrium is checked for convergence. For guyed towers, TIA codes (such as TIA-222-H §3.5) always require including $P-\Delta$ effect. Please notice, including P-Delta increases the complexities of convergence.

3.4.3 Related to Tension-only handling

- **Euler Buckling tension member:** When the checkbox is checked, the “Euler Buckling Tension Member” approach is enabled to assist converge for models with tension-only members. For models without any tension-only members, checking or not checking this checkbox does not make any difference. It is suggested to first try running the analysis without using either this “Euler Buckling Tension Member” approach or “Residual Stiffness Tension Member” approach. Increasing “Max Number of Iteration” or decreasing “Converge Tolerance” can be tried. The “Euler Buckling Tension Member” and “Residual Stiffness

Tension Member” approaches are suggested as the secondary methods. Please notice, when the checkbox is checked, the “Converge Tolerance” is automatically decreased to 1.0e-3, while the default value is 1.0e-6. This is to further assist converge.


- **Residual Stiffness tension member:** When the checkbox is checked, the “Residual Stiffness Tension Member” approach is enabled to assist converge for models with tension-only members. For models without any tension-only members, checking or not checking this checkbox does not make a difference. This checkbox and the “Euler Buckling tension member” checkbox can not be checked at the same time. In other words, only one of the “Euler Buckling Tension Member” approach and “Residual Stiffness Tension Member” approach can be activated; it is OK to not enable any of them; but it is not OK or allowed to enable both of them. Please notice, when the checkbox is checked, the “Converge Tolerance” is automatically decreased to 1.0e-3, while the default value is 1.0e-6. This is to further assist convergence.
- **Residual Stiffness ratio:** The input is used as the compression stiffness ratio for tension-only members, as depicted in Figure 3.4b. The input is enabled only when the “Residual Stiffness tension member” checkbox is checked.

3.4.4 Related to Retention Guys to Initial Tension routine

- **Retention Guys Initial Tension:** When this checkbox is checked, the “Retention to Guys Initial Tension” routine is performed. Otherwise, this routine is not performed. As explained in §3.3, when it is checked, it requires “ $T=T_i$ ”; when not checked, it means “ $T_0=T_i$ ”. By default, the checkbox is checked. For numerical reasons, the routine may only get to the solution approximately satisfying “ $T=T_i$ ”, but not exactly. The solution information can be found in the “*.LOGX” file.

Appendix

* **Bolt Pattern:** The different types of bolt patterns that are supported by OpenTower



























AISC Standard Gage: For angle bracing the gage is always assumed to be the standard AISC workable gage as shown in the table below

Angle Leg Depth:	8	7	6	5	4	3.5	3	2.5	2	1.75	1.5	1.375	1.25	1
AISC Standard Gage:	4.5	4	3.5	3	2.5	2	1.75	1.375	1.125	1	0.875	0.875	0.75	0.625




****Bracing Patterns:** The different types of bracing patterns that are supported by OpenTower

Face Bracing








			
X	CX, TX	Diagonal Up	Diagonal Down
			
Diagonal Up, Z Brace, M Brace	Diamond	K Brace Left	K Brace Right
			
K Brace Up, TK Brace Up	K Brace Down, TK Brace Down	K1 Up	K1 Down
			
K1B Down	K2 Up	K2 Down	K2A Down
			
K3 Up	K3A Down	K3A M Down	K4 Up
			
K4 Down	K4A Down	Portal	Cranked K

Plan Bracing

3-Leg Tower

 <p>Triangular 1</p>	 <p>Triangular 2</p>	 <p>Triangular 3</p>
---	---	---

4-Leg Tower

 <p>X Brace</p>	 <p>Diamond 1</p>	 <p>Diamond 1X</p>	 <p>Diamond 2</p>
 <p>Diamond 2X</p>	 <p>Diamond 3</p>	 <p>Diamond 3T</p>	

Hip Bracing

Applies to:
K1 Down, K1 Up, K1B
Down, Double K1, K3 Down,
K3 Up, K3A Down, Double
K3, Double K3A



H1



H1A

Applies to:
K2 Down, K2 Up, K2A
Down, Double K2, Double
K2A



H2



H2KD



H2Z



H2A

Applies to:
K3 Down, K3 Up, K3A
Down, Double K3, Double
K3A



H3



H3KD



H3Z



H3A

Applies to:
K4 Down, K4 Up, K4A
Down, Double K4, Double
K4A



H4



H4KD




H4Z





H4A

Torque-arm Bracing





Bearing Angle

Square Tower Orientation




Triangular Tower Orientation




Extreme Fiber SST Anchor Rods arrangement

- Bolt



- Bolts



New Features and Updates

Monopole Reinforcement and Connections

It's a new feature implemented for all the supported types of poles such as Tapered, Stepped, and Hybrid poles in OpenTower Designer. It has been implemented for all the TIA design standards (EIA/TIA-222-F, TIA-222-G, and TIA-222-H). The monopole reinforcement calculator is also added to allow user to create new reinforcement sections. To access Monopole reinforcement, go to the Section Detail page and navigate through the Reinforcement and Connection page.

Main Model

Section Detail

Tower Type: Monopole

Add Section

Remove Section

Input Method: Detailed

Preferred Section Dimension: Diameter (Flat-To-Flat)

Reinforcement

Connection

Pole Overview

Drag a column here to group by this column.

Section ID	Top Elevation (ft)	Bottom Elevation (ft)	Section Length (ft)	Connection	Design Lap Splice/Socket Length (ft)	Section Type	Section Profile	Taper Factor	Top Diameter (in)	Bottom Diameter (in)	Thickness (in)	Material	Required Lap Splice (ft)	Inside Bend Radius (in)
1	150.00	105.00	45.0000	LapSplice	3.5625	18	TT20x29x0.19x18	0.2000	20.0000	29.0000	0.1875	A572 Gr.65	3.5781	auto
2	108.56	63.56	45.0000	LapSplice	4.5359	18	TT27.91x36.91x...	0.2000	27.9125	36.9125	0.2500	A572 Gr.65	4.5516	auto
3	68.10	23.10	45.0000	LapSplice	5.4850	18	TT35.51x44.51x...	0.2000	35.5053	44.5053	0.3125	A572 Gr.65	5.4850	auto
4	28.58	0.00	28.5835	BasePlate	0.0000	18	TT42.78x48.5x0...	0.2000	42.7833	48.5000	0.3125	A572 Gr.65	0.0000	auto

Reinforcement

The Reinforcements table provides all the inputs needed to reinforce existing tower on monopoles. The columns of the table are explained. Depending upon the input provided, it will design the reinforcement and the modified pole using the properties. The elevation view will display the modifications on flattened view of the pole between two user defined elevations.

Parameter

Type

Specify the type for reinforcement. You must choose from Plate, Channel, Solid Rod, Bent Plate and Arbitrary (Other shapes)

Model

Specify the model. There is an existing database of different types of pole reinforcement models part of the application. User can review the existing database from the monopole reinforcement tab in the Library. User can also create the new pole reinforcements of plate, channel, solid rod, bent plates and arbitrary shapes using reinforcement calculator from the Library and save as UPT or update the existing database.

Description

**Actual Bottom
Elevation (ft)**

**Effective Bottom
Elevation (ft)**


**Actual Top
Elevation (ft)**

**Actual Bottom
Elevation (ft)**

Location

**Stand Off Distance
(in)**

Lateral Offset (in)




Specify the actual bottom elevation in ft.

Specify the effective bottom elevation in ft.

Specify the actual top elevation in ft.

Specify the actual bottom elevation in ft.

Specify the Flats/angle in degrees. Flats for polygonal shapes and angle in degrees for round poles. Flats are counted assuming the tip point of the Plan View pointing to the north specifies the first plate and clockwise the plate counts are incremented. Explained in the below figure.



Specify the standoff distance. It will move the plates out. It gives the offset.


Specify the lateral offset distance. It will shift the plate from the center of the flat to the center of the pole.

**Bottom End
Connection Bolt
Type**


Specify the Bottom End Connection Bolt Type

**Top End
Connection Bolt
Type**

Specify the Top End Connection Bolt Type



Existing Models of Reinforcement Database



Create New Models of Reinforcements

Monopole Reinforcement Calculator

Reinforcement: Test Type: Channel B_{Channel}: 4.06 in H_{Channel}: 1.05 in T_{Channel}: 0.375 in T_{Channel}: 0.375 in Channel_{InsideDepth}: 3.685 in

Material: A36 MaterialFy: 36 ksi MaterialFu: 58 ksi E: 29000 ksi G: 11200 ksi C1: 0.22 C2: 1.49

Tension Only: Yes L_u: 15 in EffectiveLengthFactorX: 1.0 EffectiveLengthFactorY: 1.0 BoltHoleSize: 1.1875 in

Bottom End Connection

Connection Type: Bolted Bolt Type: PC 8.8 - M20 (100) Threads Included: N No of Bolts: 6 Bolt Spacing: 3 in

Edge Distance: 2 in

Top End Connection

Connection Type: Bolted Bolt Type: PC 8.8 - M20 (100) Threads Included: N No of Bolts: 6 Bolt Spacing: 3 in

Edge Distance: 2 in

Top End Connection Same: Yes

Bolt Data

Name: Description:

Bolt Diameter: mm Sleeve Outer Diameter: in Bolt Fu: ksi

Bolt Diameter: in Sleeve Inner Diameter: in Sleeve Fu: ksi Bolt Shear: kip

Calculate

Common Data Rev. F Rev. G Rev. H

Reinforcement

Channel ID (in)	Channel J (in ⁴)	Channel CW (in ⁴)	Gross Area (in ²)	Pole Face to Centroid (in)	I _x (in ⁴)	r _x (in)	I _y (in ⁴)	r _y (in)	Net Area (in ²)	Bottom Connection Length and Edge Dist (in)	Top Connection Length and Edge Dist (in)
00644	0.0951	0.306	2.0288	0.3185	0.1419	0.2644	3.8159	1.3715	1.56	17	17

Bolt

Area of Bolt (in ²)	Sleeve Area (in ²)
0.4869	0.5324

Save as UPT Save to DB Cancel Save

Reinforcement Calculator

After adding the input, click Apply button to apply the changes. **View Selection** window shows the elevation view with different elevation of the Pole. The Reinforcement Details Table gets automatically populated depending upon the Model selection and its corresponding properties in the Reinforcements table and is non editable.

Reinforcements Interferences Reinforcement Details										
	Model	B (in)	H (in)	Gross Area (in ²)	Pole Face To Centroid (in)	Bottom Termination	Top Termination	Net Area (in ²)	Bolt Hole Size (in)	Reinforcement Material
1	CCI-WSFP-060100	6	1	6	0.5	0	24	4.75	1.1875	A572-65
2	CCI-SFP-065125	6.5	1.25	8.125	0.625	33	33	6.5625	1.1875	A572-65
3	CCI-SFP-060100	6	1	6	0.5	24	24	4.75	1.1875	A572-65
4	CCI-AFP-045100	4.5	1	4.5	0.5	24	24	3.25	1.1875	A572-65

Pole Modification

Mod Name: Mod 1 Description: Tower Sections Reinforced

Reinforcement Bolt & Stiffener

View Selection Elevation View Width Scale Factor: 2.5 Starting Flat: 1 Plan View

Top Elevation: 93.78 ft

Bot Elevation: 76.73 ft

Plan Elevation: 85.25 ft

Reinforcements Interferences Reinforcement Details

Type	Model	Bottom Elevation (ft)	Top Elevation (ft)	Location	Standoff Distance (in)	Lateral Offset (in)	Bottom End Connection Bolt Type	Top End Connection Bolt Type
1	Plate CCI-WSFP-060100	0	25	auto	15.79,11	0	-	PC 8.8 - M20 (100)
2	Plate CCI-SFP-065125	40.92	75.92	auto	1.5,9	0	PC 8.8 - M20 (100)	PC 8.8 - M20 (100)
3	Plate CCI-SFP-060100	82.5	112.5	auto	1.5,9	0	PC 8.8 - M20 (100)	PC 8.8 - M20 (100)
4	Plate CCI-AFP-045100	124.92	144.92	auto	2.6,10	0	PC 8.8 - M20 (100)	PC 8.8 - M20 (100)


Cancel Apply OK


The interferences table allows the user to add any miscellaneous components installed such as port holes or climbing pegs on the pole structure. These interferences are displayed in the elevation view, plan view and main 3-D model for user references while creating new modifications to the structure.

Parameter	Description
Description	The different type of interferences options given as Climbing Pegs, Safety Climb and Portholes.
Bottom Elevation	Bottom Elevation of the interference.
Top Elevation	Top Elevation of the interference.
Width	Width of the interference.
Location	Specify the plate/flat count as Location of the interference, as shown in the Plan View.

Once applied, the changes will be shown in the Elevation View. It will show the interferences in red and will help in understanding whether the reinforcements are defined in the location where the existing interferences are.

Once reinforcement defined, the application automatically considers the reinforcement plates for R_w and R_a factor calculations.





Pole Reinforcement

Pole Flange and Base plate Connections

The software has the capability to design connections on pole structures (such as Flange Plate and Base Plate). The user has the flexibility to choose different types of bolt, stiffener, and plate orientation.

Pole Connection Details

Additional Square BP Information				Additional Anchor Rod Information			
Clip Distance (in) :				Eta Factor :	0.5	Grout Considered : No ▾	
Anchor Rod Spacing (in) :				Lar (in) : 0			

TYPE 1


TYPE 2

TYPE 3

Plate Data										Bolt Data				Reaction Adjustment Factor		
Flange ID	Elevat...	Locat...	Type	Dia...	Thickn...	Material	Soffened	Plate Check	Qty	Bolt Circle (in)	Section Profile	Thread Type	Mo...	Axial	Shear	
1	0	Base Plate	Square	S8	2	A36	Yes	<input type="checkbox"/>	20	54	Z-A687_N	N-Included	1.0	1.0	1.0	

Plate Information										Weld Information			
Flange ID	Configuration	Clear Space (in)	Width (in)	Height (in)	Thickness (in)	H Notch (in)	V Notch (in)	Grade (ksi)	Weld Type	Groove Depth (in)	Groove Angle (deg)	H. Fillet Weld Size (in)	
1	1	-	5.75	8.5	0.75	0.25	0.25	A36M-...	Fillet	-	-	0.3125	


Flange Connections can be modeled as both exterior or interior. Also, stiffeners can be defined for both top and bottom at same location.




Pole Connection Details									
Additional Square BP Information								Anchor Rod Spacing (in):	
Clip Distance (in):		0		Eta Factor:		0.5			
Anchor Rod Spacing (in):		0							
				Plate Data					
F	Elevatio...	Location	Type	Dia...	Thic...	Mat...	Stiff...	Plate C...	
1	160	Top	Exterior	36	1.25	A36	Yes	<input type="checkbox"/>	
2	2	Bottom	Exterior	30	1.25	A36	No	<input type="checkbox"/>	
3	140	Top	Interior	42	1.25	A36	No	<input type="checkbox"/>	
4		Bottom	Interior	36	1.25	A36	No	<input type="checkbox"/>	
5	120	Top	Exterior	48	1.25	A36	No	<input type="checkbox"/>	

Flange Connection

Base plate can be modeled as both circle, square or interior and with or without stiffeners

 Pole Connection Details

Additional Square BP Information				Additional Ar	
Clip Distance (in) :		0		Eta Factor :	0.5
Anchor Rod Spacing (in) :		0		Lar (ir	


			Plate Data							
FI	Elevation...	Location	Type	Dia...	Thic...	Mat...	Stiff...	Plate C...	Qty	
	1	0	Base Plate	Circle	55	2.75	A633...	No	<input type="checkbox"/>	12

Circle

Circle

Square


Interior



The reinforcements and connections can also be added to the model as a part of the modification.

Shroud and Conduit

The user has a provision to use the Shroud or Conduit type of encasement for the feeders. This is achieved by creating a different type of continuous attachment from the UPT or include in the standard database. Both shroud and conduits are implemented for monopoles only.

 User Provided Table

Section Material Discrete Linear Mount Bolt Size Bolt Material Guy Cable

Type Of Linear Appurtenance

Select Linear Appurtenance/Attachment Type : Continuous Attachment

Linear Appurtenance Details...

General

Manufacturer :

Model :

Type: Feed Line Ladder Feed Line Ladder Climbing Ladder Shroud Conduit

Force Coefficient :

Dimension Details

Depth(in) (Graphical Only)

Width(ft) (Graphical Only)


Weight(lbf/ft)

Nominal Size (in) :

The feeders referring to the shroud attachment will be shielded from the wind load calculations and will be included in the Ra factor. Only the self-weight of those feedlines will be considered.

Also, the options include three different checkboxes to allow user to select the proper monopole force coefficient tables from TIA-222-H and also allows to verify if the reinforcements are effective or not.

Note: Rw factor logic is implemented based on addendum 1 of TIA-222-H. For round sections, any flats in the windward zone is considered fully effective in contribution to calculate Rw and Ra factors.

 Options

Select Member type for Moment:

Options

☐ TIA-222-H Consider Linear Attachment

☐ TIA-222-H Force Coefficient Reduction Based on Corner Radius Table 2-8 c

☐ Ineffective Mod Check

Select All

Cancel OK

Tower Profile Page - The Tower Profile page has been updated and includes the tower weight (for SST and monopoles) in tower notes, monopole reinforcement tables, and updates to the logo and address details.

[Top Elev. 280 ft](#)

[Top Elev. 260 ft](#)

[Top Elev. 240 ft](#)

[Top Elev. 220 ft](#)

[Top Elev. 210 ft](#)

[Top Elev. 200 ft](#)

[Top Elev. 190 ft](#)

[Top Elev. 180 ft](#)

[Top Elev. 170 ft](#)

[Top Elev. 160 ft](#)

[Top Elev. 150 ft](#)

[Top Elev. 140 ft](#)

[Top Elev. 130 ft](#)

[Top Elev. 120 ft](#)


[Top Elev. 110 ft](#)

[Top Elev. 100 ft](#)

[Top Elev. 80 ft](#)

[Top Elev. 60 ft](#)

[Top Elev. 40 ft](#)



3. Tower is designed for 115 mph basic wind in accordance with the TIA-222-G (ASCE 7-05 Wind Maps) Standard.
4. Tower is also designed for 60 mph basic wind with 0.75 in ice. Ice is considered to increase in thickness with height.
5. Deflections are based upon 115 mph service wind speed.
6. Tower structural rating : 132.2726%.

GEOMETRY DETAILS				
Panel ID	Panel Details	Face Bracing	Plan Bracing	Hip Bracing
1	TW 7 TH 20 No. of Bays 3	X Brace, Leg 1, DIA 2, TH 3		
2	TW 8.75 TH 20 No. of Bays 3	X Brace, Leg 4, DIA 5		
3	TW 10.5 TH 20 No. of Bays 2	K1 Down, Leg 6, DIA 43, H 9, RD 10, RH 8	EL 240 TRIANGULAR, 1, IB 8	
			EL 230 TRIANGULAR, 1, IB 8	
4	TW 12.25 TH 10 No. of Bays 1	K1 Down, Leg 11, DIA 44, H 13, RD 14, RH 10	EL 220 TRIANGULAR, 1, IB 8	
5	TW 13.12 TH 10 No. of Bays 1	K1 Down, Leg 11, DIA 44, H 13, RD 14, RH 10	EL 210 TRIANGULAR, 1, IB 8	
6	TW 14 TH 10 No. of Bays 1	K1 Down, Leg 15, DIA 44, H 17, RD 14, RH 10	EL 200 TRIANGULAR, 1, IB 15	
7	TW 14.88 TH 10 No. of Bays 1	K1 Down, Leg 15, DIA 44, H 17, RD 14, RH 10	EL 190 TRIANGULAR, 1, IB 15	
8	TW 15.75 TH 10 No. of Bays 1	K1 Down, Leg 18, DIA 44, H 17, RD 14, RH 14	EL 180 TRIANGULAR, 1, IB 15	
9	TW 16.62 TH 10 No. of Bays 1	K1 Down, Leg 18, DIA 44, H 17, RD 14, RH 14	EL 170 TRIANGULAR, 1, IB 15	
10	TW 17.5 TH 10 No. of Bays 1	K1 Down, Leg 19, DIA 44, H 21, RD 22, RH 10	EL 160 TRIANGULAR, 1, IB 15	
11	TW 18.38 TH 10 No. of Bays 1	K1 Down, Leg 19, DIA 44, H 21, RD 22, RH 10	EL 150 TRIANGULAR, 1, IB 15	
12	TW 19.25 TH 10 No. of Bays 1	K1 Down, Leg 23, DIA 24, H 45, RD 22, RH 22	EL 140 TRIANGULAR, 1, IB 15	
13	TW 20.12 TH 10 No. of Bays 1	K1 Down, Leg 23, DIA 24, H 45, RD 22, RH 22	EL 130 TRIANGULAR, 1, IB 15	
14	TW 21 TH 10 No. of Bays 1	K1 Down, Leg 26, DIA 24, H 47, RD 22, RH 22	EL 120 TRIANGULAR, 1, IB 15	
15	TW 21.88 TH 10 No. of Bays 1	K1 Down, Leg 26, DIA 24, H 47, RD 22, RH 22	EL 110 TRIANGULAR, 1, IB 15	
16	TW 22.75 TH 20 No. of Bays 1	K3A M Down, Leg 27, DIA 48, H 39, RHI 30, RD1 30, RHD 30, RD2 30, RHB 30, RD3 30	EL 100 TRIANGULAR, 1, IB 15	HI, RHD 16, RHH 16
17	TW 24.5 TH 20 No. of Bays 1	K3A M Down, Leg 56, DIA 48, H 45, RHI 30, RD1 30, RHD 30, RD2 30, RHB 51, RD3 30	EL 80 TRIANGULAR, 1, IB 15	HI, RHD 16, RHH 16
18	TW 26.25 TH 20 No. of Bays 1	K3A M Down, Leg 32, DIA 48, H 52, RHI 35, RD1 35, RHD 35, RD2 35, RHB 35, RD3 35	EL 60 TRIANGULAR, 1, IB 22	HI, RHD 22, RHH 22
19	TW 28 TH 20 No. of Bays 1	K3A M Down, Leg 36, DIA 48, H 52, RHI 39, RD1 39, RHD 39, RD2 39, RHB 39, RD3 39	EL 40 TRIANGULAR, 1, IB 37	HI, RHD 37, RHH 37
20	TW 29.75 TH 20 No. of Bays 1	K3A M Down, Leg 40, DIA 48, H 54, RHI 42, RD1 39, RHD 42, RD2 39, RHB 42, RD3 39	EL 20 TRIANGULAR, 1, IB 41	HI, RHD 41, RHH 41

SECTION DETAILS		
Index	Section	Material
1	BP60 8x5/16 (1/2)	A572 Gr 50
2	2L 3x3x3/16 (5/16)	A36
3	L6X3-1/2X5/16	A36
4	BP60 8x3/8 (1/2)	A572 Gr 50
5	2L2XCX3/16X3/8	A36
6	BP60 10-1/2x3/8 (1/2)	A572 Gr 50
7	2L2-1/2XCX3/16X3/8SLBB	A36
8	L1-3/4X1-3/4X1/8	A36
9	2L2XCX1/8X3/8	A36
10	L1-3/4X1-3/4X3/16	A36
11	BP60 10x1/2 (1)	A572 Gr 50

Index

A

- anchor groups, 43
- appurtenances, 72
 - configuration, 90
 - discrete, 74
 - groups, 72
 - linear, 82

B

- Bentley cloud services, 178
- bracing connections, 28

C

- Code Check, 148

D

- drilled pier foundations, 99

F

- feed lines, 86
- foundations, 92
 - design of, 111
 - guy anchors, 105
 - isolated footings, 92
- foundations
 - drilled piers, 99

G

- geometry, 12
- graphical interface reference, 135
- guy anchor foundations, 105
- guys, 42

I

- isolated footings, 92

L

- leg connections, 30
- library, 156
- load combinations
 - parameters, 66
- loads, 54
 - seismic, 68
 - wind, 54

M

- materials, 13
- modifications, 47

P

- project data, 52
- ProjectWise projects
 - associating, 179

disassociating, 180

R

reports, 123

S

scenarios

definition, 116

section catalogs, 13

section editor, 25

section property catalog, 171

seismic load definitions, 68

SPC. *See* section property catalog

T

tower model expolorer, 150

tower models

create new, 14

import from TNX, 22

open existing, 14

truss leg library, 156

U

user settings, 52

user-provided tables, 161

W

wind load definitions, 54

work order, 51