

Bentley OpenPlant Water/Wast Water WorkSpace 安装说明

目录

1. 版本历史 3
2. OPPID Workspace 安装 4
2.1 安装 Workspace 4
2.2 导入 DataManager 数据 11
3. OPM Workspace 安装 17
3.1 安装 Workspace 17

The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.

1. 版本历史

Version	Date	Author	Comments

The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.

2. OPPID Workspace 安装

2.1 安装 Workspace

1.1.1 系统需求

在执行 OpenPlant PID WWT CCK 的安装程序之前，请先安装 OpenPlant PID V8i 08.11.11.309。


1.1.2 安装过程

1) 执行 OpenPlant_PID-WWT-CCK-08.11.11.309.msi




The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.

2)　　点击【下一步】



The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.


3) *请认真阅读《奔特力软件终端用户许可协议》，如果要继续安装，请点击勾选【我接受许可协议中的条款】，然后点击【下一步】*



4) *选择安装位置*


安装程序的默认安装位置为：C:\ProgramData\Bentley\OpenPlantPID (SS6)\OPPID-WWT-Workspace\

The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.
www.bentley.com




如果需要更改安装位置，请点击【更改(C)...】按钮，在弹出的对话框中选择安装位置，例如D:\OPPID-WWT-Workspace\：

The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.
www.bentley.com




然后点击【确定】：



The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.


然后点击【下一步】继续安装过程

5)　　点击【安装(I)】



安装程序将 OpenPlant PID WWT CCK 安装到指定位置：

The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.
www.bentley.com



6) *安装完成，点击【完成(F)】按钮，结束安装过程*




The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.

WorkSpace 包含已配置好的项目，名称叫 _Water_Metric 。

2.2 导入 DataManager 数据（可选）


如果需要使用 DataManager 同步 PID 图纸数据，需要导入 DataManager project package。

导入前确认已经安装 Bentley Plant Framework（Plant Project Tools），安装包名称为 apr64 081113211en，如图。




1) 启动 Project Administrator，如图：

The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.




2) 点击 Tools>Project Packager 菜单，启动项目打包工具，如图




3) 选择 “UnPackage Project”，如图

The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley’s prior written consent.




4) 点击“Next”后选择 1.1 中安装好的 Workspace 中的“WWT Project Package.zip”压缩包，如图




The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.

5) 在 UnPackage Mode 中选择 Select Location 并设置项目数据存储路径，下图中为软件默认路径




6) 点击 Next

The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.
www.bentley.com




7) 点击 Next 后选择 Access，如图（关于数据库的更多说明请参考 Help）




The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.

8) OK 后开始解压缩及导入，根据计算机配置可能需要 10 到 30 秒或更多时间



9) 直到显示成功，如图



10) 点击 Finish，完成后点击下图刷新按钮完成导入。



The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.

3. OPM Workspace 安装


3.1 安装 Workspace

1.1.3 系统需求

在执行 OpenPlant Modeler WWT CCK 的安装程序之前，请先安装 OpenPlant Modeler V8i 08.11.11.304 或以上版本。


1.1.4 安装过程

1) 执行 OpenPlant_Modeler-WWT-CCK-08.11.11.304.msi




The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.

2)　　点击【下一步】



The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.


3) *请认真阅读《奔特力软件终端用户许可协议》，如果要继续安装，请点击勾选【我接受许可协议中的条款】，然后点击【下一步】*



4) *选择安装位置*


安装程序的默认安装位置为：C:\ProgramData\Bentley\OpenPlantModeler V8i\OPM-WWT-Workspace\

The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.




如果需要更改安装位置，请点击【更改(C)...】按钮，在弹出的对话框中选择安装位置，例如D:\OPM-WWT-Workspace\：

The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.




然后点击【确定】：



The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.


然后点击【下一步】继续安装过程

5)　　点击【安装(I)】




安装程序将 OpenPlant Modeler WWT CCK 安装到指定位置：

The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.
www.bentley.com



6)　　安装完成，点击【完成(F)】按钮，结束安装过程



The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.

WorkSpace 包含已配置好的项目，名称叫 Water_Metric 。

The information contained in this proposal is proprietary of Bentley and is not to be disclosed to any third party without Bentley's prior written consent.